



D.T.S., Inc.
27157 470th Avenue
Tea, South Dakota 57064
U.S.A.

Phone: (605) 368-5306
Fax: (605) 368-2210

www.dts-sd.com

CONTAINER MANUAL I-BEAR



Container Specifications:

Overall Dimensions:

Height:	114" w/o Chassis 158" w/ Chassis
Width:	96"
Length:	480" w/o Chassis 492" w/ Chassis
Weight:	52,500 lbs w/o fuel 59,050 lbs w/ Chassis

Cooling System Capacity:

170 Gallons
Valvoline Zerex Extended Life Coolant (ZXEDRU2)

Fuel System Capacity:

300 gallons
Diesel Fuel



Table of Contents:

1. Mechanical.....	4-19
Container Orientation	5-8
Container Setup	9
Container Maintenance	10
Container Pack Out	11
Fuel System	12-16
Cooling System	17-21
2. Electrical.....	22-35
DC Electrical System	23
Shore Power System	24-27
Fan Motor System	28-30
Power System	31-32
Control System	33-34
Grounding/Protection System	35
3. Chassis.....	36
4. Warranty	
5. Spare Parts List	



Section 1:

MECHANICAL

Container
Orientation
Setup & Maintenance

Fuel System

Cooling System



<Insert 11 x 17 Container Drawing>

Left Side View



Right Side View



Front View



Rear View



Louver Doors





Standard Operation Set Up:

1. If container is off the chassis, level the container using shims to ease end door opening.
2. Remove door restraints (105600). Return screws to original location. Apply Loctite 242 Threadlocker to bolts prior to installation.
3. Remove keys to the personnel and louver doors from the manual box.
4. Remove the steps from the radiator room. Bolt to the step mounting brackets below the personnel door. (If container is off the chassis, set steps aside.)
5. Open all (5) coolant isolation valves. Valves are located in the radiator room. Isolation valves are the (4) -3" and (1) – 5".
6. Remove the hand rail from the front of the container and install on steps.
7. Remove pre-fit rain rail from the front of the container and install above door openings using existing hardware. Seal with silicone.
8. Remove the louver covers (105587) and return screws to the original location.
9. Remove the fuel connection cover (105588) and return screws to the original location.
10. Remove the exhaust cover (105598).
11. Remove the exhaust elbow (105363) from the genset skid-frame, and install on the exhaust on the left side of the container. Make sure to install a full-faced gasket (101011) between the exhaust flanges.
12. Remove the wire tie securing the rain cap.
13. Remove ship along items.
14. Open louvers.
15. Check fluid levels.



Container Maintenance:

1. Inspect & Clean Louvers
2. Touch up paint where needed
3. Hinges - Light Oil (wipe off excess)
4. Hardware/Latches - Graphite
5. Exhaust - drain condensation
6. Fill caps/Fill cap wrench



Container Pack-Out:

1. Remove the exhaust elbow (105363) from the left side of the container. Bolt elbow to the genset skid –frame. Secure the rain cap with a wire tie.
2. Bolt the exhaust cover (105598) to the exhaust flange on the left side of the container.
3. Install and seal louver covers (105587) to the (4) exterior louvers using #10 stainless screws provided and silicone sealant.
4. Install and seal fuel connection cover (105588) using #10 stainless screws provided and silicone sealant.
5. Secure (2) coiled control cables provided by Cummins to the floor in the operator area.
6. Verify coolant isolation valves are in closed position.
7. Verify coolant drain valves are in closed position.
8. Seal the Manual and keys for the personnel and louver doors in a plastic bag and secure in the manual box.
9. Remove steps and rail from personnel door. Stow the steps in the radiator room and bolt to brackets provided on the midwall. Secure hand rail at front of the container between the Power Circuit Breaker and the container wall using the conduit clamp (s) provided.
10. Remove rain rail above doors and secure to hand rail at the front of the container. Insert screws back into original location.
11. Attach door restraints (105600) using bolts provided. Apply Loctite 242 Threadlocker to bolts prior to installation.

FUEL SYSTEM



Fuel In/Out and Vents



Daytank


Fuel/Water Separator




Generator Filters/Pump




300 Gallon Daytank with Fill Pump



Daytank Wiring Diagram



Daytank Normal Operation



GENERAL SEQUENCE OF OPERATION


When power is applied to the day tank, the pump/motor will begin to fill the day tank.

- As the fuel rises to the 86% level, the PS1 (Pump/Motor-ON) float switch opens and the tank continues to fill.
- When the fuel level reaches the 100% level, the PS2 (Pump/Motor OFF) float switch opens and stops the pump/motor.
- As the generator engine consumes fuel and the level drops to the 86% level, the pump/motor will fill the tank until the 100% fuel level is reached. PS1 turns on the pump/motor — PS2 turns it off.
- If the fuel level drops to 75%, the LOW FUEL SWITCH (option 203) closes allowing a light on the control panel to illuminate.
- If the fuel in the tank should reach 102% full, the HIGH FUEL SWITCH (Option 209) will close sending a high fuel level signal to the day tank terminal block.

- If the fuel level rises to 103%, the CRITICAL HIGH FUEL SWITCH (option 213) closes allowing the following:
 - a Critical High Fuel light on the control panel to illuminate,
 - a N.O. solenoid valve will close causing the pump/motor to stop, and
 - a set of dry contacts, to be used for remote annunciation, will become active.
- If the fuel rises 10.5% in the secondary containment (if installed), the RUPTURE ALARM SWITCH (option 395) closes allowing the following:
 - a Rupture Alarm light on the control panel to illuminate,
 - the pump/motor to stop, and
 - a set of dry contacts, to be used for remote annunciation, will become active.

Daytank Pump Performance

PUMP EXPLODED VIEW and PARTS LIST
-OPT #402 - 2 GPM, OPT #401 - 4 GPM, OPT #400 - 8 GPM-



PARTS LIST

NO.	PART NAME	REQ.	NO.	PART NAME	REQ.	NO.	PART NAME	REQ.
1	Screw	6	7	Pin	1	15	Plug Nut*	1
2	Body	1	8	Drive Shaft	1	16	Ball*	1
3	Gasket	1	9	Cover	1	17	Spring*	1
4	Bearing	4	10	Seal	1	18	Adjusting Screw*	1
5	Idle Shaft	1	11	Coupling	1	19	Lock Nut*	1
6	Gear	2	12	Cap Screw	1	20	Valve Nut*	1

* Parts For Pressure Relief Valve

PUMP PERFORMANCE CHART - 1725 RPM MOTOR AT 60° F.

PUMP	PSI	2	20	40	60	80	100	125	150
#402	GPM	2.10	1.98	1.86	1.74	1.62	1.50	1.35	1.20
2GPM	HP REQ.	.05	.09	.14	.18	.23	.28	.33	.39
	MOTOR HP	1/3	1/3	1/3	1/3	1/3	1/3	1/3	1/3
#401	GPM	4.07	3.75	3.41	3.08	2.73	2.37	2.00	1.62
4GPM	HP REQ.	.10	.16	.22	.29	.36	.43	.55	.68
	MOTOR HP	1/3	1/3	1/3	1/3	1/2	1/2	3/4	3/4
#400	GPM	8.25	7.75	7.00	6.50	5.50	-	-	-
8GPM	HP REQ.	.38	.50	.73	.80	.95	-	-	-
	MOTOR HP	1/2	1/2	3/4	1	1	-	-	-



Daytank Maintenance

PUMPS - The standard pump is a 2 GPM Bronze Gear Pump. Other pump models include: 4, 6, 10, 20, and 40 GPM. Each come with or without a pressure relief valve. This information generally applies to all models

The pump is driven directly from the shaft of the electric motor by means of a flexible coupling. An aluminum adapter connects the pump to the motor.

The pump is of bronze construction with stainless steel shafts, positive spring-loaded buna lip seals, and self-lubricating carbon bearings.

Due to close tolerances of components, fuel to the pump must be clean. Fine abrasives such as sand, silt, and powders in suspension will destroy its pumping ability. ~~A fuel strainer (Pryco option # 314 or 315) should be installed just ahead of the pump (and solenoid valves, check valves, and other like devices) to keep debris from entering the system.~~

The pump's basic metals construction allow a temperature range of -40°F. to +400°F.; however, the buna lip seals have a temperature limit of +250°F. Avoid extreme temperatures and rapid fluctuations as they are detrimental to the pump's service life.

The pump is capable of creating 18 (plus) inches of vacuum on the suction side and up to 100 psi on the discharge side. Refer to pages 4 and 5 for a chart of the performance of each pump at 1725 RPM.

~~Before starting the system for the first time, you should apply some fuel oil through a priming tee (Pryco option #312) to wet the pump gears. The fuel retained in the system lines and the gear chambers serve to wet the gears on subsequent starts.~~

MOTORS - The standard motor coupled to the pump has these characteristics: 1/3 HP, 115 VAC, 1 PH, 60 Hz, Thermal Protected, 6.6 FL Amps, 1.0 Service Factor.

The standard motor is special split phase with moderately high starting torque as well as a moderately high starting current. The thermal protected motors have internal, automatic protectors that will reset after the motor cools. Other motor configurations available range from 1/4 HP VDC motors up to 5 HP, 460 VAC.

Install power to the motor(s) according to National Electrical Code.

MOTOR LUBRICATION



Sleeve Bearings - re-oil using #5W-20 oil every 3000 hours of motor operation.

Ball Bearings - If the motor has provision for re-greasing, use a good grade of bearing grease every 2000 hours.

If lubrication instructions appear on the motor, they will supercede these instructions.

Do not use unauthorized repair parts. These can affect proper and safe operation of the motor. Contact Pryco for replacement motors.

Cooling System





Radiator Model: VC046S52 With 75 Horsepower Motor 460v 60hz 3 phase



I.E.A., INC.
FAN/MOTOR RUN-UP SHEET

S.O. # 16187 RADIATOR MODEL # VC046S52 RUN-UP # 2 of 42

DIRECT DRIVE V-BELT DRIVEN QSK50 ENG DRIVEN AT _____ RPM

FAN DATA: IEA P/N 410136 MFG Truflow DIA. 72" BLADES 11

TIP SPEED = FAN RPM x FAN DIA. IN FT. x 3.14

DESIGN	RUN-UP
<u>18.7</u>	<u>18.7</u>
<u>7.1</u>	<u>7.1</u>
FAN SHEAVE DIA.	
DRIVE SHEAVE DIA.	
FAN RPM	
TIP SPEED, FPM	
FAN HP	

APPLICATION
 BLOWER
 SUCKER

CRITICAL SPEED (S) RPM _____
 MAX. TIP SPEED, FPM 1500
 MIN. TIP SPEED FPM _____

MOTOR DATA:
 TEST MOTOR
 MOTOR ON RADIATOR HP 75

MFG Wackenhut SERIAL # OR MODEL # KSJ07A707006
 FRAME 3657 SF 1.15 VOLTS 230/460
 RPM 1725 HZ 60 PH 3
 FL AMPS 1702/1851 FL EFF. 95.4 FL PF _____

HP: 75
 PHASE: 3
 FREQUENCY: 60 HZ
 VOLTAGE: 230/460 VAC
 RPM: 1750 +/-25
 FRAME SIZE: 3657
 ENCLOSURE: TEFC
 SERVICE FACTOR: 115
 EFFICIENCY: STANDARD OR BETTER
 AMBIENT RATING: 50°C
 BEARINGS: SHIELDED OR SEALED
 CONDUIT BOX LOCATION: F1
 PREFERRED CONDUIT SIZE: STANDARD
 HOUSING CONSTRUCTION: MFG STD
 MOUNTING: FEET MOUNT
 ORIENTATION: HORIZONTAL
 APPLICATION: OUTDOOR ENVIRONMENT
 SEAL: MINIMUM OF SLINGER ON SHFT. MANUFACTURER'S ALTERNATIVES ALLOWED IF BETTER.
 SPECIAL FEATURES:

MANUFACTURER: _____ MANUFACTURER'S PART OR MODEL NUMBER: _____

MARATHON
 RELIANCE
 BALDOR
 US ELCC
 WEG

FOR FINISH TO BE APPLIED BY IEA SEE THE SDH FOR THE SUFFIX SPECIFIED. FOR SUFFIX DETAIL SEE CS-3008 ***

MODEL NO.	FRAME	HP	PH	FL AMP	FL EFF.	FL PF	FL SPEED	FL VOLT	FL HZ
MOTOR 75 HP	3657	75	3	1702/1851	95.4		1725	230/460	60



Cleaning Procedures

Periodically inspect the radiator core for signs of damage, corrosion, and clogging. Straighten any fins that have become bent or have been flattened. If the radiator core appears to be clogged with debris, it should be cleaned using water and mild detergent that does not react with copper or aluminum. Clean the cores from the AIR DISCHARGE side of the radiator to avoid pushing the debris further into the core. Clean the outside of the radiator, if dirty, to aid in routine inspection of the cooling system. Take care to keep all sight glasses clean to ease system fluid inspection. Repair or replacement of the core should be performed by qualified service personnel. If any air filters are used upstream of the core, inspect and replace as needed. Periodically test coolant fluid samples to assure it is free of sediment, corrosive products, and/or biological contaminants. If automatic air vents are not used in the cooling system, periodic air venting should be performed to remove accumulated air. CAUTION should be exercised when venting the cooling system to avoid injury. High pressure and/or high temperature fluids can cause serious injury. If the core is to be stored during the winter, the coolant should be removed and the system thoroughly dried to avoid system damage due to freezing, unless an anti-freeze agent is used in the cooling system.

Lubrication Procedure and Interval

Radiators using bearings require greasing at an interval dependant upon their usage. The table below shows a lubrication maintenance schedule according to service hours. All radiators should be greased with Shell Avania #3 lithium base grease or equivalent. DO NOT MIX GREASE TYPES. Radiators requiring different lubricant or lubrication methods will be specified on the radiator drawing.

SERVICE HOURS	LUBRICATION FREQUENCY
40 Hours per Year	Every Six Months
18 Hours per Day	Twice a Month
18 Hours per Day (Dirty Environment)	Once Each Week
24 Hours per Day	Once Each Week
24 Hours per Day (Dirty Environment)	Daily


When lubricating pillow block bearings, add grease slowly until it shows slightly at the seals. This indicates proper bearing lubrication. The use of excessive pressure when greasing the bearing can pop the bearing seals. Electric motor bearings should always be kept between 1/2 and 3/4 full. This will ensure proper lubrication to the motor. Both pillow block and electric motor bearings should be serviced using the maintenance schedule above.

Belt Tension Procedure

Radiators using V-belt driven fans should have the belt tensions checked regularly. On remote units, belts and sheaves are installed by IEA. On EC-F type units, belts and sheaves may be supplied by IEA, but are mounted by the customer. IEA recommends periodic checks using a tachometer to ensure compliance of fan speed to specifications.

1. All sheaves MUST be aligned correctly to ± 0.0625 , or premature belt failure may occur. Use a long level to check sheave alignment (see Fig. 31).
2. Install the belts onto the sheaves. Tension the belts on the slack-side of the drive with the idler until the correct belt tension is achieved. Follow the operating instructions of the belt tensioning gage being used to measure belt tension.
3. Recheck the belt tension after 24 hours of operation - after the belts have seated in the sheave grooves.

Aeroquip/Flexmaster Joints



Aeroquip/Flexmaster Joints

Pipe and tubing preparation and FLEXMASTER joint installation instructions

1. Pipe (Tube) End Preparation
 - a) Deburr and clean pipe (tube) ends.
 - b) Surface should be free of deep scratches, gouges, dents, dirt, etc.
2. Joint Installation
 - a) Install retainer (1), gasket (2) and sleeve (3) on one side of pipe in sequence shown in Figure 1.
 - b) Install remaining retainer (4) and gasket (5) on other pipe end.
 - c) Position retainer (4) and gasket (5) to proper pipe insertion depth ("D") as shown in Table 1.




Figure 1

- d) Slide sleeve (3) to gasket (5) and move gasket (2) and retainer (1) into position as shown in Figure 2. Pipe must be inserted to proper depth ("D") into both gaskets as shown in Table 1.




Figure 2

3. Special Notes

- a) Assembly of gaskets can be made easier by dipping gaskets in water or the fluid to be sealed. The use of other rubber lubricants can be detrimental to the life of the gaskets. Never lubricate the metal parts.

- b) Self-restrained gasket installation. To simplify installation of a self-restrained gasket, install lower gasket halfway onto the pipe first, leaving the split area in the steel retaining ring free at the top. See Figure 3. Then, stretch the gasket and split area of the retaining ring until they slip over the tube or pipe and into position. Refer to Figure 3.




Figure 3

4. Coupler Installation

- Install both V-couplings, encompassing the retainer, gasket and sleeve as shown in Figure 4. Do not tighten either coupling until the entire joint is assembled (See Figure 2). Tighten nuts to the torque specified in Table 2. Do not lubricate the nut or bolt before assembly. The gap method outlined in Table 3 may be used for standard gaskets only.




Figure 4



Section 2: ELECTRICAL SYSTEMS

DC Electrical System

Shore Power System


Fan Motor System

Power System

Control System

Grounding/Protection System

DC Electrical System



Shore Power System



Shore Power Entrance



Shore Power Panel (120/208V 3 PH)

Engine Water Jacket Heater




AC Lights (120V)



Shore Power System



Outlets (Receptacles) 120V



Control Panel Heater (208V)

Alternator Heater (120V)



Daytank Pump & Controls (120V)






Shore Power System




Battery Charger (120V)

Shore Power: One-Line Diagram



Wiring Diagram



NOTE:
ALL CONDUITS GROUNDED

Fan Motor System



Genset Output (4160V)



Minibreak (4160V)

Minibreak (4160V) - Inside



**Transformer
(4160V Primary/480V Secondary)**



Fan Motor System




Soft Start (480V)




Radlator Fan Motor (480V)

Fan Motor System: One-Line Diagram



Wiring Diagram



Power System



Genset (4160V)



Breaker (4160V) – operator view

Breaker (4160V) – output view




Load Connection Box (4160V)





Power System Wiring Diagram



Control System



Generator Control Panel



Control Output Box

Control Output Box


DMC



Control System Schematic



D.T.S., Inc.



- NOTES:
1. INTERCONNECTION WIRING TO BE 14 AWG STRANDED WIRE MINIMUM. AC AND DC CONTROL WIRES TO BE RUN IN SEPARATE CONDUITS.
 2. BATTERY CHARGER TO BATTERY WIRING TO BE SIZED FOR CHARGER OUTPUT AND LENGTH OF RUN.
FOR DC CONNECTIONS: USE 14 AWG OR LARGER FOR WIRE UP TO 40 FEET.
USE 12 AWG OR LARGER FOR WIRE UP TO 50 FEET.
USE 10 AWG OR LARGER FOR WIRE UP TO 100 FEET.
FOR AC CONNECTIONS: USE 14 AWG OR LARGER FOR WIRE UP TO 100 FEET.
USE 12 AWG OR LARGER FOR WIRE UP TO 150 FEET.
 3. NET DATA WIRES TO BE MINIMUM 22 AWG (NEW LEVEL IV TWISTED PAIR COMMUNICATIONS CABLE ONLY PART NUMBER 23-1550 (PVC) OR 23-1131 (UL94V-0 PAID)) IS RECOMMENDED. CONNECTIONS ARE NOT POLARITY SENSITIVE. CONSULT THE MANUFACTURER'S DATA SHEET FOR WIRING INFORMATION. ALL WIRING CROSSINGS 4000 FEET DO NOT RUN IN CONDUIT WITH OTHER INTERCONNECT WIRES.

Grounding/Protection System



Surge Arrestors

Shore Power Inlet



Load Connection Box



Section 3: CHASSIS

