

Engine Serial Number - SYC01128 (Build Date - 26/01/2007, Test Date - 06/02/2007, Ship Date - unknown)

[View Latest Kit Information](#)

▼ ENGINE - ENTIRE GROUP (SYC01128)

Qty.	Note	Part No.	Change Level	Req. Qty	Part Name
	IY	<a href="#">274-1894</a>	00	001	GENERAL AR
	IRY	<a href="#">273-9683</a>	05	001	ENGINE AR-COMPLETE
	IY	<a href="#">205-7860</a>	08	001	FILM GP
	IY	<a href="#">262-8092</a>	00	001	GENERATOR AR
	IY	<a href="#">260-0892</a>	07	001	INSTALLATION AR-GENERATOR
	IY	<a href="#">271-8138</a>	03	001	ADAPTER GP-GENERATOR COUPLING
	IY	<a href="#">245-0000</a>	02	001	BOX GP-CONTROL PANEL
	IKY	<a href="#">245-0095</a>	01	001	WIRING GP-GENERATOR
	IY	<a href="#">245-0082</a>	01	001	CONTROL GP-GENERATOR SET
	IY	<a href="#">252-7367</a>	01	003	MOUNTING GP-PANEL
	IY	<a href="#">252-7409</a>	01	001	FASTENER GP-WIRING HARNESS
	IY	<a href="#">245-0003</a>	04	001	BOX GP-EXTENSION TERMINAL
	IY	<a href="#">269-7013</a>	02	001	COVER GP-GENERATOR
	IY	<a href="#">252-7344</a>	02	001	BUS BAR GP-BOX
	IY	<a href="#">270-1480</a>	00	001	RAIL GP-SLIDE
	IY	<a href="#">245-0087</a>	04	001	MOUNTING GP-CONTROL PANEL
	IKY	<a href="#">252-7372</a>	01	001	WIRING GP-GENERATOR
	IKY	<a href="#">252-7418</a>	03	001	WIRING GP-GENERATOR
	IY	<a href="#">252-7556</a>	00	002	COVER GP-CONTROL PANEL
	IY	<a href="#">260-6666</a>	04	001	CONNECTION GP-GENERATOR LEADS
	IY	<a href="#">252-7411</a>	08	001	GROUND GP-ELECTRICAL
	IY	<a href="#">245-0001</a>	00	001	COVER GP-CONTROL PANEL
	IY	<a href="#">245-0013</a>	01	001	COVER GP-GENERATOR
	IY	<a href="#">245-0007</a>	01	002	COVER GP-GENERATOR
	IY	<a href="#">245-0023</a>	01	001	COVER GP-CONTROL PANEL
	IY	<a href="#">245-0027</a>	03	001	COVER GP-ENCLOSURE
	IY	<a href="#">245-0096</a>	00	001	COVER GP-EXTENSION BOX
	IY	<a href="#">245-0025</a>	00	001	COVER GP-EXTENSION BOX
	IY	<a href="#">245-0024</a>	00	001	COVER GP-ENCLOSURE
	IY	<a href="#">252-7700</a>	00	001	PLUG GP-BOX
	IY	<a href="#">255-3436</a>	11	001	RADIATOR GP
	IY	<a href="#">256-9937</a>	01	001	FAN GP-BLOWER
	IY	<a href="#">270-0453</a>	07	001	LINES GP-AIR
	IY	<a href="#">261-0653</a>	07	001	LINES GP-COOLANT
	IY	<a href="#">271-3843</a>	02	001	LINES GP-ENGINE OIL DRAIN
	IY	<a href="#">257-0360</a>	07	001	LINES GP-AIR
	IY	<a href="#">271-3840</a>	07	001	LINES GP-FUEL

**PART NUMBERS**

	IY	<a href="#">271-3845</a>	03	001	FUMES DISPOSAL GP
	IY	<a href="#">267-3346</a>	04	001	BASE GP-ENGINE & GENERATOR
	IY	<a href="#">275-0030</a>	00	001	COVER GP-ENGINE LIFTING EYE
	IY	<a href="#">275-0032</a>	00	001	COVER GP-ENGINE LIFTING EYE
	IKY	<a href="#">121-3364</a>	04	001	SENSOR & MTG GP-RADIATOR
	IY	<a href="#">263-1745</a>	01	001	WIRING GP-BOX
	IY	<a href="#">252-7438</a>	03	001	PLUG GP-BOX
	IY	<a href="#">281-2747</a>	00	001	HARNESS GP
	IY	<a href="#">281-3146</a>	02	001	DRIVE GP-FAN
	IY	<a href="#">263-1743</a>	02	001	CONTROL GP-EMCP ELECTRONIC
	IKY	<a href="#">263-1744</a>	04	001	BOX GP-ELECTRONIC
	IY	<a href="#">252-7347</a>	01	001	WIRING GP-PANEL
	IY	<a href="#">252-7328</a>	03	001	TRANSFORMER GP-CURRENT
	IY	<a href="#">261-3291</a>	00	001	STARTING MOTOR GP-ELECTRIC
	IY	<a href="#">260-9520</a>	01	001	WIRING GP-ELECTRIC STARTING
	IY	<a href="#">280-7395</a>	02	001	COVER GP-ENGINE
	ILY	<a href="#">268-3890</a>	03	001	COVER GP-ACCESS
	IY	<a href="#">255-3438</a>	05	001	GUARD GP-BELT
	IRY	<a href="#">5N-5692</a>	12	001	ALTERNATOR GP-CHARGING
	IY	<a href="#">256-7170</a>	02	001	MOUNTING GP-ALTERNATOR
	IY	<a href="#">260-9522</a>	03	001	WIRING GP-ELECTRONIC CONTROL
	IY	<a href="#">280-1442</a>	03	001	PUMP GP-PRELUBRICATION
	IY	<a href="#">280-7391</a>	01	001	REGULATOR GP-OIL LEVEL
	SY	<a href="#">5N-2457</a>	06	001	FITTING GP-EXHAUST
	SY	<a href="#">279-3216</a>	01	001	MOUNTING GP-ENGINE FLEXIBLE
	SY	<a href="#">279-3217</a>	01	001	MOUNTING GP-VIBRATION ISOLATOR
	IY	<a href="#">286-0348</a>	00	001	SHIELD GP-HEAT
	IKY	<a href="#">252-7362</a>	00	001	WIRING GP-PANEL
	IY	<a href="#">275-9901</a>	04	001	WIRING GP-JACKET WATER HEATER
	IY	<a href="#">292-2541</a>	03	001	HEATER GP-JACKET WATER
					<b>SHIPPED LOOSE</b>
	SY	<a href="#">5N-2457</a>		001	FITTING GP-EXHAUST
	SY	<a href="#">6L-4502</a>		001	CHART-PLATE & FILM
	SY	<a href="#">271-3845</a>		001	FUMES DISPOSAL GP
	SY	<a href="#">279-3216</a>		001	MOUNTING GP-ENGINE FLEXIBLE
	SY	<a href="#">279-3217</a>		001	MOUNTING GP-VIBRATION ISOLATOR

Key:

Y Separate Illustration

I Installed

R REMFG PART MAY BE AVAILABLE

L Less Indicator

S Shipped Loose