

Engine Serial Number - 3PG00557 (Build Date - unknown, Test Date - unknown, Ship Date - unknown)

[View Latest Kit Information](#)

▼ ENGINE - ENTIRE GROUP (3PG00557)

Qty.	Note	Part No.	Change Level	Req. Qty	Part Name
					PART NUMBERS
	IY	199-3720	00	001	GENERAL AR-GENSET
	IY	3N-8594	05	001	COVER GP-ENGINE LIFTING EYE
	IY	7L-7871	08	001	BATTERY GP
	IY	142-2474	07	001	SUPPORT GP-BATTERY
	IY	142-6947	04	001	SENSOR GP-COOLANT LEVEL
	IY	154-5504	03	001	CONTROL GP-GOVERNOR
	IY	156-0040	01	001	TRANSFORMER GP-CURRENT
	IY	158-0341	02	001	FASTENER GP-GENERATOR COUPLING
	IY	160-9644	03	001	SWITCH GP-DISCONNECT
	IY	169-4450	03	001	HARNESS AS-WIRING
	IY	196-7177	04	001	PANEL GP-ELECTRONIC
	IY	196-7332	01	001	BOX GP-JUNCTION
	IY	197-3688	04	001	AIR CLEANER GP
	IY	197-8428	08	001	ENGINE AR-COMPLETE
	IY	198-9810	08	001	BOX GP-EXTENSION TERMINAL
	IY	199-6484	02	001	WIRING GP-ENGINE
	IY	218-2840	01	001	GUARD GP-PULLEY
	IY	220-6034	01	001	RADIATOR GP
	IY	220-6036	01	001	LINES GP-AIR
	IY	194-4583	00	001	GENERATOR AR
	IY	206-8791	01	001	FUMES DISPOSAL GP
	IY	222-7173	00	001	ENCLOSURE GP
	IY	195-9574	03	001	LINES GP-ENGINE OIL DRAIN
	IY	196-2947	03	001	ENCLOSURE GP-GENERATOR
	IY	196-7330	00	001	MOUNTING GP-JUNCTION BOX
	IY	217-8710	00	001	LINES GP-FUEL
	IY	218-8544	02	001	BASE GP-ENGINE & GENERATOR
	IY	220-6029	00	001	LINES GP-COOLANT DRAIN
	IY	206-9569	01	001	EXTENSION GP-BASE
	IY	143-9519	06	001	REGULATOR GP-VOLTAGE
	IY	155-8893	04	001	WIRING GP-GENERATOR
	IY	193-3262	02	001	HARNESS AS-WIRING
	IY	198-9185	01	001	MOUNTING GP-CONTROL
	IY	199-1556	03	001	CONNECTION GP-GENERATOR LEADS
	IY	190-2565	04	001	HARNESS AS-WIRING
	IY	200-0844	02	001	RELAY GP
	IY	190-2566	04	001	HARNESS AS-WIRING

	IY	200-0842	02	001	RELAY GP
	IY	171-6828	02	001	MODULE GP-INTERFACE
	IY	171-6834	06	001	MODULE GP-ALARM
	IY	131-1965	02	001	PANEL GP-INSTRUMENT
	IY	194-5280	02	001	HEATER GP-JACKET WATER
	IY	207-5406	00	001	CONNECTION GP-ELECTRICAL
	IY	114-6486	01	001	BATTERY CHARGER
	IY	199-8975	00	001	MOUNTING GP-BATTERY CHARGER
	IY	203-5570	00	001	CONNECTION GP-ELECTRICAL
	IY	169-4524	08	001	MOUNTING GP-CIRCUIT BREAKER
	IY	183-2489	01	001	CIRCUIT BREAKER GP
	IY	198-8877	02	001	COVER GP-GENERATOR
	IY	222-2331	00	001	WIRING GP-PANEL
	IY	209-6697	00	001	CONTACTOR GP

Key:

Y Separate Illustration

I Installed