

C32 GENERATOR SET

Machine Serial Number - SXC02660 (Build Date - 02/03/2008)

Engine Serial Number - SYC02592 (Build Date - 18/02/2008, Test Date - 21/02/2008, Ship Date - unknown)

[View Latest Kit Information](#)

▼ PRODUCT - ENTIRE GROUP (SXC02660)

Qty.	Note	Serial No.	Part No.	Part Name
	Y		<a href="#">253-7904</a>	GENERAL AR
	Y		<a href="#">308-5838</a>	FILM GP
	Y		<a href="#">274-5581</a>	CABLE GP-GENERATOR GROUND
(N/A)		SYC02592	1000	ENGINE
(N/A)		G5C01908	1404	GENERATOR

Key:

Y Separate Illustration

▼ ENGINE - ENTIRE GROUP (SYC02592)

Qty.	Note	Part No.	Change Level	Req. Qty	Part Name
<b>PART NUMBERS</b>					
	IY	<a href="#">253-7904</a>	02	001	GENERAL AR
	IRY	<a href="#">253-7557</a>	18	001	ENGINE AR-COMPLETE
	IY	<a href="#">205-7860</a>	08	001	FILM GP
	IY	<a href="#">260-0892</a>	08	001	INSTALLATION AR-GENERATOR
	IY	<a href="#">271-8138</a>	03	001	ADAPTER GP-GENERATOR COUPLING
	IY	<a href="#">279-0735</a>	00	001	CABLE GP-BATTERY
	IY	<a href="#">245-0000</a>	02	001	BOX GP-CONTROL PANEL
	IY	<a href="#">245-0095</a>	01	001	WIRING GP-GENERATOR
	IY	<a href="#">245-0082</a>	03	001	CONTROL GP-GENERATOR SET
	IY	<a href="#">252-7367</a>	01	003	MOUNTING GP-PANEL
	IY	<a href="#">252-7409</a>	03	001	FASTENER GP-WIRING HARNESS
	IY	<a href="#">245-0003</a>	06	001	BOX GP-EXTENSION TERMINAL
	IY	<a href="#">269-7013</a>	02	001	COVER GP-GENERATOR
	IY	<a href="#">252-7343</a>	03	001	BUS BAR GP-BOX
	IY	<a href="#">245-0087</a>	06	001	MOUNTING GP-CONTROL PANEL
	IY	<a href="#">252-7372</a>	01	001	WIRING GP-GENERATOR
	IY	<a href="#">252-7418</a>	03	001	WIRING GP-GENERATOR
	IY	<a href="#">252-7556</a>	00	002	COVER GP-CONTROL PANEL
	IY	<a href="#">260-6666</a>	05	001	CONNECTION GP-GENERATOR LEADS
	IY	<a href="#">252-7411</a>	09	001	GROUND GP-ELECTRICAL
	IY	<a href="#">245-0001</a>	00	001	COVER GP-CONTROL PANEL
	IY	<a href="#">245-0013</a>	01	001	COVER GP-GENERATOR
	IY	<a href="#">245-0007</a>	01	002	COVER GP-GENERATOR
	IY	<a href="#">245-0023</a>	01	001	COVER GP-CONTROL PANEL
	IY	<a href="#">245-0027</a>	03	001	COVER GP-ENCLOSURE

	IY	<a href="#">245-0096</a>	00	001	COVER GP-EXTENSION BOX
	IY	<a href="#">245-0025</a>	00	001	COVER GP-EXTENSION BOX
	IY	<a href="#">245-0024</a>	00	001	COVER GP-ENCLOSURE
	IY	<a href="#">255-3436</a>	12	001	RADIATOR GP
	IY	<a href="#">270-0453</a>	07	001	LINES GP-AIR
	IY	<a href="#">261-0653</a>	07	001	LINES GP-COOLANT
	IY	<a href="#">271-3843</a>	03	001	LINES GP-ENGINE OIL DRAIN
	IY	<a href="#">271-3840</a>	09	001	LINES GP-FUEL
	IY	<a href="#">271-3845</a>	03	001	FUMES DISPOSAL GP
	IY	<a href="#">267-3346</a>	05	001	BASE GP-ENGINE & GENERATOR
	SY	<a href="#">256-3167</a>	03	001	MOUNTING GP-ENGINE FLEXIBLE
	IY	<a href="#">275-0030</a>	00	001	COVER GP-ENGINE LIFTING EYE
	IY	<a href="#">275-0032</a>	00	001	COVER GP-ENGINE LIFTING EYE
	IY	<a href="#">256-9937</a>	01	001	FAN GP-BLOWER
	IY	<a href="#">270-1480</a>	00	001	RAIL GP-SLIDE
	IY	<a href="#">121-3364</a>	04	001	SENSOR & MTG GP-RADIATOR
	IY	<a href="#">263-1745</a>	03	001	WIRING GP-BOX
	IY	<a href="#">252-7438</a>	03	001	PLUG GP-BOX
	IY	<a href="#">281-2747</a>	01	001	HARNESS GP
	SY	<a href="#">256-3170</a>	01	001	MOUNTING GP-VIBRATION ISOLATOR
	IY	<a href="#">269-4149</a>	03	001	DRIVE GP-FAN
	IY	<a href="#">315-7777</a>	01	001	SUPPORT GP-BATTERY
	IY	<a href="#">287-0380</a>	02	001	MOUNTING GP-AIR CLEANER
	IY	<a href="#">262-8094</a>	00	001	GENERATOR AR
	IY	<a href="#">283-0010</a>	03	001	CONTROL GP-EMCP ELECTRONIC
	IY	<a href="#">263-1744</a>	05	001	BOX GP-ELECTRONIC
	IY	<a href="#">269-7022</a>	00	001	LIGHTING GP-GENERATOR
	IY	<a href="#">252-7329</a>	03	001	TRANSFORMER GP-CURRENT
	IY	<a href="#">273-6002</a>	07	001	LINES GP-AIR
	IY	<a href="#">308-5838</a>	03	001	FILM GP
	IY	<a href="#">261-3291</a>	00	001	STARTING MOTOR GP-ELECTRIC
	IY	<a href="#">260-9520</a>	02	001	WIRING GP-ELECTRIC STARTING
	IY	<a href="#">280-7395</a>	02	001	COVER GP-ENGINE
	ILY	<a href="#">268-3890</a>	03	001	COVER GP-ACCESS
	IY	<a href="#">295-8951</a>	00	001	BATTERY GP
	IY	<a href="#">255-3438</a>	06	001	GUARD GP-BELT
	IRY	<a href="#">5N-5692</a>	13	001	ALTERNATOR GP-CHARGING
	IY	<a href="#">260-9522</a>	04	001	WIRING GP-ELECTRONIC CONTROL
	IY	<a href="#">303-6241</a>	00	001	MOUNTING GP-ALTERNATOR
	IY	<a href="#">275-9901</a>	05	001	WIRING GP-JACKET WATER HEATER
	IY	<a href="#">292-2540</a>	03	001	HEATER GP-JACKET WATER
	IY	<a href="#">274-5581</a>	01	001	CABLE GP-GENERATOR GROUND
	IY	<a href="#">278-4176</a>	01	001	SHIELD GP-HEAT
	IY	<a href="#">286-5296</a>	02	001	SHIELD GP
					<b>SHIPPED LOOSE</b>
	SY	<a href="#">6L-4502</a>		001	CHART-PLATE & FILM


SY [256-3167](#)

001 MOUNTING GP-ENGINE FLEXIBLE

SY [256-3170](#)

001 MOUNTING GP-VIBRATION ISOLATOR

SY [271-3845](#)

001 FUMES DISPOSAL GP