

C9 Generator Set

Machine Serial Number - C9E01586

Machine Build Date - 2009/05/16

Engine Serial Number - S9L02583

Engine Build Date - 2009/04/30

Product - Entire Group (C9E01586)

Part Number	Serial Number	Part Name
259-7971		General AR
259-0241		Transformer GP-Current
8D-2676		Switch AS-Toggle
272-8238		Block AS-Terminal
236-1159		Module GP-Alarm
252-7504		Control GP-Electronic
253-3028		Connection GP-Generator Leads
1000	S9L02583	Engine
1404	G5A03440	Generator

Engine - Entire Group (S9L02583)

Part Number	Change Level	Part Name
259-7971 I	00	General AR
257-5707 I	08	Engine AR
253-3687 I		Base GP-Engine & Generator
261-0001 I		Cover GP-Control Panel
258-6763 I		Enclosure AS
236-4395 I		Cover GP-Instrument Panel
258-6782 I		Door GP
258-6776 I		Mounting GP-Divider Plate
262-6161 I		Air Cleaner GP
256-4300 I		Fumes Disposal GP
262-7395 I		Film GP
268-3282 I	00	Film GP
246-1428 I		Harness AS-Wiring
256-2079 I		Drain GP-Engine Oil

Part Number	Change Level	Part Name
244-9579 		Cover GP-Base
265-4944 		Harness AS-Wiring
265-9947 		Lines GP-Coolant
240-0170 		Box GP-Connection
253-3023 		Fastener GP-Instrument Panel
256-2077 		Radiator GP
205-7860 	10	Film GP
144-7184 	02	Cover GP-Engine Lifting Eye
213-0144 		Cover GP-Access
255-6676 		Mounting GP-Beam
241-6078 		Seal GP-Enclosure
268-8667 		Plug GP-Box
262-9635 		Mounting GP-Wiring
306-2797 	01	Coupling GP-Generator
286-8875 		Fastener GP-Wiring Harness
254-1300 	00	Generator AR
261-5132 		Control GP-Generator Set
261-8428 		Control GP-Engine Monitoring
258-6799 		Mounting GP-Control Panel
261-5828 		Relay GP
261-6623 		Panel GP-Electrical
292-5967 		Panel GP-Electrical
261-8479 		Wiring GP-Generator
243-3541 		Circuit Breaker GP
258-6812 		Cover GP-Enclosure

Part Number	Change Level	Part Name
243-5599 		Cover GP-Access
240-1621 		Wiring GP-Generator
277-3571 		Seal GP-Enclosure
284-9189 		Terminal GP-Circuit Breaker
295-2373 		Connection GP-Terminal Strip
272-2205 		Support GP-Cable
260-0568 		Bracket GP-Mounting
263-9343 		Sensor GP-Coolant Level
258-0789 		Heater GP-Jacket Water
282-9958 		Circuit Breaker GP
300-9746 		Conduit GP-Electrical
264-9682 		Lines GP-Fuel
336-8901 	00	Regulator GP-Voltage
261-8430 		Switch AS
327-0286 		Heater GP-Space
258-6778 		Panel GP-Electronic
258-6795 		Mounting GP-Terminal Strip
261-7137 		Contactor GP
239-0431 		Transformer GP-Current
261-5613 		Harness AS-Power
239-6757 		Mounting GP
266-2701 		Cover GP-Control Panel
258-6790 		Mounting GP-Bus Bar
240-1622 		Cable GP
243-4797 		Shunt-Trip

Part Number	Change Level	Part Name
237-8962 I		Harness AS-Wiring
237-7206 I		Battery GP
299-1472 I		Support GP-Battery
289-8748 I		Switch GP-Disconnect
114-6486 I	02	Battery Charger
267-9862 I		Mounting GP-Battery Charger
289-9478 I		Harness AS-Wiring
289-9479 I		Harness AS-Wiring
258-9068 I		Guard GP-Exhaust
253-3028 I		Connection GP-Generator Leads
259-0241 I		Transformer GP-Current
239-3812 I		Duct GP-Cable
330-1050 I	00	Connection GP-Generator Leads
261-0736 I		Panel GP-Electronic
6L-4502 S		Chart-Plate & Film

I - Installed

S - Shipped Loose