

C18 Generator Set

Machine Serial Number - T3500209

Machine Build Date - 2020/01/22

Engine Serial Number - CM800386

Engine Build Date -

Product - Entire Group (T3500209)

Part Number	Serial Number	Part Name
<u>461-6245</u>		General AR
1000	CM800386	Engine - -
1404	G6B25894	Generator - -

Engine - Entire Group (CM800386)

Part Number	Change Level	Part Name
<u>461-6245</u> I	00	General AR
<u>419-0904</u> I	06	Engine AR-Complete
<u>356-0117</u> I	01	Fumes Disposal GP
<u>374-5706</u> I	00	Cover GP-Engine Lifting Eye
<u>461-6300</u> I	01	Installation AR-Cem
<u>450-3088</u> I	00	Lines GP-Exhaust
548-5016 I	00	Harness AS-Wiring
<u>418-3907</u> I	01	Generator AR
<u>461-6308</u> I	05	Panel GP-Electronic
<u>356-0121</u> I	00	Control GP-Generator Set
<u>399-9212</u> I	02	Harness AS-Panel
<u>441-6937</u> I	06	Control GP-Voltage

Part Number	Change Level	Part Name
<u>399-9188</u> I	03	Harness AS-Power
<u>390-1194</u> I	03	Harness AS-Power
<u>390-1193</u> I	03	Harness AS-Power
<u>561-2892</u> I	00	Marker AS-Terminal
<u>461-6309</u> I	02	Panel GP-Electrical
<u>461-6311</u> I	01	Wiring GP-Engine
<u>374-5740</u> I	01	Wiring GP-Sensor
<u>418-3946</u> I	00	Conduit GP-Electrical
<u>468-3000</u> I	01	Module AR-Clean Emissions
<u>419-5595</u> I	01	Cover GP-Enclosure
<u>419-5596</u> I	01	Cover GP-Access
<u>390-4880</u> I	02	Duct GP-Cable
<u>420-0302</u> I	00	Bar GP-Ground
<u>442-7827</u> I	01	Mounting GP-Wiring
<u>449-0638</u> I	03	Enclosure GP-Genset
<u>461-6312</u> I	03	Radiator & Fan GP
<u>375-2299</u> I	00	Module GP-Alarm
<u>399-9192</u> I	01	Harness AS-Wiring
<u>374-5748</u> I	01	Relay GP-Accessory
<u>443-7017</u>	00	Mounting GP-Transformer

Part Number	Change Level	Part Name
<u>374-5739</u> I	02	Panel GP-Electrical
<u>360-8830</u> I	03	Air Cleaner GP
461-6316 I	00	Enclosure GP-Generator
<u>390-1219</u> I	03	Harness AS-Power
447-9517 I	00	Cap AS-Rain
<u>366-2203</u> I		Exciter AS
<u>443-0637</u> I	01	Harness AS-Wiring
<u>374-5742</u> I	01	Wiring GP-Heater
<u>239-9949</u> I		Heater GP-Space
461-6195 I	02	Base GP-Engine & Generator
461-6204 I	03	Drain GP-Oil
<u>416-9013</u> I	01	Bracket GP-Mounting
<u>441-0461</u> I	00	Mounting GP-Bracket
461-6197 I	00	Tank GP-Fuel
461-6327 I	03	Lines GP-Fuel
<u>399-9199</u> I	01	Wiring GP-Sensor
<u>422-6083</u> I	00	Cover GP-Engine Lifting Eye
<u>422-6080</u> I	00	Mounting GP-Hydraulic Tank
<u>464-7490</u> I	00	Mounting GP-Hydraulic Tank

Part Number	Change Level	Part Name
<u>339-5996</u> I	01	Battery Charger
<u>399-9218</u> I	04	Harness AS-Power
<u>115-2422</u> I	09	Battery GP
<u>461-6318</u> I	02	Cable GP
<u>535-6407</u> I	00	Support GP-Battery
<u>461-6198</u> I	02	Heater GP-Jacket Water
<u>461-6320</u> I	02	Wiring GP-Jacket Water Heater
<u>384-4305</u> I		Regulator GP-Temperature
<u>393-2340</u> I	02	Mounting GP-Transformer
<u>420-1480</u> I	01	Connection GP-Generator Leads
<u>423-0805</u> I	00	Mounting GP-Connector
<u>390-4857</u> I	02	Plate GP-Cover
<u>398-4246</u> I	02	Mounting GP-Engine & Generator
<u>233-9351</u> I		Coupling GP-Generator
<u>393-2375</u> I	02	Bar GP-Ground
<u>422-7343</u> I	00	Mounting GP-Connector
<u>456-5303</u> I	00	Connection GP-Generator Leads
<u>423-5429</u> I	00	Connection GP-Generator Leads
<u>423-5435</u> I	00	Mounting GP-Connector
<u>520-4219</u>	00	Film GP

Part Number	Change Level	Part Name
I		
<u>421-6990</u> I	01	Connection GP-Generator Leads
<u>416-6948</u> I	00	Mounting GP-Connector
<u>443-0294</u> I	00	Support GP-Cable
<u>399-9186</u> I	04	Harness AS-Power
<u>461-6372</u> I	03	Circuit Breaker GP
<u>393-2372</u> I	04	Cover GP-Enclosure
<u>461-6423</u> I	01	Containment GP-Fluid
<u>463-2662</u> S	00	Switch AS-Stop
<u>519-0520</u> I	03	Enclosure GP-Generator
<u>504-3122</u> I	00	Module AR-Diesel Exhaust Fluid
<u>356-0205</u> I	01	Switch GP-Disconnect
461-6314 I	03	Film GP
461-6451 I	00	Film GP
G6B25894		
T3500209		
I - Installed		