

**G3408 Gas Engine**

Engine Serial Number - 6NB05019

Engine Build Date -

**Engine - Entire Group (6NB05019)**

Part Number	Change Level	Part Name
<u>214-7182</u> I	04	Engine AR
<u>2W-0587</u> I	04	Lines GP-Oil Supply
<u>2W-1432</u> I	07	Aftercooler GP-Treated Water
<u>2W-1857</u> I	05	Control GP-Carburetor
<u>2W-2046</u> I	09	Lines GP-Turbocharger Oil
<u>4N-2328</u> I	07	Meter GP-Service
<u>4N-4286</u> I	08	Support GP-Engine
<u>4P-3442</u> I	02	Mounting GP-Air Cleaner
<u>4P-3445</u> I	06	Air Cleaner GP
<u>4P-3448</u> I	01	Carburetor GP
<u>4P-3449</u> I	04	Lines GP-Air
<u>4P-3943</u> I	08	Regulator GP-Gas Pressure
<u>4P-6023</u> I	14	Bypass GP-Exhaust
<u>4W-8052</u> I	02	Turbocharger GP
<u>7N-9078</u> I	01	Support GP-Engine
<u>9Y-1268</u> I	04	Pump GP-Auxiliary Water
<u>110-7837</u>	03	Control GP-Governor

Part Number	Change Level	Part Name
<u>111-6835</u> I	07	Lines GP-Water
<u>119-6229</u> I	03	Manifold GP-Exhaust
<u>135-6298</u> I	05	Lines GP-Water
<u>135-8583</u> I	00	Pulley GP-Crankshaft
<u>139-9028</u> I	02	Damper & Pulley GP
<u>163-8068</u> I	03	Drive GP-Governor
<u>1W-1340</u> I	03	Mounting GP-Alternator
<u>2S-7227</u> I	19	Starting Motor GP-Electric
<u>4W-6327</u> I	09	Panel GP-Instrument
<u>5N-0369</u> I	07	Circuit Breaker GP
<u>6N-9294</u> I	17	Alternator GP-Charging
<u>8M-7892</u> I	20	Ammeter GP
<u>9W-1077</u> I	06	Switch GP-Start
<u>101-8633</u> I	04	Wiring GP-Shutoff
<u>101-8637</u> I	01	Wiring GP-Alternator
<u>102-9281</u> I	05	Shutoff GP-Electrical
<u>216-4018</u> I	03	Ignition GP-Gas Engine
<u>7N-8844</u> I	03	Drive GP-Fan
<u>103-0692</u> S	08	Valve GP-Solenoid

Part Number	Change Level	Part Name
<u>4N-3465</u> <b>S</b>	12	Fan GP-Blower
<u>4N-3465</u> <b>S</b>		Fan GP-Blower
<u>4N-3339</u> <b>S</b>		Spider AS
<u>8T-4223</u> <b>S</b>		Washer-Hard
<u>8T-8919</u> <b>S</b>		Bolt
<u>4P-3445</u> <b>S</b>		Air Cleaner GP
<u>4W-5828</u> <b>S</b>		Cap AS-Air Cleaner
<u>103-0692</u> <b>S</b>		Valve GP-Solenoid
<u>110-7837</u> <b>S</b>		Control GP-Governor
<u>131-5451</u> <b>S</b>		Control AS-Governor
<u>216-4018</u> <b>S</b>		Ignition GP-Gas Engine
<u>2S-6024</u> <b>S</b>		Fuse
<u>8T-6342</u> <b>S</b>		Tube-Heat Shrink
<u>9G-2731</u> <b>S</b>		Holder AS-Fuse
<u>163-6164</u> <b>S</b>		Control GP-Timing
<u>6L-4502</u> <b>S</b>		Chart-Plate & Film