

🔍 ⚙️ 📄

- > **Remote Service**
- > **New Information (Last 30 days)**
- > **Alternate Parts**

▼ **Product Configuration**

3456 Generator Set
 Machine Serial Number - C4G00856
 Machine Build Date - 2006/09/22

Engine Serial Number - 3PG02526
 Engine Build Date - 2006/08/24

Product - Entire Group (C4G00856)

Part Number	Serial Number	Part Name
-------------	---------------	-----------

281-6035		General AR
--------------------------	--	------------

259-0243		Transformer GP-Current
--------------------------	--	------------------------

0V-2329		Production Correction
---------	--	-----------------------

283-9174		Connection GP-Electrical
--------------------------	--	--------------------------

237-9990		Connection GP-Terminal Strip
--------------------------	--	------------------------------

282-6288		Cover GP-Base
--------------------------	--	---------------

283-9184		Strip GP-Terminal
--------------------------	--	-------------------

1000	3PG02526	Engine
------	----------	--------

1404	G6B03395	Generator
------	----------	-----------

Engine - Entire Group (3PG02526)

Part Number	Change Level	Part Name
-------------	--------------	-----------

283-9174	F	Connection GP-Electrical
--------------------------	---	--------------------------

237-9990	F	Connection GP-Terminal Strip
--------------------------	---	------------------------------

281-6035	01	General AR
--------------------------	----	------------

282-1911	01	Engine AR-Complete
--------------------------	----	--------------------

235-1211		Generator AR
--------------------------	--	--------------

237-7198	05	Lines GP-Fuel
--------------------------	----	---------------

239-0433		Transformer GP-Current
--------------------------	--	------------------------

239-6758		Mounting GP-Control Panel
--------------------------	--	---------------------------

240-1621		Wiring GP-Generator
--------------------------	--	---------------------

238-0009		Cover GP-Access
--------------------------	--	-----------------

233-9351		Coupling GP-Generator
--------------------------	--	-----------------------

233-9391		Air Cleaner GP
--------------------------	--	----------------

217-3789		Radiator GP
--------------------------	--	-------------

219-1899		Lines GP-Coolant Drain
--------------------------	--	------------------------

237-7204		Support GP-Battery
--------------------------	--	--------------------

237-7206		Battery GP
--------------------------	--	------------

218-2840	02	Guard GP-Pulley
--------------------------	----	-----------------

144-7184	02	Cover GP-Engine Lifting Eye
--------------------------	----	-----------------------------

142-6866	05	Lines GP-Engine Oil Drain
--------------------------	----	---------------------------

240-4116		Fumes Disposal GP
--------------------------	--	-------------------

235-9566		Panel GP-Electronic
--------------------------	--	---------------------

236-4395		Cover GP-Instrument Panel
--------------------------	--	---------------------------

235-7992		Cover GP-Instrument Panel
--------------------------	--	---------------------------

235-7998		Cover GP-Instrument Panel
--------------------------	--	---------------------------

240-0170		Box GP-Connection
--------------------------	--	-------------------

237-1852		Harness AS-Engine
--------------------------	--	-------------------

235-9063		Wiring GP-Panel
--------------------------	--	-----------------

236-4560		Seal GP-Enclosure
--------------------------	--	-------------------

235-8332		Panel GP-Control
--------------------------	--	------------------

240-1622		Cable GP
--------------------------	--	----------

239-9728		Connection GP-Generator Leads
--------------------------	--	-------------------------------

217-3790		Lines GP-Air
--------------------------	--	--------------

253-3023		Fastener GP-Instrument Panel
--------------------------	--	------------------------------

245-3609		Control GP-Speed
--------------------------	--	------------------

245-3638		Cover GP-Control Panel
--------------------------	--	------------------------

236-5307		Control GP-Emcp Electronic
--------------------------	--	----------------------------

236-5314		Wiring GP-Panel
--------------------------	--	-----------------

268-1457		Panel GP-Electrical
--------------------------	--	---------------------

239-0455		Enclosure GP-Generator
--------------------------	--	------------------------

237-7192		Film GP
--------------------------	--	---------

241-3092		Seal GP-Enclosure
--------------------------	--	-------------------

241-6058		Insulation GP-Weather
--------------------------	--	-----------------------

237-7213		Cover GP-Base
--------------------------	--	---------------

236-4433		Cover GP-Instrument Panel
--------------------------	--	---------------------------

237-7177		Base GP-Engine & Generator
--------------------------	--	----------------------------

235-4480		Extension GP-Base
--------------------------	--	-------------------

235-1244		Mounting GP-Engine & Generator
--------------------------	--	--------------------------------

9Y-6496	01	Module GP-Interface
-------------------------	----	---------------------

228-3559		Sensor GP-Liquid Level
--------------------------	--	------------------------

196-2236	02	Heater GP-Jacket Water
--------------------------	----	------------------------

251-8749		Mounting GP-Jacket Wtr Heater
--------------------------	--	-------------------------------

183-2899		Harness AS-Wiring
--------------------------	--	-------------------

282-9957		Circuit Breaker GP
--------------------------	--	--------------------

239-9373		Mounting GP-Generator
--------------------------	--	-----------------------

239-9949		Heater GP-Space
--------------------------	--	-----------------

289-9728		Harness AS-Wiring
--------------------------	--	-------------------

239-3812		Duct GP-Cable
--------------------------	--	---------------

240-0484		Panel GP-Electronic
--------------------------	--	---------------------

239-7799		Connection GP-Generator Leads
--------------------------	--	-------------------------------

272-2205		Support GP-Cable
--------------------------	--	------------------

259-0983		Mounting GP-Voltage Regulator
--------------------------	--	-------------------------------

258-8562		Switch GP-Toggle
--------------------------	--	------------------

259-0243		Transformer GP-Current
--------------------------	--	------------------------

282-6288		Cover GP-Base
--------------------------	--	---------------

283-9184		Strip GP-Terminal
--------------------------	--	-------------------

6L-4502		Chart-Plate & Film
---------	--	--------------------

6V-2687		Screw-Pan Head
---------	--	----------------

9X-0203		Module GP-Relay Driver
-------------------------	--	------------------------

9Y-6496		Module GP-Interface
-------------------------	--	---------------------

9Y-6497		Board AS-Relay
---------	--	----------------

156-6198		Screw-Machine
----------	--	---------------

235-9566		Panel GP-Electronic
--------------------------	--	---------------------

236-0389		Plate
----------	--	-------

239-3812		Duct GP-Cable
--------------------------	--	---------------

I - Installed
 L - Less Indicator
 S - Shipped Loose