

**3412C Generator Set**

Machine Serial Number - 9EP01990

Machine Build Date - 2002/05/26

Engine Serial Number - 1EZ02636

Engine Build Date - 2002/05/01

**Product - Entire Group (9EP01990)**

Part Number	Serial Number	Part Name
<u>167-6894</u>		General AR
<u>184-7031</u>		Contacto GP
1000	1EZ02636	Engine
1404	AFK00349	Generator
<u>188-3857</u>		Extension GP-Fuel Tank
PP4109		Unknown Part

**Engine - Entire Group (1EZ02636)**

Part Number	Change Level	Part Name
<u>167-6894</u> I	00	General AR
<u>166-8587</u> I	03	Engine AR
<u>3N-8594</u> I	04	Cover GP-Engine Lifting Eye
<u>6N-8878</u> I	02	Gauge GP-Fuel Pressure
<u>7L-7871</u> I	08	Battery GP
<u>142-6947</u> I	04	Sensor GP-Coolant Level
<u>149-7876</u> I	03	Fastener GP-Generator Coupling
<u>149-7899</u> I	02	Sensor GP-Engine
<u>151-7794</u> I	04	Mounting GP-Engine Flexible
<u>154-5504</u> I	03	Control GP-Governor
<u>196-8775</u>	02	Switch GP-Disconnect

Part Number	Change Level	Part Name
<u>168-3241</u> I	05	Enclosure GP-Generator
<u>168-3296</u> I	03	Air Cleaner GP
<u>169-0199</u> I	09	Panel GP-Electronic
<u>169-0247</u> I	09	Box GP-Extension Terminal
<u>169-2051</u> I	08	Radiator & Fan GP
<u>169-4440</u> I	04	Harness AS-Wiring
<u>169-4442</u> I	06	Harness AS-Wiring
<u>169-4450</u> I	03	Harness AS-Wiring
<u>169-4514</u> I	03	Box GP-Junction
<u>180-3986</u> I	02	Mounting GP-Junction Box
<u>156-0043</u> I	00	Transformer GP-Current
<u>188-8215</u> I	01	Guard GP-Belt
<u>204-2515</u> I	00	Wiring GP-Generator
<u>136-6597</u> I	00	Generator AR
<u>143-9517</u> I	06	Regulator GP-Voltage
<u>166-0858</u> I	03	Fumes Disposal GP
<u>188-1007</u> I	05	Enclosure GP-Generator
<u>168-3245</u> I	01	Lines GP-Engine Oil Drain
<u>168-3252</u> I	02	Lines GP-Coolant Drain
<u>169-2069</u>	01	Lines GP-Flexible Fuel

Part Number	Change Level	Part Name
<u>170-8402</u>	02	Base GP-Engine & Generator
<u>198-8793</u>	00	Support GP-Battery
<u>188-3857</u>	01	Extension GP-Fuel Tank
<u>169-2106</u>	03	Cover GP-Access
<u>203-7164</u>	00	Connection GP-Generator Leads
<u>190-2566</u>	03	Harness AS-Wiring
<u>200-0842</u>	01	Relay GP
<u>168-3238</u>	02	Heater GP-Jacket Water
<u>171-6841</u>	03	Connection GP-Electrical
<u>184-7031</u>	02	Contact GP
<u>169-0237</u>	03	Cover GP-Generator
<u>169-4524</u>	07	Mounting GP-Circuit Breaker
<u>183-3914</u>	01	Circuit Breaker GP
<u>184-7038</u>	01	Wiring GP-Panel
<u>189-8889</u>	01	Cable GP-Generator Ground
<u>171-6831</u>	04	Relay GP
<u>171-6826</u>	03	Panel GP-Instrument
<u>150-0024</u>	00	Control GP-Engine Electronic