

G3412 Generator Set

Machine Serial Number - KAP01056

Machine Build Date - 2014/03/11

Engine Serial Number - CTP03249

Engine Build Date - 2014/02/21

Product - Entire Group (KAP01056)

Part Number	Serial Number	Part Name
<u>205-0994</u>		General AR
<u>352-9862</u>		Film GP
355-9019		Electronics GP-Generator Set
<u>419-8941</u>		Contactora GP
1000	CTP03249	Engine
1404	AER01264	Generator

Engine - Entire Group (CTP03249)

Part Number	Change Level	Part Name
<u>205-0994</u> I	00	General AR
<u>202-1316</u> I	10	Engine AR
<u>101-8639</u> I	03	Wiring GP-Alternator
<u>111-6836</u> I	09	Lines GP-Water
<u>119-6230</u> I	06	Manifold GP-Exhaust
<u>135-6298</u> I	05	Lines GP-Water
<u>135-8583</u> I	00	Pulley GP-Crankshaft
<u>139-9028</u> I	02	Damper & Pulley GP
<u>149-7876</u> I	08	Fastener GP-Generator Coupling
<u>151-7794</u> I	04	Mounting GP-Engine Flexible
<u>163-6112</u>	03	Drive GP-Governor

Part Number	Change Level	Part Name
<u>169-2120</u>	03	Fumes Disposal GP
<u>169-4450</u>	05	Harness AS-Wiring
<u>195-8030</u>	07	Wiring GP-Engine
<u>205-2906</u>	02	Drive GP-Fan
<u>205-7860</u>	10	Film GP
<u>206-5551</u>	01	Wiring GP-Generator
<u>208-0946</u>	06	Sensor GP-Liquid Level
<u>208-5385</u>	01	Mounting GP-Electronic Control
<u>208-7866</u>	06	Plate & Film GP
<u>216-6070</u>	00	Switch GP-Disconnect
<u>249-2700</u>	00	Lines GP-Engine Oil Drain
<u>262-7751</u>	01	Cover GP-Control Panel
<u>344-5865</u>	01	Ignition GP-Gas Engine
<u>344-7582</u>	00	Control GP-Timing
<u>353-3733</u>	01	Guard GP-Belt
<u>360-7200</u>	01	Bracket GP-Mounting
<u>377-5966</u>	00	Enclosure GP-Generator
<u>378-6408</u>	00	Box GP-Extension Terminal
<u>381-7219</u>	00	Panel GP-Electronic

Part Number	Change Level	Part Name
<u>393-4621</u> I	01	Wiring GP-Engine
<u>393-5726</u> I	00	Base GP-Engine & Generator
<u>393-6222</u> I	00	Lines GP-Coolant Drain
<u>393-6402</u> I	00	Lines GP-Engine Oil Drain
<u>394-8501</u> I	00	Radiator & Fan GP
<u>416-6269</u> I	00	Wiring GP-Panel
<u>2S-7227</u> I	19	Starting Motor GP-Electric
<u>2W-2949</u> I	07	Control GP-Carburetor
<u>2W-4237</u> I	02	Lines GP-Oil Supply
<u>2W-4685</u> I	10	Lines GP-Turbocharger Oil
<u>2W-7848</u> s	01	Fitting GP-Exhaust
<u>3N-7056</u> s	00	Support GP-Battery
<u>3N-8594</u> I	06	Cover GP-Engine Lifting Eye
<u>4P-3030</u> I	06	Aftercooler GP-Water
<u>4P-3449</u> I	04	Lines GP-Air
<u>4P-6023</u> I	15	Bypass GP-Exhaust
<u>4P-6715</u> I	03	Mounting GP-Air Cleaner
<u>4P-6717</u> I	01	Air Cleaner GP
<u>4P-6720</u> I	01	Carburetor GP
<u>4P-6721</u>	09	Regulator GP-Gas Pressure

Part Number	Change Level	Part Name
<u>4W-6321</u> I	04	Turbocharger GP
<u>4W-6328</u> I	09	Panel GP-Instrument
<u>5N-5692</u> I	14	Alternator GP-Charging
<u>7L-7871</u> s	09	Battery GP
<u>7W-0825</u> s	03	Cable GP-Battery
<u>9Y-1268</u> I	05	Pump GP-Auxiliary Water
<u>272-5156</u> I	00	Cover GP-Access
<u>439-5385</u> I	00	Shutoff GP-Electrical
<u>136-6617</u> I	00	Generator AR
<u>379-0343</u> I	01	Cover GP-Access
<u>203-7164</u> I	06	Connection GP-Generator Leads
<u>199-7045</u> I	02	Transformer GP-Current
<u>416-7094</u> I	00	Control GP-Governor
<u>247-4217</u> I	07	Regulator GP-Voltage
<u>170-8333</u> I	07	Mounting GP-Circuit Breaker
<u>183-2487</u> I	03	Circuit Breaker GP
<u>189-8892</u> I	02	Connection GP-Generator Leads
<u>221-8681</u> I	01	Cover GP
<u>222-2331</u> I	01	Wiring GP-Panel

Part Number	Change Level	Part Name
<u>179-9017</u> I	07	Cover GP-Generator
<u>183-2484</u> I	03	Circuit Breaker GP
<u>183-2518</u> I	05	Connection GP-Generator Leads
<u>184-7038</u> I	02	Wiring GP-Panel
<u>169-4522</u> I	05	Box GP-Extension Terminal
<u>419-8941</u> I	00	Contactor GP
AER01264		
KAP01056		
<u>2W-7848</u> s		Fitting GP-Exhaust
<u>1B-5357</u> s		Nut-Full
<u>5L-3773</u> s		Gasket-Exhaust Elbow
<u>5P-5855</u> s		BOLT-12 Point Head
<u>214-6045</u> s		Bellows AS
<u>3N-7056</u> s		Support GP-Battery
<u>3N-7054</u> s		Support AS-Battery
<u>3N-7055</u> s		Board
<u>7L-7871</u> s		Battery GP
<u>2V-7397</u> s		Cable AS
<u>8L-8413</u> s		Strap-Cable
<u>9G-0003</u> s		Cover AS-Terminal
<u>9G-0004</u>		Cover AS-Terminal

Part Number	Change Level	Part Name
9X-9720 S		Battery
<u>7W-0825</u> S		Cable GP-Battery
3V-6785 S		Cable AS
7N-5274 S		Cover AS-Terminal
8N-0869 S		Cover-Terminal
8N-1725 S		Cover AS-Terminal
9G-8909 S		Cover-Terminal
<u>6L-4502</u> S		Chart-Plate & Film
I - Installed S - Shipped Loose		