

3456 Generator Set

Machine Serial Number - CCB00941

Machine Build Date - 2004/01/22

Engine Serial Number - 7WG01641

Engine Build Date -

Product - Entire Group (CCB00941)

Part Number	Serial Number	Part Name
<u>194-4798</u>		General AR-Genset
1000	7WG01641	Engine
1404	CER00825	Generator

Engine - Entire Group (7WG01641)

Part Number	Change Level	Part Name
<u>194-4798</u> 	01	General AR-Genset
<u>3N-8594</u> 	05	Cover GP-Engine Lifting Eye
<u>7L-7871</u> 	09	Battery GP
<u>136-5937</u> 	01	Fitting GP-Exhaust
<u>245-5710</u> 	00	Support GP-Battery
<u>142-6947</u> 	04	Sensor GP-Coolant Level
<u>154-5504</u> 	03	Control GP-Governor
<u>156-0040</u> 	01	Transformer GP-Current
<u>158-0341</u> 	03	Fastener GP-Generator Coupling
<u>160-9644</u> 	03	Switch GP-Disconnect
<u>169-0256</u> 	06	Mounting GP-Bus Bar
<u>169-4450</u> 	04	Harness AS-Wiring
<u>170-8400</u> 	04	Cover GP-Control Panel
<u>235-4664</u> 	00	Engine AR-Complete
<u>196-2772</u> 	03	Fumes Disposal GP
<u>196-7332</u> 	01	Box GP-Junction
<u>197-3688</u> 	04	Air Cleaner GP
<u>198-8879</u> 	02	Cover GP-Generator
<u>198-9810</u> 	09	Box GP-Extension Terminal
<u>199-6484</u> 	02	Wiring GP-Engine
<u>218-2840</u> 	01	Guard GP-Pulley

Part Number	Change Level	Part Name
<u>220-6034</u> I	02	Radiator GP
<u>220-6036</u> I	01	Lines GP-Air
<u>205-7860</u> I	03	Film GP
<u>194-4583</u> I	00	Generator AR
<u>171-6833</u> I	06	Relay GP
<u>179-1687</u> I	04	Sensor GP-Temperature
<u>193-3247</u> I	06	Harness AS-Wiring
<u>196-7178</u> I	05	Panel GP-Electronic
<u>169-0241</u> I	05	Connection GP-Terminal Strip
<u>195-9574</u> I	03	Lines GP-Engine Oil Drain
<u>196-2947</u> I	03	Enclosure GP-Generator
<u>196-7330</u> I	00	Mounting GP-Junction Box
<u>199-1238</u> I	00	Wiring GP-Sensor
<u>217-8708</u> I	00	Lines GP-Fuel
<u>218-8546</u> I	01	Tank & Base GP-Fuel
<u>220-6029</u> I	00	Lines GP-Coolant Drain
<u>247-4217</u> I	01	Regulator GP-Voltage
<u>198-9185</u> I	01	Mounting GP-Control
<u>199-1556</u> I	05	Connection GP-Generator Leads
<u>171-6834</u> I	06	Module GP-Alarm
<u>196-2236</u> I	01	Heater GP-Jacket Water
<u>196-6907</u> I	03	Mounting GP-Jacket Wtr Heater
<u>203-5888</u> I	01	Connection GP-Electrical
<u>171-6837</u> I	06	Connection GP-Electrical
<u>197-7075</u> I	03	Pump GP-Fuel Transfer
<u>209-6697</u> I	01	Contacto GP
<u>221-1801</u> I	01	Guard GP-Exhaust
<u>222-0878</u> I	00	Cover GP-Water Lines

I - Installed