

G3412 Generator Set

Machine Serial Number - KAP00761
Machine Build Date - 2009/08/22

Engine Serial Number - CTP02954
Engine Build Date - 2009/08/05

Product - Entire Group (KAP00761)

Part Number	Serial Number	Part Name
<u>205-0996</u>		General AR
314-2358		Conversion Gp.
219-4205		Kit-Gas Valve
1000	CTP02954	Engine
1404	AFE01351	Generator

Engine - Entire Group (CTP02954)

Part Number	Change Level	Part Name
<u>205-0995</u> I, L	F	General AR
<u>202-2009</u> I, L	F	Engine AR
<u>2N-8220</u> I	05	Breather GP
<u>229-8406</u> I	01	Lines GP-Air
<u>228-9834</u> I	02	Lines GP-Coolant Drain
<u>205-2905</u> I	01	Drive GP-Fan
<u>237-3971</u> I	00	Carburetor GP
<u>2S-7227</u> I	18	Starting Motor GP-Electri
<u>2W-4237</u> I	03	Lines GP-Oil Supply
<u>2W-4685</u> I	10	Lines GP-Turbocharger C
<u>3N-8594</u> I	06	Cover GP-Engine Lifting I
<u>4P-6715</u> I	03	Mounting GP-Air Cleaner
<u>4P-6717</u> I	01	Air Cleaner GP
<u>4P-6721</u> I	06	Regulator GP-Gas Press
<u>9Y-1268</u> I	04	Pump GP-Auxiliary Water
<u>107-7215</u> I	03	Aftercooler GP-Water
<u>109-5175</u> I	01	Control GP-Carburetor
<u>113-0909</u> I	09	Bypass GP-Exhaust
<u>119-6230</u> I	05	Manifold GP-Exhaust
<u>124-8591</u> I	04	Lines GP-Water

Part Number	Change Level	Part Name
<u>135-6298</u> I	04	Lines GP-Water
<u>135-8583</u> I	00	Pulley GP-Crankshaft
<u>139-9028</u> I	02	Damper & Pulley GP
<u>149-7876</u> I	07	Fastener GP-Generator C
<u>168-3241</u> I	09	Enclosure GP-Generator
<u>169-0247</u> I	14	Box GP-Extension Termir
<u>169-4450</u> I	05	Harness AS-Wiring
<u>170-8400</u> I	05	Cover GP-Control Panel
<u>194-0906</u> I	00	Wiring GP-Engine
<u>195-8022</u> I	02	Harness AS-Wiring
<u>195-8025</u> I	03	Harness AS-Wiring
<u>195-8030</u> I	03	Wiring GP-Engine
<u>195-8033</u> I	02	Fastener GP-Wiring Harn
<u>196-8775</u> I	04	Switch GP-Disconnect
<u>201-4237</u> I	01	Turbocharger GP
<u>204-2515</u> I	02	Wiring GP-Generator
<u>205-7784</u> I	05	Radiator & Fan GP
<u>207-8040</u> I	04	Base GP-Engine & Gene
<u>7L-7871</u> I	09	Battery GP
<u>208-0946</u> I	05	Sensor GP-Liquid Level
<u>2W-7848</u> s	01	Fitting GP-Exhaust
<u>209-3660</u> I	04	Control GP-Governor
<u>4W-6328</u> I	09	Panel GP-Instrument
<u>224-5129</u> I	00	Timer GP
<u>169-2120</u> I	03	Fumes Disposal GP
<u>108-1655</u> I	09	Sensor & Mounting GP
<u>107-7897</u> I	04	Drive GP-Governor
<u>216-4023</u> I	02	Ignition GP-Gas Engine
<u>5N-5692</u>	14	Alternator GP-Charging

Part Number	Change Level	Part Name
<u>205-7860</u>	10	Film GP
<u>198-8793</u>	00	Support GP-Battery
<u>168-3245</u>	01	Lines GP-Engine Oil Drai
<u>101-8639</u>	01	Wiring GP-Alternator
<u>249-2700</u>	00	Lines GP-Engine Oil Drai
<u>111-6836</u>	08	Lines GP-Water
<u>206-5551</u>	01	Wiring GP-Generator
<u>146-1859</u>	03	Shutoff GP-Electrical
<u>238-2689</u>	00	Mounting GP-Bracket
<u>212-6298</u>	00	Sensor GP-Speed
<u>210-9076</u>	05	Guard GP-Belt
<u>208-7866</u>	04	Plate & Film GP
<u>136-6634</u>	00	Generator AR
<u>143-9518</u>	11	Regulator GP-Voltage
<u>153-3434</u>	04	Mounting GP-Engine Fle
<u>171-6833</u>	07	Relay GP
<u>204-6801</u>	03	Panel GP-Electronic
<u>193-3247</u>	07	Harness AS-Wiring
<u>169-2106</u>	04	Cover GP-Access
<u>203-7164</u>	04	Connection GP-Generato
<u>171-6826</u>	08	Panel GP-Instrument
<u>171-6842</u>	03	Connection GP-Electrical
<u>170-8333</u>	07	Mounting GP-Circuit Bre
<u>183-2487</u>	02	Circuit Breaker GP
<u>189-8892</u>	02	Connection GP-Generato
<u>221-8681</u>	00	Cover GP
<u>222-2331</u>	01	Wiring GP-Panel
<u>184-7029</u>	05	Mounting GP-Battery Ch

Part Number	Change Level	Part Name
<u>218-4368</u> I	01	Connection GP-Electrical
<u>118-4304</u> I	01	Battery Charger
<u>184-7031</u> I	04	Contactor GP
<u>205-0996</u> I	00	General AR
<u>202-2011</u> I	09	Engine AR
<u>199-7045</u> I	02	Transformer GP-Current
AFE01351		
KAP00761		
1B-5357 S		Nut-Full
<u>2W-7848</u> S		Fitting GP-Exhaust
5L-3773 S		Gasket-Exhaust Elbow
5P-5855 S		BOLT-12 Point Head
<u>6L-4502</u> S		Chart-Plate & Film
7E-1569 S		Washer
214-6045 S		Bellows AS
I - Installed L - Less Indicator S - Shipped Loose		