

3512 Gen Set Engine

Engine Serial Number - 24Z09730

Engine Build Date - 2000/06/13

Engine - Entire Group (24Z09730)

| Part Number | Change Level | Part Name |
|---------------------|--------------|----------------------------|
| <u>7C-5185</u> | 17 | Engine AR |
| <u>4P-7610</u> | 03 | Sensor GP-Speed |
| <u>7C-0526</u> | 01 | Starting Motor GP-Electri |
| <u>7C-1665</u> | 07 | Drive GP-Fan |
| <u>7C-2459</u> | 02 | Guard GP-Belt |
| <u>7C-7827</u> | 04 | Mounting GP-Radiator |
| <u>7C-7831</u> | 06 | Lines GP-Water |
| <u>7C-8124</u> | 04 | Housing & Regulator GP |
| <u>7E-7528</u> | 04 | Radiator GP |
| <u>7N-6782</u> | 08 | Indicator GP-Air Filter Ch |
| <u>7W-5224</u> | 00 | Pulley GP-Fan Drive |
| <u>7W-5639</u> | 02 | Fan GP-Blower |
| <u>7W-6669</u> | 01 | Guard GP-Damper |
| <u>8N-7182</u> | 08 | Damper GP |
| <u>8N-9302</u> | 08 | Air Cleaner GP |
| <u>8N-9639</u> | 04 | Guard GP-Damper |
| <u>104-4704</u> | 03 | Mounting GP-Control Par |
| <u>104-9728</u> | 02 | Mounting GP-Contactor |
| <u>105-7183</u> | 02 | Fastener GP-Wiring Harn |
| <u>115-7033</u> | 00 | Rail GP-Engine & Gen St |
| <u>120-4520</u> | 04 | Harness AS-Wiring |
| <u>121-8855</u> | 06 | Connection GP-Electrical |
| <u>134-3241</u> | 01 | Sensor GP-Temp & Press |
| <u>136-0991</u> | 05 | Panel GP-Control |
| <u>138-1973</u> | 02 | Governor GP-Electronic |
| <u>121-9480</u> | 02 | Connection GP-Terminal |

| Part Number | Change Level | Part Name |
|----------------------|--------------|--------------------------|
| <u>121-4712</u> I | 01 | Panel GP-Electronic |
| <u>131-1962</u> I | 01 | Panel GP-Instrument |
| <u>121-6202</u> I | 06 | Regulator GP-Voltage |
| <u>145-5138</u> I | 00 | Wiring GP-Electronic Cor |
| <u>105-2049</u> I | 02 | Sensor & Mtg GP-Radiatr |
| <u>2W-7756</u> I | 04 | Flange GP-Exhaust |
| <u>141-7048</u> I | 01 | Muffler |
| <u>9Y-6095</u> I | 06 | Pump GP-Fuel Priming |
| <u>8N-6435</u> I | 02 | Filter GP-Primary Fuel |
| <u>5N-2438</u> I | 05 | Lines GP-Flexible Fuel |
| <u>7E-6634</u> I | 04 | Cooler GP-Fuel |
| <u>9Y-5563</u> I | 00 | Fumes Disposal GP |
| <u>4W-0472</u> I | 04 | Fumes Disposal GP |
| <u>7E-6247</u> I | 03 | Heater GP-Jacket Water |
| <u>6I-1041</u> I | 04 | Mounting GP-Jacket Wtr |
| <u>6I-1042</u> I | 06 | Mounting GP-Jacket Wtr |
| <u>3E-0264</u> I | 02 | Switch GP-Temperature |
| <u>7L-7872</u> I | 08 | Battery GP |
| <u>7C-3874</u> I | 02 | Battery Charger |
| <u>158-6170</u> I | 03 | Conversion AR |
| 0S-1588 s | | Bolt |
| 1B-5357 s | | Nut-Full |
| 1L-3769 s | | Ring-Retaining |
| 1W-0531 s | | Base-Primary Fuel Filter |
| 2H-3429 s | | Ring-Retaining |
| 2J-0157 s | | Seal-O-Ring |
| 2N-8928 s | | Clip |
| 2V-7397 s | | Cable AS |

| Part Number | Change Level | Part Name |
|----------------------|--------------|---------------------|
| 2W-7755 s | | Flange-Exhaust |
| 3E-3361 s | | Plug AS-Connector |
| 3E-3362 s | | Wedge-Plug Lock |
| <u>3N-6504</u> s | | Hose AS |
| 5F-5990 s | | Clip |
| 5M-2894 s | | Washer-Hard |
| 5P-0597 s | | Clamp-Hose |
| 5P-1472 s | | Hose |
| 5P-8245 s | | Washer-Hard |
| <u>7C-3874</u> s | | Battery Charger |
| 7H-9678 s | | Retainer-Element |
| 7N-1628 s | | Nut |
| 7S-9323 s | | Spring |
| 8H-2778 s | | Seal-Ring |
| 8H-7202 s | | Case AS-Fuel Filter |
| 8L-8413 s | | Strap-Cable |
| 8N-1186 s | | Hose AS |
| 8T-8730 s | | Socket-Connector |
| 9G-0003 s | | Cover AS-Terminal |
| 9G-0004 s | | Cover AS-Terminal |
| 9M-2342 s | | Filter Element-Fuel |
| 9S-8752 s | | Nut-Full |
| 9X-8873 s | | Bolt |
| <u>9X-9730</u> s | | Battery GP |
| 111-5822 s | | Gasket-Exhaust |
| <u>131-1962</u> s | | Panel GP-Instrument |
| <u>141-7048</u> s | | Muffler |
| <u>171-6719</u> s | | Kit-Parts |
| <u>171-6721</u> | | Kit-Parts |

Part Number
s

Change Level

Part Name

I - Installed

S - Shipped Loose
