

**3516 Gen Set Engine**

Engine Serial Number - 4XF

Engine Build Date - 1994/09/27

**Engine - Entire Group (4XF )**

Part Number	Change Level	Part Name
<u>7C-8116</u> I	20	Engine AR
<u>4P-0554</u> I	01	Mounting GP-Air Cleaner
<u>4P-0558</u> I	00	Air Cleaner GP
<u>4P-7610</u> I	01	Sensor GP-Speed
<u>7C-0527</u> I	02	Starting Motor GP-Electric
<u>7C-1664</u> I	04	Drive GP-Fan
<u>7C-2459</u> I	01	Guard GP-Belt
<u>7N-6782</u> I	06	Indicator GP-Air Filter Change
<u>7W-5224</u> I	00	Pulley GP-Fan Drive
<u>7W-5639</u> I	01	Fan GP-Blower
<u>7W-6669</u> I	01	Guard GP-Damper
<u>8N-9639</u> I	04	Guard GP-Damper
<u>9Y-6676</u> I	03	Radiator GP
<u>103-6101</u> I	01	Control GP-Engine Monitoring
<u>104-6203</u> I	02	Installation AR-Generator
<u>104-9728</u> I	01	Mounting GP-Contactor
<u>105-7184</u> I	02	Fastener GP-Wiring Harness
<u>104-5950</u> I	03	Rail GP-Engine Support
<u>9Y-7822</u> I	01	Flange GP-Radiator
<u>105-2048</u> I	01	Sensor & Mtg GP-Radiator
<u>9Y-6496</u> I	02	Module GP-Interface
<u>6I-1043</u> I	00	Mounting GP-Jacket Wtr Heater
<u>6I-1044</u> I	02	Mounting GP-Jacket Wtr Heater
<u>7E-6248</u> I	02	Heater GP-Jacket Water
<u>7L-7872</u> I	06	Battery GP
<u>7E-6681</u>	03	Cooler GP-Fuel

Part Number	Change Level	Part Name
<u>107-0169</u>	00	Pump GP-Fuel Priming
<b>I - Installed</b>		