

**C15 Generator Set**

Machine Serial Number - C5E00448  
 Machine Build Date - 2006/10/27

Engine Serial Number - FSE00544  
 Engine Build Date - 2006/09/19

**Product - Entire Group (C5E00448)**

Part Number	Serial Number	Part Name
<u>273-2987</u>		General AR
<u>268-0889</u>		Base GP-Engine & Gene
<u>268-3155</u>		Mounting GP-Jacket Wtr
0V-2329		Production Correction
5N-9635		Convenience Num
289-8328		Mounting GP-Jacket Wtr
<u>287-4962</u>		Lines GP-Fuel
1000	FSE00544	Engine
1404	G6B03508	Generator

**Engine - Entire Group (FSE00544)**

Part Number	Change Level	Part Name
<u>268-3155</u> 	F	Mounting GP-Jacket Wtr
<u>273-2987</u> 	00	General AR
<u>272-9743</u> 	05	Engine AR-Complete
<u>260-4784</u> 		Radiator GP
<u>218-4698</u> 		Fan GP-Blower
<u>264-0255</u> 		Lines GP-Coolant Drain
<u>272-0225</u> 		Lines GP-Fuel
<u>233-9351</u> 		Coupling GP-Generator
<u>270-3125</u> 		Battery GP
<u>144-7184</u> 	02	Cover GP-Engine Lifting
<u>251-1413</u> 		Fastener GP-Panel
<u>264-0256</u> 		Drain GP-Oil
<u>263-5120</u> 		Fumes Disposal GP
<u>261-8429</u> 		Potentiometer AS
<u>261-5613</u> 		Harness AS-Power
<u>258-6791</u> 		Panel GP-Electronic
<u>258-6790</u> 		Mounting GP-Bus Bar
<u>258-6782</u> 		Door GP

Part Number	Change Level	Part Name
<u>258-6776</u> 		Mounting GP-Divider Plat
<u>258-6773</u> 		Mounting GP-Bracket
<u>240-0170</u> 		Box GP-Connection
<u>266-7116</u> 		Harness AS-Engine
<u>240-1622</u> 		Cable GP
<u>262-9635</u> 		Mounting GP-Wiring
<u>266-2701</u> 		Cover GP-Control Panel
<u>268-8667</u> 		Plug GP-Box
<u>205-7860</u> 	08	Film GP
<u>253-3023</u> 		Fastener GP-Instrument I
<u>239-0410</u> 		Transformer GP-Current
<u>240-1621</u> 		Wiring GP-Generator
<u>258-6763</u> 		Enclosure AS
<u>277-3571</u> 		Seal GP-Enclosure
<u>235-1209</u> 		Generator AR
<u>239-6758</u> 		Mounting GP-Control Par
<u>266-1425</u> 		Mounting GP-Control Par
<u>261-5132</u> 		Control GP-Generator Se
<u>239-3812</u> 		Duct GP-Cable
<u>239-7792</u> 		Connection GP-Generato
<u>272-2205</u> 		Support GP-Cable
<u>242-8292</u> 		Base GP-Fuel Tank
<u>287-4961</u> 		Lines GP-Fuel
<u>270-0171</u> 		Support GP-Battery
<u>263-9346</u> 		Mounting GP-Engine & G
<u>279-7015</u> 		Cover GP-Base
<u>261-5828</u> 		Relay GP
<u>261-6623</u> 		Panel GP-Electrical

Part Number	Change Level	Part Name
<u>261-8479</u> I		Wiring GP-Generator
<u>258-6778</u> I		Panel GP-Electronic
<u>258-6795</u> I		Mounting GP-Terminal St
<u>246-3101</u> I		Harness AS-Wiring
<u>275-5521</u> I		Connector AS
<u>264-7113</u> I		Air Cleaner GP
<u>275-2202</u> I		Enclosure GP-Generator
<u>235-3326</u> S		Muffler GP
<u>275-8628</u> I		Film GP
<u>261-7645</u> I		Cover GP-Control Panel
<u>241-3092</u> I		Seal GP-Enclosure
<u>241-6058</u> I		Insulation GP-Weather
<u>266-1422</u> I		Cover GP-Control Panel
<u>282-6303</u> I		Insulation GP-Generator
<u>240-6068</u> I		Cover GP-Generator
<u>286-2426</u> I	01	Film GP
<u>282-6302</u> I		Grommet
<u>196-2236</u> I	02	Heater GP-Jacket Water
<u>282-9958</u> I		Circuit Breaker GP
<u>183-2899</u> I		Harness AS-Wiring
<u>242-2094</u> I		Switch AS-Liquid Level
<u>247-2701</u> I		Mounting GP-Electronic C
<u>292-5967</u> I		Panel GP-Electrical
<u>243-3542</u> I		Circuit Breaker GP
<u>258-6812</u> I		Cover GP-Enclosure
<u>239-9808</u> I		Connection GP-Generato
<u>243-5599</u> I		Cover GP-Access
<u>260-0568</u> I		Bracket GP-Mounting

Part Number	Change Level	Part Name
<u>284-9190</u> I		Terminal GP-Circuit Brea
<u>295-2373</u> I		Connection GP-Terminal
<u>243-4797</u> I		Shunt-Trip
<u>261-7137</u> I		Contacto GP
<u>263-9343</u> I		Sensor GP-Coolant Leve
<u>268-2649</u> I		Mounting GP-Battery Cha
<u>193-3260</u> I	04	Harness AS-Wiring
<u>287-4962</u> I		Lines GP-Fuel
<u>268-0889</u> I, L		Base GP-Engine & Gene
C5E00448		
G6B03508		
5H-8331 s		Gasket
<u>6L-4502</u> s		Chart-Plate & Film
6V-5686 s		Bolt
7X-2553 s		Bolt
8T-1757 s		Nut
8T-4194 s		Bolt
8T-4223 s		Washer-Hard
8T-4244 s		Nut
9X-8257 s		Washer
9X-8268 s		Washer
113-9848 s		Gasket
<u>160-9631</u> s		Muffler GP
220-5619 s		Clamp-Exhaust
227-3019 s		Tube
235-3320 s		Tube AS
235-3322 s		Bracket AS
235-3323 s		Strap-Muffler
235-3324 s		Pipe AS
<u>235-3326</u>		Muffler GP

Part Number s	Change Level	Part Name
235-3330 s		Tube AS

---

**I - Installed**  
**S - Shipped Loose**  
**L - Less Indicator**

---