

G3516 Gas Engine

Engine Serial Number - 4EK00911

Engine Build Date - 1996/05/02

Engine - Entire Group (4EK00911)

| Part Number | Change Level | Part Name |
|---------------------|--------------|----------------------------|
| <u>4P-8336</u> | 07 | Engine AR |
| <u>6I-0670</u> | 02 | Lines GP-Air |
| <u>7W-1678</u> | 01 | Indicator GP-Air Filter Ch |
| <u>8N-9639</u> | 04 | Guard GP-Damper |
| <u>9Y-0673</u> | 00 | Air Cleaner GP |
| <u>107-9020</u> | 02 | Meter GP-Service |
| <u>107-9022</u> | 02 | Pyrometer GP |
| <u>107-9023</u> | 01 | Gauge AS-Pressure |
| <u>107-9024</u> | 01 | Gauge GP-Coolant Temp |
| <u>107-9025</u> | 01 | Gauge GP-Manifold Pres |
| <u>107-9026</u> | 01 | Gauge AS-Pressure |
| <u>9Y-6496</u> | 02 | Module GP-Interface |
| <u>108-3921</u> | 01 | Gauge GP-Air Inlet Temp |
| <u>118-0474</u> | 02 | Harness AS-Panel |
| <u>7W-8708</u> | 00 | Installation AR-Generator |
| <u>112-5018</u> | 00 | Rail GP-Engine Support |
| <u>4P-6546</u> | 01 | Control AS-Governor |
| <u>103-6193</u> | 05 | Panel GP-Control |
| <u>9Y-8179</u> | 02 | Connection GP-Water |
| <u>2W-5616</u> | 03 | Cover GP-Oil Pan |
| <u>113-4174</u> | 02 | Pump GP-Prelubrication |
| <u>113-4239</u> | 03 | Lines GP-Prelubrication |
| <u>8N-3896</u> | 13 | Starting Motor GP-Electri |
| <u>4W-4755</u> | 02 | Switch GP-Magnetic |
| <u>6I-1043</u> | 01 | Mounting GP-Jacket Wtr |

| Part Number | Change Level | Part Name |
|----------------------|--------------|-------------------------|
| <u>7E-6248</u> I | 05 | Heater GP-Jacket Water |
| <u>109-7034</u> I | 00 | Control GP-Jacket Water |
| I - Installed | | |