

G3516 Gas Engine

Engine Serial Number - 4EK02470

Engine Build Date - 1999/04/20

Engine - Entire Group (4EK02470)

Part Number	Change Level	Part Name
<u>4P-8336</u> 	08	Engine AR
<u>6I-0670</u> 	02	Lines GP-Air
<u>7W-1678</u> 	01	Indicator GP-Air Filter Ch
<u>8N-9639</u> 	04	Guard GP-Damper
<u>9Y-0673</u> 	00	Air Cleaner GP
<u>107-9020</u> 	02	Meter GP-Service
<u>107-9022</u> 	03	Pyrometer GP
<u>107-9023</u> 	01	Gauge AS-Pressure
<u>107-9024</u> 	01	Gauge GP-Coolant Temp
<u>107-9025</u> 	01	Gauge GP-Manifold Pres
<u>107-9026</u> 	01	Gauge AS-Pressure
<u>9Y-6496</u> 	02	Module GP-Interface
<u>108-3921</u> 	02	Gauge GP-Air Inlet Temp
<u>118-0474</u> 	04	Harness AS-Panel
<u>2W-5616</u> 	04	Cover GP-Oil Pan
<u>7W-8708</u> 	00	Installation AR-Generator
<u>112-5018</u> 	00	Rail GP-Engine Support
<u>9Y-8179</u> 	02	Connection GP-Water
<u>110-6206</u> 	00	Drain GP-Engine Oil
<u>113-4174</u> 	02	Pump GP-Prelubrication
<u>113-4239</u> 	04	Lines GP-Prelubrication
<u>8N-3896</u> 	13	Starting Motor GP-Electri
<u>4W-4755</u> 	02	Switch GP-Magnetic
<u>6I-1043</u> 	03	Mounting GP-Jacket Wtr
<u>7E-6248</u> 	05	Heater GP-Jacket Water

Part Number	Change Level	Part Name
<u>109-7034</u> I	01	Control GP-Jacket Water
<u>131-5567</u> I	01	Control AS-Governor
<u>103-6193</u> I	07	Panel GP-Control
<u>131-5457</u> I	01	Control AS-Governor
<u>7W-9828</u> I	00	Adapter GP-Air Cleaner
2B-2695 S		Bolt
5N-7830 S		Gasket
<u>6L-7004</u> S		Potentiometer
6V-2687 S		Screw-Pan Head
7E-8266 S		Holder AS-Fuse
7W-9829 S		Adapter AS
9M-1974 S		Washer-Hard
<u>9X-0203</u> S		Module GP-Relay Driver
9Y-6027 S		Fuse-Ceramic
9Y-6497 S		Board AS-Relay
031-4155 S		Locknut
<u>103-6193</u> S		Panel GP-Control
<u>118-0474</u> S		Harness AS-Panel
<u>131-5457</u> S		Control AS-Governor
<u>131-5567</u> S		Control AS-Governor
I - Installed		
S - Shipped Loose		