

3512B MARINE ENGINE

Engine Serial Number - 2EZXXXXX (Build Date - 02/2000, Test Date - 03/2000, Ship Date - 03/2000)

ENGINE - ENTIRE GROUP (2EZXXXXX)

Qty.	NPR	Note	Part No.	ChangeReq. Level	Qty	Part Name
		I	LA3232	01	001	3512B-DITA-SCAC MAR PROP ENG
	<u>NPR</u>	IY	<u>173-6960</u>	01	001	ENGINE AR
	<u>NPR</u>	IY	<u>4P-0558</u>	00	001	AIR CLEANER GP
		I	5N-9635		001	CONVENIENCE NUM
		I	5P-2506	00	001	LITERATURE GP
	<u>NPR</u>	IY	<u>8N-5743</u>	09	001	DRIVE GP-ACCESSORY
	<u>NPR</u>	IY	<u>8N-9639</u>	04	001	GUARD GP-DAMPER
	<u>NPR</u>	IY	<u>8N-9698</u>	05	001	RAIL GP-ENGINE SUPPORT
	<u>NPR</u>	IY	<u>9X-9647</u>	01	001	SENSOR GP-POSITION
	<u>NPR</u>	IY	<u>115-3634</u>	00	001	FILTER-SOOT
	<u>NPR</u>	IY	<u>116-6894</u>	06	001	CONVERSION AR-CRANK ROTATION
	<u>NPR</u>	IY	<u>162-7687</u>	01	001	MOUNTING GP-AIR CLEANER
	<u>NPR</u>	IY	<u>7N-4885</u>	10	001	SWITCH GP-COOLANT LEVEL
	<u>NPR</u>	IY	<u>7N-6965</u>	09	001	CONNECTION GP-WATER
		I	LA0330	02	001	SEA WATER PUMP REMOVAL
	<u>NPR</u>	IY	<u>5N-2438</u>	05	001	LINES GP-FLEXIBLE FUEL
	<u>NPR</u>	IY	<u>102-8627</u>	01	001	MODULE GP-SYSTEM COMMUNICATION
		I	LA0170	03	001	PILOT HOUSE INSTRUMENT PANEL
	<u>NPR</u>	IY	<u>123-8210</u>	02	001	PANEL GP-PILOT HOUSE INSTR
		I	LA1021	06	001	MARINE GEAR SENSORS
	<u>NPR</u>	IY	<u>130-5173</u>	00	001	SENSOR GP-PRESSURE
	<u>NPR</u>	IY	<u>130-5174</u>	00	001	SENSOR GP-TEMPERATURE
	<u>NPR</u>	IY	<u>9Y-4888</u>	02	001	CONNECTION GP-OIL
	<u>NPR</u>	IY	<u>133-9300</u>	01	001	CONTROL GP-ENGINE ELECTRONIC
	<u>NPR</u>	IY	<u>8N-8510</u>	07	001	VALVE GP-EXPLOSION RELIEF
		I	LA2253	00	001	JACKET WATER HEATER - DUAL
	<u>NPR</u>	IY	<u>7E-6247</u>	03	001	HEATER GP-JACKET WATER
	<u>NPR</u>	IY	<u>124-0059</u>	04	001	MOUNTING GP-JACKET WTR HEATER
	<u>NPR</u>	IY	<u>150-4220</u>	01	001	MOUNTING GP-JACKET WTR HEATER

**PART NUMBERS**

	I	LA3360	00	001	ENGINE MOUNT PREMIUM PANEL LH
	<u>NPR</u>	I 136-1695	03	001	LINES GP-FUEL
	<u>NPR</u>	I 148-7955	02	001	WIRING GP-ENGINE
	<u>NPR</u>	I 148-7956	00	001	WIRING GP-BOX
	I	LA3449	02	001	PREMIUM WIRING HARNESS
	<u>NPR</u>	IY <u>120-4501</u>	05	001	FILTER GP-ENGINE OIL
	<u>NPR</u>	IY <u>121-0470</u>	03	001	FILTER GP-FUEL
	<u>NPR</u>	IY <u>131-9094</u>	02	001	TRAY GP-CABLE
	<u>NPR</u>	I 133-6463	00	001	BOX & MOUNTING GP
	<u>NPR</u>	IY <u>134-6288</u>	03	001	BOX & MOUNTING GP
	<u>NPR</u>	IY <u>134-6299</u>	01	001	MOUNTING GP-INSTRUMENT PANEL
	<u>NPR</u>	I 134-6300	02	001	BOX GP-INSTRUMENT PANEL
	<u>NPR</u>	I 139-8529	04	001	HARNESS AS-PANEL
	<u>NPR</u>	I 153-7205	02	001	COVER GP-CYLINDER BLOCK
	<u>NPR</u>	IY <u>153-7208</u>	01	001	FILLER GP-ENGINE OIL
	<u>NPR</u>	IY <u>143-1897</u>	01	001	TRAY GP-CABLE
	I	LA2070	03	001	ELECTRIC STARTING MOTOR LH 24V
	<u>NPR</u>	IY <u>8N-3898</u>	10	001	STARTING MOTOR GP-ELECTRIC
	<u>NPR</u>	IY <u>131-9138</u>	03	001	CONNECTION GP-ELECTRICAL
	<u>NPR</u>	IY <u>150-4197</u>	01	001	WIRING GP-ELECTRIC STARTING
	I	LA2115	01	001	PYROMETER AND THERMOCOUPLES
	<u>NPR</u>	IY <u>120-4504</u>	02	001	PYROMETER GP
	I	158-6225	01	001	WIRING GP-PYROMETER
	<u>NPR</u>	IY <u>120-4498</u>	01	001	THERMOCOUPLE GP
	<u>NPR</u>	IY <u>115-1062</u>	02	001	PUMP GP-FUEL PRIMING
	<u>NPR</u>	IY <u>184-2445</u>	00	001	DRIVE GP-ACCESSORY
	<u>NPR</u>	ILY <u>8N-5767</u>	05	001	DRIVE GP-ACCESSORY
	I	0P-9715		001	EXTRA LITERATURE - ENGLISH
	I	0P-9894		001	FORWARDING/INSURANCE CHARGES
	I	0V-1056		001	PRICE PROTECTION PSD 31DEC99
	I	0P-1914		001	DOMESTIC PACK FOR EXPORT
	I	LL5200	00	001	1675 BHP WOF @ 1600 RPM
	I	0K-2103	00	001	1249 KW @ 1600 RPM (1675 BHP)
					<b>SHIPPED LOOSE</b>
	<u>NPR</u>	S 0L-1351		002	BOLT
	<u>NPR</u>	S 0S-1591		008	BOLT

	NPR	S	1A-2029	013	BOLT
	NPR	S	3N-6504	001	HOSE AS
	NPR	SY	<u>4P-0558</u>	002	AIR CLEANER GP
	NPR	S	5F-5990	002	CLIP
	NPR	S	5M-2894	015	WASHER-HARD
	NPR	S	5P-0537	012	WASHER-HARD
	NPR	S	5P-3860	002	CLAMP-HOSE
	NPR	S	5P-4869	002	CLAMP-HOSE
	NPR	S	6V-8225	012	NUT
	NPR	S	8N-1186	001	HOSE AS
	NPR	S	8N-5254	002	HOSE-REDUCER
	NPR	S	8T-3991	012	SCREW-BUTTON HEAD
	NPR	SY	<u>9X-9647</u>	001	SENSOR GP-POSITION
	NPR	SY	<u>115-3634</u>	002	FILTER-SOOT
	NPR	SY	<u>123-8210</u>	001	PANEL GP-PILOT HOUSE INSTR
	NPR	SY	<u>130-5173</u>	001	SENSOR GP-PRESSURE
	NPR	SY	<u>130-5174</u>	001	SENSOR GP-TEMPERATURE
	NPR	SY	<u>133-9300</u>	001	CONTROL GP-ENGINE ELECTRONIC
	NPR	S	162-7689	001	SUPPORT AS
	NPR	SR	<u>164-8940</u>	001	MODULE GP-SYSTEM COMMUNICATION
		S	JERD2157	001	SOFT
		S	LEXM0051	002	IMO TECH DOC
		S	SEBP2987	002	PTSBK
		S	SEBU6251	002	LUBE
		S	SEBU6874	001	OMM
		S	SEBU6984	002	SUPP
		S	SEBU7253	002	OMM
		S	SELF5255	002	WARRANTY 140013C1(A)
		S	SENR6588	001	SMGP
		S	ESO	001	(PRNT ESO COPY)
		S	PML	001	*REQUIRED DECALS

Key:

I Installed

Y Separate Illustration

L Less Indicator

S Shipped Loose

R REMFG PART MAY BE AVAILABLE