

3508 INDUSTRIAL ENGINE

Engine Serial Number - 68Z Prefix (Build Date - 12/2006, Test Date - 12/2006, Ship Date - unknown)

▼ ENGINE - ENTIRE GROUP (68Z Prefix)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	508DI04	F	001	3508 DITA JW INDUSTRIAL ENGINE
		I	CLCNTC0	F	001	TORQUE CONV COOLING CONNECTION
		I	GOVMRH0	F	001	3161 MECHANICAL GOVERNOR-RH
		I	GOVCN05	F	001	GOV CONTROL REMOTE AND POS LCK
		I	HMCHSO1	F	001	HYDRA-MECHANICAL SHUTOFF
		I	REMNSO0	F	001	REMOTE NORMAL SHUTOFF
		I	ALCAIN0	F	001	ALARM CONTACTOR GP
		I	OPGAGE0	F	001	OIL PRESSURE MONITOR
		I	EXRVAL2	F	001	EXPLOSION RELIEF VALVE
		I	ACLHD16	F	001	AIR CLEANER - HEAVY DUTY
		I	RAILS03	F	001	RAILS
		I	FPPRH01	F	001	FUEL PRIMING PMP RH MOUNTED
		S	FLN0001	F	001	FLEXIBLE FUEL LINES
		S	PFF0001	F	001	PRIMARY FUEL FILTER
		I	OPADRN4	F	001	OIL PAN DRAIN VALVE
		S	FUMDIS2	F	001	FUMES DISPOSAL
		I	ASMRH10	F	001	AIR STARTING MOTOR RH 11
		I	MASCRH0	F	001	MANUAL AIR START CONTROL RH
		S	APRRH01	F	001	AIR PRESSURE REGULATOR RH
		I	AIRSI01	F	001	AIR START SILENCER
		S	EXCFF12	F	001	FLEXIBLE FITTING
		S	EXCEL02	F	001	ELBOW, 203 MM (8 IN) 02
		S	EXCFL05	F	001	FLANGE-203MM (8 IN) (1-5)
		I	WHARRM2	F	001	WIRING HARNESS REMOVAL
		I	DMGDRM1	F	001	DAMPER GUARD REMOVAL 02
		S	RAD4615	F	001	RADIATOR 46/CV, 0.520
		I	EXPTTAG	F	001	EXPORT TAG
		I	1200RPM	F	001	1200 RPM

	I	INDUSTA	F	001	INDUSTRIAL CONTINUOUS A RATING	
	I	INDUSTR	F	001	INDUSTRIAL ENGINE	
	I	TRSENG1	F	001	STD ENGINE TEST CHARGE 3L0436	
	S	LITENGE	F	002	EXTRA ENGLISH LITERATURE	
	S	LITPAPR	F	002	PAPER PARTS BOOK-IN ENGLISH	
	I	MSCIK16	F	001	OTHER CONSTRUCTION	
	I	MWCODEB	F	001	PUMP	
	I	MSINDOE	F	001	INDUSTRIAL	
	I	SET5018	F	001	680 BHP (507 BKW) W/O FAN	
	I	DPX0002	F	001	DOMESTIC PACK FOR EXPORT	
	I	HP00680	F	001	680 BHP (507 BKW) W/O FAN	
	I	NOTCERT	F	001	NON CERTIFIED ENGINE	
	I	0V-2329	F	001	PRODUCTION CORRECTION	
	I	PA1812	F	001	DAMPER GUARD REMOVAL	
	NPR	N	262-6877	F	001	MUFFLER
					PART NUMBERS	
		I	PA0926	17	001	3508 DITA INDUSTRIAL ENGINE
	NPR	IY	4W-0281		001	ENGINE AR
	NPR	IY	5N-7770	07	001	CONNECTION GP-TORQUE CONV CLR
	NPR	IY	8N-6712	17	001	GOVERNOR GP
		I	PL4156	00	001	CONTROL AR-GOV(REMOTE&POS.LOCK
		I	PA3716	01	001	SHUTOFF AR-FULL SYS.HYDRA-MECH
	NPR	IY	4W-1703	02	001	VALVE GP-DIVERTER
	NPR	IY	8N-8542	02	001	CONTACTOR GP
	NPR	IY	2W-8810	02	001	GAUGE GP-ENGINE OIL PRESSURE
	NPR	IY	5N-4830	16	001	VALVE GP-EXPLOSION RELIEF
		I	PL3724	06	001	CLEANER GP - AIR (HEAVY DUT
		I	PA1966	10	001	RAILS
	NPR	IY	7W-9465	08	001	PUMP GP-FUEL PRIMING
	NPR	SY	5N-2438	05	001	LINES GP-FLEXIBLE FUEL
	NPR	SY	8N-6435	02	001	FILTER GP-PRIMARY FUEL
	NPR	IY	9Y-7876	03	001	DRAIN GP-ENGINE OIL
		I	LA0182	06	001	FUMES DISPOSAL
		I	PL3243	07	001	AIR STARTING MOTOR RH
		I	LA2832	00	001	MANUAL AIR START CONTROL - RH
	NPR	NY	8N-8483	05	001	VALVE GP-AIR CONTROL

	I	LA0256	06	001	AIR START SILENCER
NPR	SY	5N-2457	06	001	FITTING GP-EXHAUST
NPR	SY	5L-7520	04	001	ELBOW-EXHAUST
NPR	SY	7N-6961	05	001	FLANGE GP-EXHAUST
NPR	IY	7W-5028	03	001	CONVERSION GP-WIRING
	I	PA1812	04	001	DAMPER GUARD REMOVAL
	S	LA1011	04	001	RADIATOR 46/CV, 0.520
	I	PA7685	02	001	EXPORT TAG
	I	0P-1852		001	STD ENGINE TEST CHARGE 3L0436
	S	0P-9715		002	EXTRA LITERATURE-G.S. M/AUX
	S	0V-1672		002	ENGLISH PAPER PARTS LIST
	I	0V-1085		001	END USE: INDUSTRIAL
	I	PP0615	00	001	680 BHP WOF 1200 RPM CONT.
	I	0P-1914		001	DOMESTIC PACK FOR EXPORT
	I	0V-2329		001	PRODUCTION CORRECTION
	I	PA1812	04	001	DAMPER GUARD REMOVAL
NPR	N	262-6877	00	001	MUFFLER SHIPPED LOOSE
	S	ESO		001	(PRNT ESO COPY)
	S	PML		001	*REQUIRED DECALS
NPR	S	0S-1571		008	BOLT
NPR	S	0S-1588		001	BOLT
NPR	S	0S-1590		008	BOLT
NPR	S	0S-1591		008	BOLT
	S	0V-1672		001	ENGLISH PAPER PARTS LIST
NPR	S	1F-7958		001	NUT-FULL
NPR	S	1H-7666		002	GASKET
NPR	S	1K-4649		001	SPACER
NPR	SY	1L-2073		001	VALVE GP-PRESSURE REDUCING
NPR	S	1L-3769		001	RING-RETAINING
NPR	S	1S-5772		002	GASKET
NPR	S	1W-0531		001	BASE-PRIMARY FUEL FILTER
NPR	S	2H-3429		001	RING-RETAINING
NPR	S	2J-0157		001	SEAL-O-RING
NPR	S	2N-8928		008	CLIP
NPR	S	3B-6552		002	ELBOW-PIPE

	NPR	S	3B-7749	001	NIPPLE-PIPE
	NPR	S	3L-8993	001	FITTING
	NPR	SY	3N-2451	004	JOINT AS-TUBE
	NPR	S	3N-6504	001	HOSE AS
	NPR	S	3V-3308	008	WASHER-HARD
	NPR	S	4K-0367	002	NUT-FULL
	NPR	S	4L-6454	024	BOLT
	NPR	S	4P-3117	001	VALVE-BALL
	NPR	SY	4W-6341	001	MOUNTING GP-AIR CLEANER
	NPR	S	5B-7666	001	ELBOW
	NPR	S	5F-5990	002	CLIP
	NPR	S	5L-3233	002	FITTING-CONNECTOR
	NPR	S	5L-3773	001	GASKET-EXHAUST ELBOW
	NPR	SY	5L-7520	001	ELBOW-EXHAUST
	NPR	S	5M-2894	001	WASHER-HARD
	NPR	SY	5N-2438	001	LINES GP-FLEXIBLE FUEL
	NPR	SY	5N-2457	001	FITTING GP-EXHAUST
	NPR	SY	5N-7770	001	CONNECTION GP-TORQUE CONV CLR
	NPR	S	5N-7772	001	ORIFICE AS
	NPR	SY	5N-7822	002	AIR CLEANER GP
	NPR	S	5N-7830	002	GASKET
	NPR	S	5N-7905	002	HOSE
	NPR	S	5N-7906	001	SUPPORT AS
	NPR	S	5N-7915	002	ANGLE
	NPR	S	5N-7917	004	SPACER
	NPR	S	5N-7918	002	PLATE
	NPR	SY	5N-8603	002	PRECLEANER GP
	NPR	S	5N-8606	002	GASKET
	NPR	SY	5N-8728	001	AIR CLEANER GP
	NPR	S	5N-8729	012	SPACER
	NPR	S	5N-8730	002	ADAPTER AS
	NPR	S	5P-0597	002	CLAMP-HOSE
	NPR	S	5P-1075	020	WASHER-HARD
	NPR	S	5P-1472	580	HOSE
	NPR	S	5P-4869	004	CLAMP-HOSE
	NPR	S	5P-8245	001	WASHER-HARD

	NPR	S	5S-7379	006	BOLT
	NPR	S	6F-5985	001	HOSE AS
	NPR	S	6I-2933	002	INDICATOR-AIR FILTER SERVICE
		SY	6L-4502	001	CHART-PLATE & FILM
	NPR	S	6V-3835	001	SEAL-O-RING
	NPR	S	6V-6866	002	PLUG
	NPR	S	6V-8182	014	NUT
	NPR	S	6V-8188	001	NUT
	NPR	S	6V-8801	008	NUT
	NPR	S	7C-3879	002	BAR
	NPR	S	7C-3892	002	BRACKET
	NPR	S	7E-9762	001	BRACKET AS
	NPR	S	7H-9678	001	RETAINER-ELEMENT
	NPR	S	7N-1628	001	NUT
	NPR	S	7N-3674	001	BLOCK
	NPR	SY	7N-6782	001	INDICATOR GP-AIR FILTER CHANGE
	NPR	S	7N-6955	001	FLANGE
	NPR	SY	7N-6961	001	FLANGE GP-EXHAUST
	NPR	S	7S-9323	001	SPRING
	NPR	S	7W-1506	001	ELBOW
	NPR	SY	7W-5639	001	FAN GP-BLOWER
	NPR	SY	7W-9269	001	LINES GP-AIR STARTING
	NPR	S	7X-0344	002	BOLT
	NPR	S	7X-0354	006	BOLT
	NPR	S	7X-0355	005	BOLT
	NPR	S	7X-0448	002	NUT
	NPR	S	8C-7323	002	BOLT
	NPR	S	8H-2778	001	SEAL-RING
	NPR	S	8H-7202	001	CASE AS-FUEL FILTER
	NPR	S	8L-5008	002	ELBOW-PIPE
	NPR	S	8N-1186	001	HOSE AS
	NPR	S	8N-1663	002	BOOT
	NPR	SY	8N-6435	001	FILTER GP-PRIMARY FUEL
	NPR	SY	8N-8483	001	VALVE GP-AIR CONTROL
	NPR	S	8T-2502	006	BOLT
	NPR	S	8T-4122	028	WASHER-HARD

	NPR	S	8T-4223	002	WASHER-HARD
	NPR	S	8T-4224	096	WASHER-HARD
	NPR	S	8T-4835	006	BOLT
	NPR	S	8T-4896	084	WASHER-HARD
	NPR	S	8T-4994	032	WASHER-HARD
	NPR	S	8T-8915	004	BOLT
	NPR	S	8T-8919	001	BOLT
	NPR	S	8T-9001	001	JOINT AS-TUBE
	NPR	S	8T-9043	048	BOLT
	NPR	S	9B-7237	008	BOLT
	NPR	S	9M-2342	001	FILTER ELEMENT-FUEL
	NPR	S	9S-1366	001	BOLT
	NPR	S	9S-8752	008	NUT-FULL
	NPR	S	9Y-2942	001	BRACKET
	NPR	SY	9Y-5563	001	FUMES DISPOSAL GP
	NPR	SRY	9Y-6675	001	RADIATOR GP
	NPR	SY	9Y-6676	001	RADIATOR GP
	NPR	S	9Y-7645	002	GUARD AS-FAN
	NPR	S	031-4155	048	LOCKNUT
	NPR	S	115-1783	001	SPIDER AS-FAN
	NPR	S	201-2184	008	BOLT
	NPR	S	201-8898	001	BOLT
	NPR	S	214-6045	001	BELLOWS AS
	NPR	S	251-5715	010	BOLT
	NPR	S	262-6877	001	MUFFLER
		S	SEBP2964	002	PTSBK
		S	SEBU6251	003	LUBE 1632-16 (A)
		S	SEBU6701	003	OMM
		S	SEBU6984	003	SUPP 140013B1(A)
		S	SELF5397	001	WARRANTY
		S	SERP2964	003	PTSCD

Key:

I Installed

S Shipped Loose

N Not Installed

Y Separate Illustration

R REMFG PART MAY BE AVAILABLE