

3512B MARINE AUXILIARY

Engine Serial Number – FFG Prefix (Build Date - 02/2005, Test Date - 02/2005, Ship Date - unknown)

📁 ENGINE - ENTIRE GROUP (FFG Prefix)

Qty.	NPR	Note	Part No.	ChangeLevel	Req. Qty	Part Name
		I	219-5980	00	001	INSTRUCTIONS
	<u>NPR</u>	IY	<u>224-7128</u>	16	001	GENERAL AR
	<u>NPR</u>	IY	<u>224-7127</u>	04	001	ENGINE AR
	<u>NPR</u>	IY	<u>7E-4836</u>	09	001	MOUNTING GP-ALTERNATOR
	<u>NPR</u>	IY	<u>7W-5780</u>	04	001	GUARD GP-BELT
	<u>NPR</u>	IY	<u>8N-8510</u>	19	001	VALVE GP-EXPLOSION RELIEF
	<u>NPR</u>	IY	<u>107-7361</u>	03	001	DRIVE GP-ACCESSORY
	<u>NPR</u>	IY	<u>115-1062</u>	03	001	PUMP GP-FUEL PRIMING
	<u>NPR</u>	IY	<u>120-4498</u>	03	001	THERMOCOUPLE GP
	<u>NPR</u>	IY	<u>121-0470</u>	11	001	FILTER GP-FUEL
	<u>NPR</u>	IY	<u>132-3802</u>	04	001	WIRING GP-ENGINE
	<u>NPR</u>	IY	<u>161-0797</u>	03	001	CONTROL AS-GOVERNOR
	<u>NPR</u>	IY	<u>163-1462</u>	00	001	SENSOR & MTG GP-ELECTRIC
	<u>NPR</u>	IY	<u>165-3804</u>	03	001	STARTING MOTOR GP-AIR
	<u>NPR</u>	IY	<u>165-3980</u>	01	001	MOUNTING GP-AIR COMPRESSOR
	<u>NPR</u>	IY	<u>166-7256</u>	04	001	LINES GP-ENGINE OIL
	<u>NPR</u>	IY	<u>166-7363</u>	05	001	MOUNTING GP-INSTRUMENT PANEL
	<u>NPR</u>	IY	<u>167-0872</u>	03	001	CONNECTION GP-PRELUBRICATION
	<u>NPR</u>	IY	<u>207-5043</u>	00	001	MOUNTING GP-ENGINE
	<u>NPR</u>	IY	<u>207-5103</u>	04	001	BOX GP-INSTRUMENT PANEL
	<u>NPR</u>	IY	<u>207-7023</u>	05	001	LINES GP-FUEL
	<u>NPR</u>	IY	<u>225-2587</u>	02	001	AIR CLEANER GP
	<u>NPR</u>	IY	<u>225-3355</u>	02	001	HEATER GP-JACKET WATER
	<u>NPR</u>	IY	<u>225-3523</u>	01	001	FILTER GP-FUMES DISPOSAL
	<u>NPR</u>	IY	<u>7E-2858</u>	04	001	ALTERNATOR GP-CHARGING
	<u>NPR</u>	IY	<u>193-1009</u>	01	001	TANK GP-EXPANSION
	<u>NPR</u>	IY	<u>225-3524</u>	00	001	COUPLING GP-GENERATOR
	<u>NPR</u>	IY	<u>225-7841</u>	03	001	INSTALLATION AR
		I	226-0359	00	001	INSTRUCTIONS
	<u>NPR</u>	IY	<u>217-2715</u>	01	001	WIRING GP-ENGINE

PART NUMBERS

	NPR	IY	<u>165-7297</u>	03	001	BARRING & MOUNTING GP
	NPR	IY	<u>208-1609</u>	02	001	LINES GP-AIR STARTING
	NPR	IY	<u>208-1642</u>	02	001	MOUNTING GP-CONTROL PANEL
	NPR	IY	<u>224-6973</u>	06	001	PANEL GP-CONTROL
		I	0K-3682	00	001	SETTING
	NPR	IY	<u>227-5421</u>	02	001	CONTACTOR GP-OIL LEVEL
	NPR	IY	<u>102-8627</u>	01	001	MODULE GP-SYSTEM COMMUNICATION
	NPR	IY	<u>227-4710</u>	01	001	FILTER GP-ENGINE OIL
	NPR	IY	<u>229-5744</u>	00	001	CONTROL GP-POWER
	NPR	IY	<u>126-9191</u>	05	001	GROUND GP-ELECTRICAL
	NPR	IY	<u>245-9768</u>	01	001	LINES GP-WATER
		I	225-9205	02	001	REF DIMENSIONS-GEN
		I	5P-2506	00	001	LITERATURE GP
	NPR	IY	<u>233-6280</u>	00	001	GUARD GP-FLYWHEEL
	NPR	IY	<u>234-0190</u>	00	001	BOX GP-JUNCTION
		I	235-3956	01	001	WITNESS TEST
	NPR	IY	<u>235-5231</u>	00	001	WIRING GP-ALTERNATOR
	NPR	IY	<u>209-3620</u>	02	001	ADAPTER GP-CRANKSHAFT
	NPR	IY	<u>194-4173</u>	02	001	SENSOR GP-TEMPERATURE
	NPR	IY	<u>194-4176</u>	03	001	SENSOR & MTG GP-PRESSURE
	NPR	IY	<u>197-5666</u>	04	001	CONTACTOR GP-OIL PRESSURE
	NPR	IY	<u>198-0319</u>	04	001	SENSOR & MTG GP-PRESSURE
	NPR	IY	<u>234-0564</u>	04	001	CONTROL GP-JACKET WATER HEATER
	NPR	IY	<u>7W-3355</u>	05	001	SENSOR GP-SPEED
	NPR	IY	<u>134-6315</u>	02	001	WIRING GP-PANEL
		I	5N-9949		001	CONVENIENCE NUMB
		I	8Q-9795	00	001	PACKAGING AR
	NPR	I	218-5112	00	001	WIRING GP
	NPR	IY	<u>253-9277</u>	00	001	CONVERSION GP-WIRING
		I	245-8400	00	001	CHART - DTO
		I	0V-2319		001	NEW UPS 150KVA 50HZ 400V 4WIRE
		I	0V-1050		001	END USE: MARINE AUX COMMERCIAL
		I	0V-8707		001	DTO QUOTE DESIGN FEE
						SHIPPED LOOSE
		S			001	
	SY		<u>6L-4502</u>		001	CHART-PLATE & FILM

	<u>NPR</u>	SY	<u>102-8627</u>	001	MODULE GP-SYSTEM COMMUNICATION
	<u>NPR</u>	SY	<u>161-0797</u>	001	CONTROL AS-GOVERNOR
	<u>NPR</u>	SY	<u>165-3804</u>	001	STARTING MOTOR GP-AIR
	<u>NPR</u>	SY	<u>193-1009</u>	001	TANK GP-EXPANSION
	<u>NPR</u>	SY	<u>207-5043</u>	004	MOUNTING GP-ENGINE
	<u>NPR</u>	SY	<u>209-3620</u>	012	ADAPTER GP-CRANKSHAFT
	<u>NPR</u>	SY	<u>225-3524</u>	012	COUPLING GP-GENERATOR
	<u>NPR</u>	SY	<u>225-7841</u>	012	INSTALLATION AR
	<u>NPR</u>	SY	<u>229-5744</u>	001	CONTROL GP-POWER
	<u>NPR</u>	SY	<u>233-6280</u>	010	GUARD GP-FLYWHEEL

Key:

I Installed

Y Separate Illustration

S Shipped Loose