

C11 INDUSTRIAL ENGINE
 Engine Serial Prefix - GLS (Build Date - 07/2007, Test Date - 07/2007)

▼ ENGINE - ENTIRE GROUP (GLS)

Qty.	NPR	Note	Part No.	ChangeReq. Level	Qty	Part Name
						FEATURE CODES
		I	C11DI02	F	001	C11 ACERT ATAAC IND ENGINE 02
		S	CGTPS04	F	001	REMOTE SPEED CONT-HAND KNOB
		I	FLYHG08	F	001	FLY. HSG SAE NO. 1 CAST IRN 08
		I	ENGSUP1	F	001	REAR ENGINE SUPPORT
		I	ENGSUP4	F	001	FRONT ENGINE SUPPORT
		I	FANADS3	F	001	SUCTION FAN ADAPTER
		I	FANPL18	F	001	FAN PULLEY 0.800:1 RATIO
		I	FNH0482	F	001	FAN HEIGHT-482.6 MM (19.00 IN)
		I	ALT2412	F	001	CHARGING ALT 24V 60 AMP
		I	ALTPL00	F	001	ALT PULLEY 3.69 DIA 2 GROOVE
		I	ALMT01	F	001	ALTERNATOR MOUNTING
		I	ALTGD00	F	001	ALTERNATOR GUARD
		I	FNDRMT0	F	001	FAN DRIVE MOUNTING
		I	FLY0002	F	001	FLYWHEEL
		S	PPFWS04	F	001	PRIMARY FUEL FILTER/WATER SEP
		I	ACL9001	F	001	AIR CLEANER
		S	FLN0001	F	001	FLEXIBLE FUEL LINES
		I	ELSM LH1	F	001	LH ELEC STRT MTR 24V 42MT
		I	LUBOIL1	F	001	LUBRICATING OIL
		S	EXCEL01	F	001	ELBOW - TURBO OUTLET 90 DEG
		S	MES0001	F	001	MESSENGER DISPLAY
		S	GIPCNT0	F	001	CONTROL 24V
		I	2100RPM	F	001	2100 RPM
		I	EXHFRNT	F	001	FRONT FACING EXHAUST
		I	INDUSTC	F	001	INDUST INTERMITTENT C RATING
		I	INDUSTR	F	001	APPLICATION
		I	VLT0024	F	001	24 VOLT
		I	PBKHCD1	F	001	**OLD**PARTS BOOK-PAPER & ELEC
		I	MSCIK38	F	001	PUMPS (NON-FIRE/IRR/PTR)

	I	MWCODEB	F	001	PUMP	
	I	HP00385	F	001	385 BHP (287 BKW) W/O FAN	
	I	MSINDOE	F	001	INDUSTRIAL	
	I	CERTIF5	F	001	EPA/CARB TIER3 & EC STAGE IIIA	
					PART NUMBERS	
	I	PQ0079	09	001	ENGINE AR - C11 DIT-ATAAC IND	
	<u>NPR</u>	IY 236-4572	07	001	ENGINE AR-CORE	
	S	5P-2506	00	001	LITERATURE GP	
	<u>NPR</u>	IY 116-1091	04	001	SEAL GP-CRANKSHAFT	
	<u>NPR</u>	IY 116-5436	00	001	FILTER GP-FUEL	
	<u>NPR</u>	IY 117-0165	02	001	PLUG GP-CYLINDER BLOCK	
	<u>NPR</u>	IY 117-2766	07	001	DAMPER GP	
	<u>NPR</u>	IY 117-2786	01	001	COVER GP-OIL FILTER BASE	
	<u>NPR</u>	IY 138-2550	01	001	MOUNTING GP-FAN DRIVE	
	<u>NPR</u>	IY 138-2579	00	001	PULLEY GP-CRANKSHAFT	
	<u>NPR</u>	IY 180-5168	00	001	FASTENER GP-DAMPER & PULLEY	
	<u>NPR</u>	I	189-9183	00	001	COVER GP-STORAGE
	<u>NPR</u>	IY 215-9005	06	001	PAN GP-OIL	
	<u>NPR</u>	IY 219-7462	08	001	WIRING GP-ELECTRONIC CONTROL	
	<u>NPR</u>	IY 222-3092	09	001	MANIFOLD GP-INLET	
	<u>NPR</u>	IY 224-0880	02	001	LIFTING GP-ENGINE	
	<u>NPR</u>	IY 224-7662	03	001	PLUG GP-ENGINE OIL COOLER	
	<u>NPR</u>	IY 227-2574	04	001	COVER GP-FRONT HOUSING	
	<u>NPR</u>	IY 227-5518	01	001	PLUG GP-AIR INLET MANIFOLD	
	<u>NPR</u>	IY 227-9545	02	001	PLUG GP-CYLINDER BLOCK	
	<u>NPR</u>	IY 229-8437	05	001	CONTROL & MTG GP-ENGINE ELEK	
	<u>NPR</u>	IY 230-4523	09	001	COOLER GP-ENGINE OIL	
	<u>NPR</u>	IY 231-1975	05	001	SENSOR GP-ENGINE	
	<u>NPR</u>	IY 238-6725	03	001	LINES GP-WATER	
	<u>NPR</u>	IY 237-9753	00	001	PLUG GP-ENGINE	
	<u>NPR</u>	IY 244-8677	02	001	FILLER GP-ENGINE OIL	
	<u>NPR</u>	SY 240-6054	02	001	CONNECTION GP-ELECTRICAL	
	<u>NPR</u>	IY 255-0658	02	001	LINES GP-FUEL FILTER	
	I	255-0996	00	001	INSTRUCTIONS	
	<u>NPR</u>	IY 255-9253	00	001	FITTING GP-FUEL LINES	
	<u>NPR</u>	IY 255-9254	01	001	FITTING GP-FUEL LINES	

	NPR	IY	<u>236-5900</u>	03	001	LINES GP-WATER
	NPR	IY	<u>241-0983</u>	03	001	LINES GP-AIR
	NPR	IY	<u>258-4484</u>	01	001	FUMES DISPOSAL GP
	NPR	IY	<u>229-2614</u>	06	001	COVER GP-VALVE MECHANISM
	NPR	IY	<u>240-4815</u>	01	001	LINES GP-TURBOCHARGER OIL
	NPR	IY	<u>262-4166</u>	01	001	PLUG GP-ENGINE
	NPR	IY	<u>231-3492</u>	03	001	FILTER GP-ENGINE OIL
	NPR	IY	<u>247-9665</u>	01	001	BASE GP-OIL FILTER
	NPR	IY	<u>267-3476</u>	02	001	MANIFOLD GP-EXHAUST
	NPR	IY	<u>275-1294</u>	01	001	TURBOCHARGER GP
	NPR	IY	<u>282-6837</u>	00	001	GAUGE GP-OIL LEVEL (DIPSTICK)
	NPR	IY	<u>272-6657</u>	01	001	FITTING GP-FUEL LINES
	NPR	SY	<u>134-0670</u>	01	001	CONTROL GP-ENGINE SPEED
		I	PQ0099	02	001	FLY. HSG SAE NO. 1 CAST IRN 08
	NPR	IY	<u>9Y-9238</u>	04	001	COVER GP-SHIPPING
	NPR	IY	<u>264-4643</u>	01	001	HOUSING GP-FLYWHEEL
	NPR	IY	<u>127-5728</u>	00	001	COVER GP-FLYWHEEL HOUSING
	NPR	IY	<u>129-4865</u>	00	001	SUPPORT GP-ENGINE
		I	PA7631	01	001	FRONT ENGINE SUPPORT
	NPR	IY	<u>188-2872</u>	00	001	SUPPORT GP-ENGINE
	NPR	IY	<u>131-7701</u>	01	001	ADAPTER GP-FAN
		I	PA6959	05	001	FAN PULLEY 0.800:1 RATIO
	NPR	IY	<u>128-3415</u>	03	001	DRIVE GP-FAN
	NPR	IY	<u>131-9141</u>	01	001	PULLEY GP-FAN DRIVE
		I	265-3872	00	001	INSTRUCTIONS
	NPR	IY	<u>4N-3986</u>	15	001	ALTERNATOR GP-CHARGING
	NPR	ICLY	<u>2W-8494</u>	01	001	PULLEY-ALTERNATOR
	NPR	IY	<u>243-3019</u>	01	001	MOUNTING GP-ALTERNATOR
	NPR	IY	<u>269-8598</u>	00	001	GUARD GP-ALTERNATOR
	NPR	IY	<u>243-3023</u>	02	001	MOUNTING GP-FAN DRIVE
		I	PQ0508	01	001	FLYWHEEL
	NPR	IY	<u>117-2774</u>	01	001	FLYWHEEL GP
	NPR	IY	<u>117-2794</u>	04	001	FASTENER GP-FLYWHEEL
		SY	<u>212-9431</u>	00	001	FILTER GP-WATER SEP & FUEL
	NPR	IY	<u>243-3032</u>	02	001	AIR CLEANER GP
	NPR	SY	<u>125-0032</u>	01	001	LINES GP-FLEXIBLE FUEL

	I	PQ0540	00	001	LH ELEC STRT MTR 24V 42MT
	<u>NPR</u>	IY <u>102-5836</u>	04	001	STARTING MOTOR GP-ELECTRIC
	I	PQ0529	00	001	FACTORY OIL FILL GP
	<u>NPR</u>	I 212-4532	04	001	PLATE & FILM GP
	<u>NPR</u>	SY <u>155-8536</u>	01	001	ELBOW GP-EXHAUST
	<u>NPR</u>	SY <u>243-3820</u>	06	001	MODULE GP-DISPLAY
	I	PA7677	05	001	CONTROL 24V
	<u>NPR</u>	SY <u>195-0131</u>	00	001	WIRING GP-ENGINE
	<u>NPR</u>	SY <u>195-1345</u>	00	001	CONTROL GP-AUTO START/STOP
	I	0V-1766		001	**OLD**PARTS BOOK-PAPER & ELEC
	I	PP5388	01	001	385 BHP WOF 2100 RPM 'C'
	I	0K-5789	00	001	SETTING
	I	0V-1085		001	END USE: INDUSTRIAL
					SHIPPED LOOSE
	<u>NPR</u>	S 1P-7625		001	ELBOW
	<u>NPR</u>	S 2R-6806		001	CONNECTOR-O-RING
	<u>NPR</u>	S 3J-1907		001	SEAL-O-RING
	<u>NPR</u>	S 3K-0360		001	SEAL-O-RING
	<u>NPR</u>	S 4W-9160		001	CLAMP-V BAND
	<u>NPR</u>	S 5N-4437		001	BOOT
	<u>NPR</u>	S 5P-9074		001	WIRE-ELECTRICAL
	<u>NPR</u>	S 6K-9194		001	ELBOW-FLARED
	<u>NPR</u>	S 7C-2644		001	CLIP
	<u>NPR</u>	S 8C-3334		002	RIVET-TUBULAR
	<u>NPR</u>	S 8C-6354		001	CAP-RECEPTACLE
	<u>NPR</u>	S 8T-8732		001	RECEPTACLE-CONNECTOR
	<u>NPR</u>	S 8T-8736		001	RECEPTACLE-CONNECTOR
	<u>NPR</u>	S 8T-8737		068	PLUG-SEAL
	<u>NPR</u>	S 9M-6522		001	CONNECTOR
	<u>NPR</u>	S 9W-0844		003	SOCKET-CONNECTOR
	<u>NPR</u>	S 9W-0852		002	PIN-CONNECTOR
	<u>NPR</u>	S 9Y-7332		001	HOSE AS
	S	LEBM3227		001	MESSENGER GUIDE 140021D3(A)
	S	SEBP4127		001	PTSBK 14002C2 (A)
	S	SEBU6251		001	LUBE 140019B2(A)
	S	SEBU7901		001	OMM 14004D3 (A)

	S	SELF5391	001	WARRANTY 140022F3(A)
	S	SERP4127	001	PTSCD 1400 (A)
	S	SMBU6981	001	SUPP
	<u>NPR</u>	S 118-2136	001	FILM-INFORMATION
	<u>NPR</u>	S 124-5268	001	HOSE AS
	<u>NPR</u>	S 133-0967	001	PIN-CONNECTOR
	<u>NPR</u>	S 133-0969	001	CONNECTOR-SOCKET
	<u>NPR</u>	SY <u>134-0670</u>	001	CONTROL GP-ENGINE SPEED
	<u>NPR</u>	S 151-6320	002	TOOL-WIRE REMOVAL
	<u>NPR</u>	S 155-8538	001	ELBOW-EXHAUST
	<u>NPR</u>	S 160-7689	001	PLUG AS-CONNECTOR
	<u>NPR</u>	S 180-9339	007	PIN-CONNECTOR
	<u>NPR</u>	S 180-9340	069	SOCKET-CONNECTOR
	<u>NPR</u>	SY <u>195-0131</u>	001	WIRING GP-ENGINE
	<u>NPR</u>	SY <u>195-1345</u>	001	CONTROL GP-AUTO START/STOP
		SY <u>212-9431</u>	001	FILTER GP-WATER SEP & FUEL
	<u>NPR</u>	SY <u>243-3820</u>	001	MODULE GP-DISPLAY

Key:

I Installed

S Shipped Loose

Y Separate Illustration

CL CLASSIC PART AVAILABLE