

C15 INDUSTRIAL ENGINE

Engine Serial Prefix - JAS (Build Date - 12/2005, Test Date - 12/2005, Ship Date - unknown)

▼ ENGINE - ENTIRE GROUP (JAS)

Qty.	NPR	Note	Part No.	Change Level	Req. Qty	Part Name
		I	PA9194	04	001	ENGINE AR - C15 DIT-ATAAC IND
	<u>NPR</u>	IY	<u>254-3836</u>	03	001	ENGINE AR-CORE
		I	0K-6001		001	307 BKW (412 BHP) @ 2100 RPM
	<u>NPR</u>	IY	<u>107-6736</u>	01	001	COVER GP-CYLINDER BLOCK
	<u>NPR</u>	IY	<u>107-6737</u>	01	001	COVER GP-CYLINDER BLOCK
	<u>NPR</u>	IY	<u>108-2312</u>	02	001	FITTING GP-QUICK DISCONNECT
	<u>NPR</u>	IY	<u>109-1657</u>	01	001	FASTENER GP-VALVE MECHANISM
	<u>NPR</u>	IY	<u>111-2088</u>	01	001	LIFTING GP-ENGINE
	<u>NPR</u>	IY	<u>112-2418</u>	00	001	LIFTING GP-ENGINE
	<u>NPR</u>	IY	<u>116-5434</u>	00	001	FITTING GP-FUEL LINES
	<u>NPR</u>	IY	<u>126-0081</u>	02	001	LINES GP-AIR
	<u>NPR</u>	IY	<u>126-7631</u>	02	001	CONNECTION GP-ELECTRICAL
	<u>NPR</u>	IY	<u>135-6552</u>	02	001	MANIFOLD GP-EXHAUST
	<u>NPR</u>	IY	<u>139-9095</u>	04	001	PUMP GP-FUEL TRANSFER
	<u>NPR</u>	IY	<u>141-8953</u>	00	001	FASTENER GP-FUEL LINES
	<u>NPR</u>	IY	<u>154-6189</u>	04	001	FLYWHEEL GP
	<u>NPR</u>	IY	<u>159-6159</u>	05	001	COVER GP-FRONT HOUSING
	<u>NPR</u>	IY	<u>159-9107</u>	05	001	CONNECTION GP-ELECTRICAL
	<u>NPR</u>	IY	<u>176-7007</u>	04	001	FASTENER GP-OIL PAN
	<u>NPR</u>	IY	<u>187-3316</u>	00	001	COVER GP-VALVE MECHANISM
	<u>NPR</u>	IY	<u>191-0583</u>	00	001	MANIFOLD GP-FUEL
	<u>NPR</u>	IY	<u>191-5054</u>	02	001	PUMP GP-FUEL PRM & SEC FILTER
	<u>NPR</u>	IY	<u>193-2261</u>	02	001	DAMPER & PULLEY GP
	<u>NPR</u>	IY	<u>193-7413</u>	04	001	SUPPORT GP-ENGINE
	<u>NPR</u>	IY	<u>194-3967</u>	02	001	MOUNTING GP-SENSOR
	<u>NPR</u>	IY	<u>196-2111</u>	02	001	PAN GP-OIL
	<u>NPR</u>	I	196-3193	01	001	PLATE & FILM GP
	<u>NPR</u>	IY	<u>204-5024</u>	00	001	FASTENER GP-FRONT HOUSING
	<u>NPR</u>	IY	<u>205-1230</u>	02	001	HOUSING GP-FLYWHEEL
	<u>NPR</u>	IY	<u>205-1231</u>	00	001	ELBOW GP-AIR INLET

PART NUMBERS

	NPR	I	209-5354	00	001	COVER GP-SHIPPING
	NPR	IY	<u>212-8218</u>	03	001	FUMES DISPOSAL GP
	NPR	IY	<u>217-4518</u>	02	001	GUIDE GP-OIL LEVEL GAUGE
	NPR	IY	<u>224-1229</u>	05	001	HOUSING GP-FRONT
	NPR	IY	<u>224-3978</u>	02	001	PLATE GP-ENGINE IDENTIFICATION
	NPR	IY	<u>226-2313</u>	01	001	FILLER GP-ENGINE OIL
	NPR	IY	<u>227-9495</u>	01	001	SUPPORT GP-ENGINE
	NPR	IY	<u>227-9864</u>	01	001	FASTENER GP-FRONT COVER
	NPR	IY	<u>229-5519</u>	05	001	COVER GP-CYLINDER BLOCK
	NPR	IY	<u>229-9965</u>	00	001	FASTENER GP-FRONT HOUSING
	NPR	IY	<u>229-9966</u>	00	001	FASTENER GP-FRONT HOUSING
	NPR	IY	<u>234-9184</u>	00	001	PLUG GP-CYLINDER HEAD
	NPR	IY	<u>234-9706</u>	01	001	PLUG GP-CYLINDER BLOCK
	NPR	IY	<u>234-9776</u>	01	001	PLUG GP-ENGINE
	NPR	IY	<u>237-4299</u>	04	001	LINES GP-FUEL FILTER
	NPR	IY	<u>240-6047</u>	00	001	FITTING GP-FUEL LINES
	NPR	IY	<u>240-6053</u>	04	001	LINES GP-TURBOCHARGER OIL
	NPR	IY	<u>247-4886</u>	01	001	WIRING GP-ENGINE
	NPR	IY	<u>109-2373</u>	01	001	FASTENER GP-WATER PUMP
	NPR	IY	<u>140-9746</u>	00	001	COVER GP-CYLINDER BLOCK
	NPR	IY	<u>172-7120</u>	01	001	FASTENER GP-ENGINE
	NPR	IY	<u>200-2852</u>	00	001	FASTENER GP-WATER LINES
	NPR	IY	<u>247-8211</u>	00	001	PLUG GP-CYLINDER BLOCK
	NPR	IY	<u>252-5557</u>	02	001	MOUNTING GP-BELT TENSIONER
	NPR	IY	<u>255-9245</u>	02	001	LINES GP-WATER
	NPR	IY	<u>255-9250</u>	00	001	PLUG GP-WATER LINES
	NPR	IY	<u>255-9251</u>	00	001	PLUG GP-WATER LINES
	NPR	IY	<u>255-9252</u>	00	001	PLUG GP-WATER LINES
	NPR	IY	<u>255-9248</u>	00	001	FASTENER GP-WATER PUMP
	NPR	IY	<u>170-1282</u>	01	001	FILTER GP-ENGINE OIL
	NPR	IY	<u>224-0754</u>	00	001	FASTENER GP-OIL COOLER
	NPR	IY	<u>243-1560</u>	01	001	CONTROL & MTG GP-ENGINE ELEK
	NPR	IY	<u>272-2664</u>	00	001	STARTING MOTOR GP-ELECTRIC
		I	0V-1085		001	END USE: INDUSTRIAL