

3508B MARINE ENGINE | Engine Serial Prefix - S2E

▼ ENGINE - ENTIRE GROUP (S2E)

Qty.	NPR	Note	Part No.	Change Level	Req. Qty	Part Name
						FEATURE CODES
		I	508DM41	F	001	3508B DITA SCAC MARINE PROP
		I	SRVLHS1	F	001	LEFT HAND SERVICE SIDE
		I	PNLSTD1	F	001	INSTRUMENT PANEL-STANDARD
		I	PNLENG1	F	001	INSTRUMENT PANEL-ENG MTD
		I	SHLDSP1	F	001	SPRAY SHIELDING
		I	WTLVLS4	F	001	WATER LEVEL SWITCH GAUGE
		I	SWPMP07	F	001	SEA WATER PUMP DUAL IMPELLER 7
		S	PHIP010	F	001	MPD PILOT HOUSE PANEL
		S	MGSEN01	F	001	MARINE GEAR SENSORS 01
		I	ALT2476	F	001	CHARGING ALT 24V 60 AMP 76
		I	OPTDS01	F	001	DEEP SUMP OIL PAN-FLAT SUMP
		I	OPADR4	F	001	OIL PAN DRAIN VALVE
		I	SPMPLH9	F	001	SUMP PUMP LH 09
		I	FPPRH05	F	001	FUEL PRIMING PMP RH MOUNTED
		S	FLN0001	F	001	FLEXIBLE FUEL LINES
		S	RECTMO1	F	001	PROGRAM. RELAY CONTROL MODULE
		I	EXRVAL2	F	001	EXPLOSION RELIEF VALVE
		I	SOCON02	F	001	SHUTOFF CONTACTORS OP/WT
		I	ALC0001	F	001	ALARM CONTACTORS OP/WT
		I	CNLTHR1	F	001	LOCAL SPEED THROTTLE CONTROL
		I	OILTEMP	F	001	OIL TEMP SENSOR
		I	IMATEMP	F	001	INTAKE MANIFOLD TEMP SENSOR
		I	ELSDLH7	F	001	ELEC START MTR LH DUAL 24V 07
		I	BARGP01	F	001	ENGINE BARRING GROUP
		I	FULIN06	F	001	RIGID FUEL LINES-ENGINE
		I	EXPTTAG	F	001	EXPORT TAG
		I	CONNCST	F	001	CUSTOMER INTERFACE CONNECTION
		S	CLS0001	F	001	COOLANT LEVEL SENSOR
		I	DOILDFU	F	001	DUPLEX OIL / DUPLEX FUEL
		I	STNDROT	F	001	STANDARD ROTATION ENGINE

	I	IMOGL03	F	001	IMO GL ENG CERT 03
	I	DPX0001	F	001	DOMESTIC PACK-EXPORT CONTAINER
	I	SPCPNT1	F	001	SPECIAL PAINT - 3500
	I	EPTMRWH	F	001	MATTERHORN WHITE PAINT
	S	LITPAPR	F	001	EXTRA ENG LIT - PAPER (1 - 6)
	I	MSCMA90	F	001	PLEASURE CRAFT
	I	MWCODEA	F	001	PRIMARY DRIVE
	I	DM6910A	F	001	1000BHP @1600RPM A DUTY TYPE
	I	MSMARPR	F	001	MARINE PROPULSION COMMERCIAL
	I	1600RPM	F	001	1600 RPM
	I	3508B	F	001	3508B DIESEL ENGINE
	I	CSTHEXC	F	001	HEAT EXCHANGER COOLED
	I	HP01000	F	001	1000 BHP (746 BKW) W/O FAN
	I	MARINEA	F	001	MARINE CONTINUOUS A RATING
	I	MARPROP	F	001	MARINE PROPULSION ENGINE
	I	NOMCERT	F	001	DESIRED CERT NOT AVAILABLE
	I	SRST001	F	001	STD OPERATING SPEED RANGE
	I	YESMREQ	F	001	MCS CERTIFICATION REQUIRED

PART NUMBERS

	I	LA3852	04	001	3508B MARINE PROP SERIES II
	<u>NPR</u>	IRY <u>232-2468</u>	07	001	ENGINE AR
		S 5P-2506	00	001	LITERATURE GP
	<u>NPR</u>	IY <u>7N-8642</u>	05	001	RAIL GP-ENGINE SUPPORT
	<u>NPR</u>	IY <u>8N-9303</u>	09	001	AIR CLEANER GP
	<u>NPR</u>	IY <u>8N-9639</u>	04	001	GUARD GP-DAMPER
	<u>NPR</u>	SY <u>9X-9647</u>	01	001	SENSOR GP-POSITION
	<u>NPR</u>	IY <u>231-7874</u>	04	001	MOUNTING GP-BOX
	<u>NPR</u>	IY <u>231-9999</u>	07	001	BOX GP-JUNCTION
	<u>NPR</u>	IY <u>232-0008</u>	09	001	WIRING GP-ENGINE
	<u>NPR</u>	IY <u>292-4522</u>	01	001	MOUNTING GP-INSTRUMENT PANEL
	<u>NPR</u>	IY <u>290-3211</u>	00	001	BOX GP-INSTRUMENT PANEL
	<u>NPR</u>	IY <u>239-6365</u>	00	001	WIRING GP-ENGINE ELECTRONIC
	I	LA4062	01	001	FUEL & OIL CONNECTION SCREENIN
	<u>NPR</u>	IY <u>246-0455</u>	10	001	SHIELD GP-FUEL LINES
	<u>NPR</u>	IY <u>257-6899</u>	03	001	SHIELD GP-TURBOCHARGER
	<u>NPR</u>	IY <u>7N-4885</u>	12	001	SWITCH GP-COOLANT LEVEL

	I	LA3936	00	001	SEA WATER PUMP-SELF PRIMING
	<u>NPR</u>	IY <u>144-6081</u>	02	001	PUMP GP-AUXILIARY SEA WATER
	I	LA4434	01	001	PILOT HOUSE - MPD SINGE UNIT
	<u>NPR</u>	IY <u>249-6964</u>	03	001	HARNES AS-CONTROL
	<u>NPR</u>	SY <u>249-6961</u>	08	001	PANEL GP-PILOT HOUSE INSTR
	I	LA4020	01	001	MARINE GEAR SENSORS
	<u>NPR</u>	SY <u>161-9932</u>	05	001	SENSOR GP-PRESSURE
	<u>NPR</u>	SY <u>102-2240</u>	05	001	SENSOR GP-TEMPERATURE
	I	LA4784	02	001	CHARGING ALTERNATOR 24V 60 AMP
	<u>NPR</u>	IY <u>7E-4836</u>	10	001	MOUNTING GP-ALTERNATOR
	<u>NPR</u>	IY <u>7E-2858</u>	07	001	ALTERNATOR GP-CHARGING
	<u>NPR</u>	IY <u>7W-5780</u>	06	001	GUARD GP-BELT
	<u>NPR</u>	IY <u>107-7361</u>	03	001	DRIVE GP-ACCESSORY
	<u>NPR</u>	IY <u>253-9546</u>	00	001	WIRING GP-ALTERNATOR
	<u>NPR</u>	IY <u>151-9229</u>	02	001	GUARD GP-BELT
	I	PA2966	06	001	DEEP SUMP OIL PAN
	<u>NPR</u>	IY <u>7C-7185</u>	06	001	PAN GP-OIL
	<u>NPR</u>	IY <u>7C-9784</u>	05	001	GAUGE GP-OIL LEVEL (DIPSTICK)
	<u>NPR</u>	IY <u>9Y-7876</u>	02	001	DRAIN GP-ENGINE OIL
	I	PA4085	06	001	SUMP PUMP LH
	<u>NPR</u>	IY <u>7W-9703</u>	05	001	PUMP GP-SUMP
	<u>NPR</u>	IY <u>3N-4868</u>	05	001	HOSE AS
	I	LA4109	00	001	DUPLEX FUEL FILTER W/SHIELD GP
	<u>NPR</u>	IY <u>241-2738</u>	03	001	FILTER GP-FUEL
	<u>NPR</u>	IY <u>244-6567</u>	03	001	SHIELD GP-FUEL LINES
	I	LA4111	00	001	FUEL PRIMING PUMP W/SHIELD GP
	<u>NPR</u>	IY <u>210-1174</u>	03	001	PUMP GP-FUEL PRIMING
	<u>NPR</u>	IY <u>244-2478</u>	02	001	SHIELD GP-FUEL LINES
	<u>NPR</u>	SY <u>5N-2438</u>	05	001	LINES GP-FLEXIBLE FUEL
	<u>NPR</u>	SY <u>133-9300</u>	02	001	CONTROL GP-ENGINE ELECTRONIC
	<u>NPR</u>	IY <u>5N-4830</u>	19	001	VALVE GP-EXPLOSION RELIEF
	I	LA4439	00	001	CONTACTOR GP(SHUTOFF)-LH
	<u>NPR</u>	IY <u>4W-2768</u>	00	001	CONTACTOR GP
	<u>NPR</u>	IY <u>232-0858</u>	03	001	MOUNTING GP-CONTACTOR
	<u>NPR</u>	IY <u>264-3074</u>	01	002	PROTECTION GP-ENGINE
	I	LA4442	00	001	CONTACTOR GP(ALARM)-LH

	<u>NPR</u>	IY	<u>4W-2767</u>	00	001	CONTACTOR GP
	<u>NPR</u>	IY	<u>241-9056</u>	01	001	MOUNTING GP-CONTACTOR
	<u>NPR</u>	IY	<u>238-9549</u>	03	001	CONTROL GP-FUEL
	<u>NPR</u>	IY	<u>255-0178</u>	01	001	WIRING GP-SENSOR
	<u>NPR</u>	IY	<u>255-0180</u>	01	001	WIRING GP-SENSOR
		I	LA4011	01	001	ELECTRIC STARTING MOTOR LH 24V
	<u>NPR</u>	IY	<u>7C-0527</u>	06	001	STARTING MOTOR GP-ELECTRIC
	<u>NPR</u>	IY	<u>238-2928</u>	01	001	WIRING GP-ELECTRIC STARTING
	<u>NPR</u>	IY	<u>253-2468</u>	01	001	BARRING GP
		I	LA4510	00	001	RIGID FUEL RETURN LINE
	<u>NPR</u>	IY	<u>273-3285</u>	00	001	LINES GP-FUEL
	<u>NPR</u>	IY	<u>276-1307</u>	02	001	SHIELD GP-FUEL LINES
		I	0V-3364		001	EXPORT TAG
	<u>NPR</u>	IY	<u>301-0625</u>	00	001	HARNES AS-WIRING
	<u>NPR</u>	SY	<u>204-2518</u>	01	001	SENSOR GP-LIQUID LEVEL
		I	LA4906	00	001	DUPLEX OIL / DUPLEX FUEL
	<u>NPR</u>	IY	<u>120-4501</u>	13	001	FILTER GP-ENGINE OIL
	<u>NPR</u>	IY	<u>307-0008</u>	00	001	WIRING GP-SENSOR
		I	0V-1997		001	IMO GL ENG CERT 03
		I	0P-7824		001	DOMESTIC PACK-EXPORT CONTAINER
		I	0V-0933		001	SPECIAL PAINT-3500
		I	0P-9606		001	MATTERHORN WHITE PAINT
		S	0V-1672		001	EXTRA ENG LIT - PAPER (1 - 6)
		I	LL5529	00	001	1000 BHP WOF 1600 RPM MARINE
		I	0K-5444		001	746 BKW (1000 BHP) @ 1600 RPM
		I	0V-1045		001	END USE: MAR PROPULSION
						SHIPPED LOOSE
		S	ESO		001	(PRNT ESO COPY)
		S	PML		001	*REQUIRED DECALS
	<u>NPR</u>	S	0S-1571		024	BOLT
	<u>NPR</u>	S	0S-1588		008	BOLT
	<u>NPR</u>	S	0S-1591		008	BOLT
	<u>NPR</u>	S	1B-5355		024	NUT-FULL
	<u>NPR</u>	S	1B-5357		024	NUT-FULL
	<u>NPR</u>	S	1L-3769		001	RING-RETAINING
	<u>NPR</u>	S	1W-0531		001	BASE-PRIMARY FUEL FILTER

	NPR	S	2H-3429	001	RING-RETAINING
	NPR	S	2J-0157	001	SEAL-O-RING
	NPR	S	2N-2012	001	FITTING
	NPR	S	2V-7397	001	CABLE AS
	NPR	SY	<u>2W-7871</u>	001	FLANGE GP-EXHAUST
	NPR	S	2W-7872	002	FLANGE-EXHAUST
	NPR	S	2W-7873	002	GASKET-EXHAUST
	NPR	S	3N-6504	001	HOSE AS
	NPR	SY	<u>3N-8893</u>	001	HEAT EXCHANGER GP-SEA WATER
	NPR	S	3P-6061	003	GASKET
	NPR	S	3V-3308	008	WASHER-HARD
	NPR	SY	<u>4W-6673</u>	001	PUMP GP-AUXILIARY SEA WATER
	NPR	S	5B-9603	004	BOLT
	NPR	S	5F-5990	002	CLIP
	NPR	S	5L-3773	001	GASKET-EXHAUST ELBOW
	NPR	S	5L-4398	024	BOLT
	NPR	S	5M-2894	012	WASHER-HARD
	NPR	SY	<u>5N-2438</u>	001	LINES GP-FLEXIBLE FUEL
	NPR	SY	<u>5N-2457</u>	001	FITTING GP-EXHAUST
	NPR	SY	<u>5N-2458</u>	001	ELBOW-EXHAUST
	NPR	S	5P-8245	048	WASHER-HARD
		SY	<u>6L-4502</u>	001	CHART-PLATE & FILM
	NPR	S	6V-6866	002	PLUG
	NPR	SY	<u>7C-9390</u>	001	LINES GP-AUXILIARY SEA WATER
	NPR	SY	<u>7E-2627</u>	001	LINES GP-WATER
	NPR	S	7F-8896	001	KEY
	NPR	S	7H-9678	001	RETAINER-ELEMENT
	NPR	SY	<u>7L-7872</u>	001	BATTERY GP
	NPR	S	7N-1628	001	NUT
	NPR	S	7N-1831	002	HOSE AS
	NPR	S	7N-5971	001	ADAPTER
	NPR	S	7N-6954	001	FLANGE
	NPR	S	7N-6957	001	GASKET
	NPR	SY	<u>7N-6962</u>	001	FLANGE GP-EXHAUST
	NPR	SY	<u>7N-6968</u>	001	FITTING GP-EXHAUST
	NPR	S	7S-9323	001	SPRING

	NPR	SY	<u>7W-0281</u>	001	POWER TAKE-OFF GP
	NPR	S	7X-0485	002	ADAPTER
	NPR	S	8C-7566	002	ELBOW
	NPR	S	8C-7567	001	NIPPLE-PIPE
	NPR	S	8H-2778	001	SEAL-RING
	NPR	S	8H-7202	001	CASE AS-FUEL FILTER
	NPR	S	8L-8413	002	STRAP-CABLE
	NPR	S	8N-1186	001	HOSE AS
	NPR	S	8N-2555	002	FILTER-SOOT
	NPR	SY	<u>8N-6435</u>	001	FILTER GP-PRIMARY FUEL
	NPR	SY	<u>8N-9303</u>	001	AIR CLEANER GP
	NPR	S	8T-6762	001	PLUG-PIPE
	NPR	S	9G-0003	002	COVER AS-TERMINAL
	NPR	S	9G-0004	002	COVER AS-TERMINAL
	NPR	S	9L-9132	048	WASHER
	NPR	S	9M-2342	001	FILTER ELEMENT-FUEL
	NPR	S	9S-8752	008	NUT-FULL
	NPR	SY	<u>9X-9647</u>	001	SENSOR GP-POSITION
	NPR	SY	<u>9X-9730</u>	002	BATTERY GP
	NPR	SY	<u>9Y-4888</u>	001	CONNECTION GP-OIL
	NPR	SY	<u>141-7047</u>	001	MUFFLER
	NPR	SRV	<u>188-3080</u>	001	MODULE GP-SYSTEM COMMUNICATION
	NPR	SY	<u>204-2518</u>	001	SENSOR GP-LIQUID LEVEL
	NPR	S	214-6045	001	BELLOWS AS
	NPR	SY	<u>239-1475</u>	001	WIRING GP-ENGINE ELECTRONIC
	NPR	SY	<u>239-1476</u>	001	HARNES AS-PANEL
	NPR	SY	<u>240-5872</u>	001	HARNES AS-BOX
	NPR	SY	<u>241-5629</u>	001	BOX GP-JUNCTION
	NPR	S	245-3512	001	GASKET
	NPR	SY	<u>249-6961</u>	001	PANEL GP-PILOT HOUSE INSTR
		S	LEXM0051	001	IMO TECH DOC
		S	SEBU6251	001	LUBE 140019B2(A)
		S	SEBU6984	001	SUPP
		S	SEBU7844	001	OMM
		S	SEBU7920	001	EMISSIONS
		S	SELF5393	001	WARRANTY



S	SENR5002	001	DISPLAY INSTAL
S	SERP3910	001	PTSCD

Key:

I Installed

S Shipped Loose

Y Separate Illustration

R REMFG PART MAY BE AVAILABLE