

3516 INDUSTRIAL ENGINE

Engine Serial Prefix - 27Z (Build Date - 03/2009, Test Date - 03/2009)

▼ ENGINE - ENTIRE GROUP (27Z)

Qty.	NPR	Note	Part No.	Change Level	Req. Qty	Part Name
						FEATURE CODES
		I	516DI01	F	001	3516 DITA INDUSTRIAL ENGINE
		I	WTCLMN1	F	001	WATERCOOLED MANIFOLD
		I	INSR161	F	001	RH 16 HOLE INSTRUMENT PANEL
		N	GIPDT02	F	001	DIGITAL TACHOMETER
		I	CET0003	F	001	EXPANSION TANK
		I	CSOETCC	F	001	
		I	SWPMP05	F	001	SWP NON-SELF PRIMIN 05
		I	GOVMRH0	F	001	3161 MECHANICAL GOVERNOR-RH
		I	ELSOS10	F	001	ELECTRIC SHUTOFF OS
		I	MNSOLH1	F	001	MANUAL SHUTOFF LH
		I	EXRVAL1	F	001	EXPLOSION RELIEF VALVE
		I	FLYHG04	F	001	FLYWHEEL AND HOUSING, SAE NO.0
		I	FLY0000	F	001	FLYWHEEL - SAE NO. 0
		I	ACLRD01	F	001	AIR CLEANER -REGULAR DUTY
		S	AIARM05	F	001	AIR INLET ADAPTER-ROUND
		I	RAILS05	F	001	RAILS
		I	FPPRH01	F	001	FUEL PRIMING PUMP, RH MOUNTED
		S	FLN0001	F	001	FLEXIBLE FUEL LINES
		S	PFF0001	F	001	PRIMARY FUEL FILTER
		S	FUMDIS2	F	001	FUMES DISPOSAL
		I	FTHSG01	F	001	TWO SIDED FRONT HOUSING
		I	SHAFT02	F	001	FRONT STUB SHAFT
		I	EXPTTAG	F	001	EXPORT TAG
		I	1800RPM	F	001	1800 RPM
		I	INDUSTA	F	001	INDUSTRIAL CONTINUOUS A RATING
		I	INDUSTR	F	001	INDUSTRIAL ENGINE
		I	TRBAR02	F	001	TWO TURBO ARRANGEMENT
		S	LITENGE	F	005	EXTRA ENGLISH LITERATURE
		I	MSCIK36	F	001	DREDGE (INDUSTRIAL)
		I	MWCODEA	F	001	PRIMARY DRIVE

	I	SETREQ1	F	001	===STANDARD SETTING REQUEST===
	I	MSINDOE	F	001	INDUSTRIAL
	I	ESCNONE	F	001	NO EXTENDED SERVICE COVERAGE
	I	HP01710	F	001	1710 BHP (1275 BKW) W/O FAN
	I	NOTCERT	F	001	NON CERTIFIED ENGINE
	IL	5N-9999	F	001	===STANDARD SETTING REQUEST===
	IL	PP4085	F	001	1280 BHP WOF 1800 RPM
					PART NUMBERS
	I	PA0921	15	001	3516 DITA INDUSTRIAL ENGINE
	<u>NPR</u>	IY 4W-0284	30	001	ENGINE AR
	<u>NPR</u>	IY 2W-0688	04	001	CONTROL GP-GOVERNOR
	S	5P-2506	00	001	LITERATURE GP
	<u>NPR</u>	IY 2W-8947	02	001	WIRING GP-ENGINE
	<u>NPR</u>	IY 2W-9593	07	001	METER GP-SERVICE
	<u>NPR</u>	IY 7E-3159	01	001	TACHOMETER GP-ELECTRIC
	<u>NPR</u>	IY 8N-9639	05	001	GUARD GP-DAMPER
	<u>NPR</u>	IY 7W-9265	04	001	LINES GP-INSTRUMENT PANEL
	I	LA1473	00	001	WATERCOOLED MANIFOLD
	<u>NPR</u>	IY 7C-9238	07	001	MANIFOLD GP-EXHAUST
	<u>NPR</u>	IY 7C-9931	09	001	LINES GP-AIR
	<u>NPR</u>	IY 9Y-0333	12	001	LINES GP-TURBOCHARGER OIL
	<u>NPR</u>	IY 9Y-0543	01	001	LINES GP-WATER
	<u>NPR</u>	IY 9Y-9107	10	001	LINES GP-WATER
	I	PA2364	00	001	PANEL AR. - PREMIUM - RH
	<u>NPR</u>	IY 1W-8104	10	001	LINES GP-INSTRUMENT PANEL
	<u>NPR</u>	IY 4W-6463	07	001	LINES GP-INSTRUMENT PANEL
	<u>NPR</u>	IY 4W-6803	02	001	MOUNTING GP-INSTRUMENT PANEL
	<u>NPR</u>	IY 4W-6887	09	001	PANEL GP-INSTRUMENT
	<u>NPR</u>	IY 8N-5721	03	001	LINES GP-INSTRUMENT PANEL
	<u>NPR</u>	NY 7E-3159	01	001	TACHOMETER GP-ELECTRIC
	I	PA3285	05	001	TANK GP - EXPANSION
	<u>NPR</u>	IY 8N-7717	12	001	TANK GP-EXPANSION
	<u>NPR</u>	IY 8N-8993	07	001	CONNECTION GP-WATER
	<u>NPR</u>	IY 102-6694	08	001	HOUSING & REGULATOR GP
	<u>NPR</u>	IY 3N-2652	10	001	CONNECTION GP-EXPANSION TANK
	<u>NPR</u>	IY 8N-8466	09	001	PUMP GP-AUXILIARY SEA WATER

	<u>NPR</u>	IY	<u>8N-6712</u>	18	001	GOVERNOR GP
		I	PA2254	02	001	ELECTRIC SHUTOFF OS - ETS
	<u>NPR</u>	IY	<u>7C-5032</u>	10	001	SHUTOFF GP-AIR
	<u>NPR</u>	IY	<u>7W-8053</u>	04	001	SHUTOFF GP-ELECTRICAL
	<u>NPR</u>	IY	<u>2W-5531</u>	02	001	SHUTOFF GP-MANUAL
	<u>NPR</u>	IY	<u>8N-8510</u>	24	001	VALVE GP-EXPLOSION RELIEF
		I	PA2132	06	001	FLYWHEEL,HSG&COVERS AR("0"H
	<u>NPR</u>	IY	<u>4W-1528</u>	15	001	COVER GP-FLYWHEEL HOUSING
	<u>NPR</u>	IY	<u>102-3540</u>	06	001	HOUSING GP-FLYWHEEL
		I	LA1477	01	001	FLYWHEEL, SAE NO. 0
	<u>NPR</u>	IY	<u>7W-0968</u>	04	001	FLYWHEEL GP
		I	PA2817	01	001	AIR CLEANER - REGULAR DUTY
	<u>NPR</u>	IY	<u>9Y-0998</u>	03	001	AIR CLEANER GP
	<u>NPR</u>	SY	<u>7W-9828</u>	01	001	ADAPTER GP-AIR CLEANER
		I	PA1172	10	001	RAILS
	<u>NPR</u>	IY	<u>7N-8650</u>	05	001	RAIL GP-ENGINE SUPPORT
	<u>NPR</u>	IY	<u>107-0165</u>	03	001	PUMP GP-FUEL PRIMING
	<u>NPR</u>	SY	<u>5N-2438</u>	05	001	LINES GP-FLEXIBLE FUEL
	<u>NPR</u>	SY	<u>8N-6435</u>	03	001	FILTER GP-PRIMARY FUEL
		I	LA0183	05	001	FUMES DISPOSAL
	<u>NPR</u>	IY	<u>4W-0472</u>	05	001	FUMES DISPOSAL GP
	<u>NPR</u>	NY	<u>9Y-5563</u>	03	001	FUMES DISPOSAL GP
		I	PA1813	04	001	HOUSING AR - FRONT
	<u>NPR</u>	IY	<u>7W-3724</u>	06	001	HOUSING GP-FRONT
	<u>NPR</u>	IY	<u>8N-9642</u>	08	001	COVER GP-FRONT HOUSING
	<u>NPR</u>	IY	<u>7W-3629</u>	03	001	SHAFT GP-STUB
		I	0V-3364		001	EXPORT TAG
		S	0P-9715		005	EXTRA LITERATURE - ENGLISH
		S	0V-1085		001	END USE: INDUSTRIAL
		I	0V-2329		001	PRODUCTION CORRECTION
	<u>NPR</u>	IY	<u>8N-9167</u>	10	001	DRIVE GP-ACCESSORY
		I	LL6183	00	001	1710 BHP @ 1800 RPM IND A
		I	0K-7816		001	1275 BKW (1710 BHP) @ 1800 RPM
	<u>NPR</u>	IY	<u>9Y-1239</u>	05	001	TURBOCHARGER GP
		S			001	SHIPPED LOOSE 0S1594BOLT

	S	ESO	001	(PRNT ESO COPY)
	S	PML	001	*REQUIRED DECALS
	<u>NPR</u>	S 0S-1571	004	BOLT
	<u>NPR</u>	S 0S-1585	016	BOLT
	<u>NPR</u>	S 0S-1588	004	BOLT
	<u>NPR</u>	S 1L-3769	001	RING-RETAINING
	<u>NPR</u>	S 1W-0531	001	BASE-PRIMARY FUEL FILTER
	<u>NPR</u>	S 2H-3429	001	RING-RETAINING
	<u>NPR</u>	S 2J-0157	001	SEAL-O-RING
	<u>NPR</u>	S 2N-8928	004	CLIP
	<u>NPR</u>	SY <u>2W-8947</u>	001	WIRING GP-ENGINE
	<u>NPR</u>	S 3N-6504	001	HOSE AS
	<u>NPR</u>	S 3P-6061	002	GASKET
	<u>NPR</u>	S 5F-5990	002	CLIP
	<u>NPR</u>	SY <u>5N-2438</u>	001	LINES GP-FLEXIBLE FUEL
	<u>NPR</u>	S 5N-7830	002	GASKET
		S 5N-8749	001	DIAGRAM-WIRING
	<u>NPR</u>	S 5P-0597	001	CLAMP-HOSE
	<u>NPR</u>	S 5P-1472	290	HOSE
		S 5P-2506	001	LITERATURE GP
	<u>NPR</u>	S 5P-8247	016	WASHER-HARD
		SY <u>6L-4502</u>	001	CHART-PLATE & FILM
	<u>NPR</u>	S 6V-6866	002	PLUG
	<u>NPR</u>	S 6V-8801	004	NUT
		S 7C-1880	001	DIAGRAM - WIRING
	<u>NPR</u>	SY <u>7E-3159</u>	001	TACHOMETER GP-ELECTRIC
	<u>NPR</u>	S 7H-9678	001	RETAINER-ELEMENT
	<u>NPR</u>	S 7N-1628	001	NUT
	<u>NPR</u>	S 7S-9323	001	SPRING
	<u>NPR</u>	SY <u>7W-0968</u>	001	FLYWHEEL GP
	<u>NPR</u>	SY <u>7W-9828</u>	001	ADAPTER GP-AIR CLEANER
	<u>NPR</u>	S 7W-9829	002	ADAPTER AS
	<u>NPR</u>	S 8H-2778	001	SEAL-RING
	<u>NPR</u>	S 8H-7202	001	CASE AS-FUEL FILTER
	<u>NPR</u>	S 8N-1186	001	HOSE AS
	<u>NPR</u>	S 8N-1663	001	BOOT

	<u>NPR</u>	SY	<u>8N-6435</u>	001	FILTER GP-PRIMARY FUEL
	<u>NPR</u>	SY	<u>8N-8466</u>	001	PUMP GP-AUXILIARY SEA WATER
	<u>NPR</u>	S	8T-4224	096	WASHER-HARD
	<u>NPR</u>	S	8T-4896	008	WASHER-HARD
	<u>NPR</u>	S	8T-9043	048	BOLT
	<u>NPR</u>	S	9B-7237	004	BOLT
	<u>NPR</u>	S	9M-2342	001	FILTER ELEMENT-FUEL
	<u>NPR</u>	S	9S-1343	001	PLUG-CUP
	<u>NPR</u>	SY	<u>9Y-5563</u>	001	FUMES DISPOSAL GP
	<u>NPR</u>	S	031-4155	048	LOCKNUT
	<u>NPR</u>	S	197-7348	001	TACHOMETER GP
		S	SEBU6251	006	LUBE
		S	SEBU6701	006	OMM
		S	SEBU6984	006	SUPP
		S	SELF5419	006	WARRANTY
		S	SERP2967	006	PTSCD