

C9 MARINE ENGINE

Engine Serial Number - X9Y (Build Date - 10/2010, Test Date - 10/2010)

▼ ENGINE - ENTIRE GROUP (X9Y)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						<b>FEATURE CODES</b>
		I	C09MC01	F	001	C9 ACERT TA MAR PROP-PORT 01
		S	CGTPS08	F	001	THROTTLE SENSOR PRE-CAL 100VM
		I	ALT1221	F	001	CHARGING ALT - 12V - 110AMP
		I	BLTGD05	F	001	DAMPER GUARD
		S	ELSMDF1	F	001	FRONT FACING START MOTOR-12V
		I	CLS0002	F	001	COOLANT LEVEL SENSOR 02
		I	COLHYO0	F	001	COOLER-HYDRAULIC OIL
		I	FULCOL2	F	001	FUEL COOLER-SL
		S	FLN0002	F	001	FLEXIBLE FUEL LINES
		I	EXCWCE6	F	001	WATERCOOLED ELBOW - 8 IN
		S	VIBIS01	F	001	VIBRATION ISOLATORS
		S	MPD0002	F	001	MAR POWER DISPLAY W/O SENSORS
		I	PLCRFIN	F	001	PLEASURE CRAFT FINISH
		I	CATYLLW	F	001	CAT YELLOW PAINT
		I	OFLH00	F	001	OIL FILLER-LH
		S	TRNSNR4	F	001	TRANSMISSION SENSORS-ADEM 4
		I	CSTHEXC	F	001	HEAT EXCHANGER COOLED
		I	ELECGOV	F	001	ELECTRONIC GOVERNOR
		I	RPM2500	F	001	APPLICATION SPEED - 2500 RPM
		I	VLT0012	F	001	12 VOLT
		S	PBKCD01	F	001	PARTS BOOK - ELECTRONIC
		I	MSCMA12	F	001	WORKBOAT
		I	MWCODEA	F	001	PRIMARY DRIVE
		I	HPM0575	F	001	575 MHP W/O FAN
		I	MSMARPR	F	001	MARINE PROPULSION COMMERCIAL
		I	ESCNONE	F	001	NO EXTENDED SERVICE COVERAGE
		I	EUNONE	F	001	NO EU CERTIFICATION
		I	FLAGNO	F	001	NON GERMAN FLAGGED VESSELS
		I	GERNONE	F	001	NO GERMAN FLAG IMO CERT
		I	HIPERPC	F	001	ACERT HI-PERF RECREATIONAL ENG
		I	MARINEE	F	001	MAR HI PERFORMANCE "E" RATING
		I	MARPLCR	F	001	PLEASURE CRAFT/YACHT
		I	PORTSID	F	001	PORT SIDE (RH SERVICE)

	I	TWINENG	F	001	TWIN ENGINE INSTALLATION
	I	TVANONE	F	001	NO TVA REPORT
	I	IMONONE	F	001	NO IMO GL CERTIFICATION REQ'D
					<b>PART NUMBERS</b>
	I	MC0001	06	001	C9 TA MAR PROP HEAT EX RH SER
	<a href="#">NPR</a>	IY <a href="#">311-3569</a>	05	001	ENGINE AR-COMPLETE
		S 5P-2506	00	001	LITERATURE GP
	<a href="#">NPR</a>	SY <a href="#">102-9220</a>	04	001	RECOVERY GP-COOLANT
	<a href="#">NPR</a>	I 194-9572	03	001	PLUG GP-ENGINE
	<a href="#">NPR</a>	IY <a href="#">197-5988</a>	07	001	HEAT EXCHANGER GP-SEA WATER
	<a href="#">NPR</a>	IY <a href="#">197-5991</a>	13	001	AFTERCOOLER GP-RAW WATER
	<a href="#">NPR</a>	IY <a href="#">197-5993</a>	02	001	PUMP GP-AUXILIARY SEA WATER
	<a href="#">NPR</a>	IY <a href="#">197-6009</a>	00	001	LINES GP-AUXILIARY SEA WATER
	<a href="#">NPR</a>	IY <a href="#">199-7012</a>	01	001	GAUGE GP-OIL LEVEL (DIPSTICK)
	<a href="#">NPR</a>	IY <a href="#">201-1071</a>	01	001	SENSOR GP-TEMPERATURE
	<a href="#">NPR</a>	SY <a href="#">206-4509</a>	00	001	FITTING GP-FUEL LINES
	<a href="#">NPR</a>	IY <a href="#">206-4729</a>	00	001	FASTENER GP-FRONT COVER
	<a href="#">NPR</a>	IY <a href="#">207-4851</a>	00	001	PULLEY GP-IDLER
	<a href="#">NPR</a>	IY <a href="#">222-1236</a>	01	001	DRAIN GP-COOLANT
	<a href="#">NPR</a>	SY <a href="#">222-1830</a>	00	001	DRAIN GP-COOLANT
	<a href="#">NPR</a>	IY <a href="#">222-2771</a>	04	001	ADAPTER GP-DAMPER
	<a href="#">NPR</a>	SY <a href="#">223-7456</a>	04	001	AIR CLEANER GP
	<a href="#">NPR</a>	I 235-6391	02	001	PLUG GP-ENGINE
	<a href="#">NPR</a>	IY <a href="#">257-6943</a>	02	001	WIRING GP-ENGINE
	<a href="#">NPR</a>	IY <a href="#">262-2122</a>	01	001	MOUNTING GP-AIR CLEANER
	<a href="#">NPR</a>	IY <a href="#">305-2961</a>	04	001	COVER GP-VALVE MECHANISM
	<a href="#">NPR</a>	IY <a href="#">306-3019</a>	04	001	LINES GP-WATER
	<a href="#">NPR</a>	IY <a href="#">306-5498</a>	03	001	WIRING GP-ENGINE
	<a href="#">NPR</a>	I 310-6429	01	001	PRESERVATION GP
	<a href="#">NPR</a>	IY <a href="#">317-9357</a>	00	001	SUPPORT GP-ENGINE
	<a href="#">NPR</a>	SY <a href="#">121-7028</a>	03	001	CONTROL GP-ENGINE ELECTRONIC
	<a href="#">NPR</a>	IY <a href="#">197-6014</a>	07	001	ALTERNATOR GP-CHARGING
	<a href="#">NPR</a>	IY <a href="#">197-5998</a>	02	001	GUARD GP-ALTERNATOR
	<a href="#">NPR</a>	SY <a href="#">199-6919</a>	00	001	STARTING MOTOR GP-ELECTRIC
		I PA7715	03	001	COOLANT LEVEL SENSOR
	<a href="#">NPR</a>	IY <a href="#">174-7428</a>	03	001	SENSOR GP-LIQUID LEVEL
		I PA7747	01	001	COOLER GP-HYDRAULIC OIL
	<a href="#">NPR</a>	IY <a href="#">192-2135</a>	03	001	COOLER GP-MARINE XMSN OIL
	<a href="#">NPR</a>	IY <a href="#">197-6006</a>	04	001	COOLER GP-FUEL
	<a href="#">NPR</a>	SY <a href="#">177-1823</a>	00	001	LINES GP-FLEXIBLE FUEL

	<a href="#">NPR</a>	SY	<a href="#">272-2948</a>	00	001	ELBOW GP-EXHAUST
	<a href="#">NPR</a>	SY	<a href="#">197-6018</a>	00	001	MOUNTING GP-ENGINE FLEXIBLE
		I	PA7569	08	001	MARINE POWER DISPLAY SYSTEM
	<a href="#">NPR</a>	SY	<a href="#">165-0199</a>	01	001	WIRING GP-INSTRUMENT PANEL
	<a href="#">NPR</a>	SY	<a href="#">267-8623</a>	02	001	DISPLAY GP-MONITOR
		I	314-5851	00	001	PLEASURE CRAFT FINISH
	<a href="#">NPR</a>	I	131-5443	01	001	PAINT GP
	<a href="#">NPR</a>	IY	<a href="#">172-8733</a>	03	001	FILLER GP-ENGINE OIL
		I	MC0690	00	001	TRANSMISSION SENSORS
	<a href="#">NPR</a>	SY	<a href="#">106-0735</a>	08	001	SENSOR GP-TEMPERATURE
	<a href="#">NPR</a>	SY	<a href="#">163-8512</a>	03	001	SENSOR GP-PRESSURE
	<a href="#">NPR</a>	SY	<a href="#">229-2012</a>	01	001	ADAPTER GP-SENSOR
		S	0V-1767		001	PARTS BOOK - ELECTRONIC
		I	PP5502	00	001	567 BHP 423 KW WOF 2500 RPM MA
		I	0K-7124		001	423 BKW (567 BHP) @ 2500 RPM
		I	0V-1045		001	END USE: MAR PROPULSION
						<b>SHIPPED LOOSE</b>
		S			002	PACK IN CARTON ONLY INFO(A)
		S	ESO		001	(PRNT ESO COPY)
		S	PML		001	*REQUIRED DECALS
	<a href="#">NPR</a>	S	1P-4278		002	CLAMP-HOSE
	<a href="#">NPR</a>	S	5C-7261		002	NUT
	<a href="#">NPR</a>	S	5D-1026		002	CLAMP-BAND
	<a href="#">NPR</a>	S	5K-5068		001	FITTING-PIPE
	<a href="#">NPR</a>	S	5P-0599		002	CLAMP-BAND
	<a href="#">NPR</a>	S	5P-0767		054	HOSE
		S	5P-2506		001	LITERATURE GP
	<a href="#">NPR</a>	S	5P-3860		001	CLAMP-HOSE
	<a href="#">NPR</a>	S	5P-4116		008	WASHER-HARD
	<a href="#">NPR</a>	S	5P-9617		001	ADAPTER
		SY	<a href="#">6L-4502</a>		001	CHART-PLATE & FILM
	<a href="#">NPR</a>	S	6V-5048		001	SEAL-O-RING
	<a href="#">NPR</a>	S	6V-5049		002	SEAL-O-RING
	<a href="#">NPR</a>	S	6V-8397		004	SEAL-O-RING
	<a href="#">NPR</a>	S	7F-3400		001	BAG-POLYETHYLENE
		S	7N-4210		001	BOOT
	<a href="#">NPR</a>	S	7X-2537		004	BOLT
	<a href="#">NPR</a>	S	8C-3681		200	HOSE
	<a href="#">NPR</a>	S	8C-6868		002	CONNECTOR
	<a href="#">NPR</a>	S	8C-7310		001	ADAPTER

	<a href="#">NPR</a>	S	8D-5054	003	WASHER-HARD
	<a href="#">NPR</a>	S	8S-2332	003	BOLT-12 POINT HEAD
	<a href="#">NPR</a>	S	8T-4189	002	BOLT
	<a href="#">NPR</a>	S	8T-4196	004	BOLT
	<a href="#">NPR</a>	S	8T-6703	002	CLAMP-HOSE
	<a href="#">NPR</a>	S	8T-8730	002	SOCKET-CONNECTOR
	<a href="#">NPR</a>	S	8W-2522	002	HOSE AS
	<a href="#">NPR</a>	S	9J-6190	002	UNION-ADAPTER
	<a href="#">NPR</a>	S	9S-4191	001	PLUG-O-RING
	<a href="#">NPR</a>	S	9X-0263	001	ADAPTER
	<a href="#">NPR</a>	S	030-7962	001	ELBOW
	<a href="#">NPR</a>	S	096-5028	001	INDICATOR-AIR FILTER CHANGE
	<a href="#">NPR</a>	SY	<a href="#">102-9220</a>	001	RECOVERY GP-COOLANT
	<a href="#">NPR</a>	SY	<a href="#">106-0735</a>	001	SENSOR GP-TEMPERATURE
		S	106-7602	001	BOOT
	<a href="#">NPR</a>	S	110-8314	004	WASHER
	<a href="#">NPR</a>	S	112-3231	001	ADAPTER
	<a href="#">NPR</a>	S	112-5282	001	SEAL-O-RING
	<a href="#">NPR</a>	SY	<a href="#">121-7028</a>	001	CONTROL GP-ENGINE ELECTRONIC
	<a href="#">NPR</a>	SY	<a href="#">121-7029</a>	001	CONTROL GP-ENGINE ELECTRONIC
	<a href="#">NPR</a>	S	124-6259	003	CLAMP-HOSE
	<a href="#">NPR</a>	S	124-6265	001	CLAMP-HOSE
	<a href="#">NPR</a>	S	125-7876	010	TUBE-HEAT SHRINK
	<a href="#">NPR</a>	S	129-1666	004	CLIP
	<a href="#">NPR</a>	S	133-0969	001	CONNECTOR-SOCKET
	<a href="#">NPR</a>	S	133-0970	001	RECEPTACLE AS-CONNECTOR
	<a href="#">NPR</a>	S	133-0974	001	WEDGE-PLUG LOCK
	<a href="#">NPR</a>	S	133-4076	001	PLUG AS
	<a href="#">NPR</a>	S	134-2540	001	RESISTOR AS-CONNECTION
	<a href="#">NPR</a>	S	153-7950	001	HOSE AS
	<a href="#">NPR</a>	SY	<a href="#">163-8512</a>	001	SENSOR GP-PRESSURE
	<a href="#">NPR</a>	SY	<a href="#">165-0199</a>	001	WIRING GP-INSTRUMENT PANEL
	<a href="#">NPR</a>	S	165-0200	001	CABLE AS
	<a href="#">NPR</a>	S	165-0201	001	CABLE AS
	<a href="#">NPR</a>	SY	<a href="#">177-1823</a>	001	LINES GP-FLEXIBLE FUEL
	<a href="#">NPR</a>	S	178-9522	001	ELBOW AS-EXHAUST
	<a href="#">NPR</a>	S	192-2153	001	HOSE-AIR INLET
	<a href="#">NPR</a>	S	197-5452	004	MOUNT-ENGINE
	<a href="#">NPR</a>	SY	<a href="#">197-6018</a>	001	MOUNTING GP-ENGINE FLEXIBLE
	<a href="#">NPR</a>	SY	<a href="#">199-6919</a>	001	STARTING MOTOR GP-ELECTRIC

<a href="#">NPR</a>	SY	<a href="#">200-6962</a>	001	STARTING MOTOR GP-ELECTRIC
<a href="#">NPR</a>	SY	<a href="#">206-4509</a>	001	FITTING GP-FUEL LINES
<a href="#">NPR</a>	SY	<a href="#">222-1830</a>	001	DRAIN GP-COOLANT
<a href="#">NPR</a>	S	223-7453	001	HOSE
<a href="#">NPR</a>	SY	<a href="#">223-7456</a>	001	AIR CLEANER GP
<a href="#">NPR</a>	SY	<a href="#">229-2012</a>	001	ADAPTER GP-SENSOR
<a href="#">NPR</a>	S	255-6863	001	GASKET
<a href="#">NPR</a>	SY	<a href="#">267-8623</a>	001	DISPLAY GP-MONITOR
<a href="#">NPR</a>	SY	<a href="#">272-2948</a>	001	ELBOW GP-EXHAUST
<a href="#">NPR</a>	S	280-4015	001	FILTER GP-FUMES DISPOSAL
<a href="#">NPR</a>	S	300-9952	001	VALVE AS-CHECK
<a href="#">NPR</a>	SY	<a href="#">308-9314</a>	001	AIR CLEANER GP
<a href="#">NPR</a>	S	320-2225	001	HOSE
<a href="#">NPR</a>	SY	<a href="#">336-2020</a>	001	RECOVERY GP-COOLANT
	S	LEBM0189	001	OPERN
	S	REHS1187	001	S.I.
	S	SEBP4250	001	PTSBK
	S	SEBU6984	001	SUPP
	S	SEBU7719	001	OMM
	S	SEBU7920	001	EMISSIONS
	S	SELF5393	001	WARRANTY
	S	SENR5002	001	DISPLAY INSTAL