

3512B GEN SET ENGINE

Engine Serial Number - 8RM (Build Date - 05/1997, Test Date - 05/1997, Ship Date - 06/1997)

▼ ENGINE - ENTIRE GROUP (8RM)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						<b>PART NUMBERS</b>
	<a href="#">NPR</a>	IRY	<a href="#">112-2662</a>	08	001	ENGINE AR
		I	5N-9581		001	LOW EMISSION - 3500B SERIES.
	<a href="#">NPR</a>	IY	<a href="#">7N-6782</a>	07	001	INDICATOR GP-AIR FILTER CHANGE
	<a href="#">NPR</a>	IY	<a href="#">8N-9639</a>	04	001	GUARD GP-DAMPER
	<a href="#">NPR</a>	IY	<a href="#">113-1592</a>	02	001	MOUNTING GP-AIR CLEANER
	<a href="#">NPR</a>	IY	<a href="#">116-3269</a>	03	001	REGULATOR GP-TEMPERATURE
	<a href="#">NPR</a>	IY	<a href="#">126-9191</a>	02	001	GROUND GP-ELECTRICAL
	<a href="#">NPR</a>	IY	<a href="#">5N-2438</a>	05	001	LINES GP-FLEXIBLE FUEL
	<a href="#">NPR</a>	IY	<a href="#">9Y-7876</a>	00	001	DRAIN GP-ENGINE OIL
	<a href="#">NPR</a>	IY	<a href="#">9Y-0848</a>	01	001	RAIL GP-ENGINE SUPPORT
	<a href="#">NPR</a>	IY	<a href="#">119-0851</a>	04	001	MOUNTING GP-INSTRUMENT PANEL
	<a href="#">NPR</a>	IY	<a href="#">120-4489</a>	01	001	HARNESS GP-WIRING
	<a href="#">NPR</a>	IY	<a href="#">134-6323</a>	00	001	WIRING GP-PANEL
	<a href="#">NPR</a>	IY	<a href="#">4P-7072</a>	00	001	CONNECTION GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">115-1062</a>	01	001	PUMP GP-FUEL PRIMING
	<a href="#">NPR</a>	I	4W-4755	02	001	SWITCH GP-MAGNETIC
	<a href="#">NPR</a>	I	8N-3898	09	001	STARTING MOTOR GP-ELECTRIC
	<a href="#">NPR</a>	IY	<a href="#">6I-1041</a>	01	001	MOUNTING GP-JACKET WTR HEATER
	<a href="#">NPR</a>	IY	<a href="#">6I-1042</a>	03	001	MOUNTING GP-JACKET WTR HEATER
	<a href="#">NPR</a>	IY	<a href="#">7E-6248</a>	05	001	HEATER GP-JACKET WATER
	<a href="#">NPR</a>	IY	<a href="#">7W-9828</a>	00	001	ADAPTER GP-AIR CLEANER
	<a href="#">NPR</a>	IY	<a href="#">122-3200</a>	02	001	SHUTOFF GP-AIR
	<a href="#">NPR</a>	IY	<a href="#">134-6315</a>	00	001	WIRING GP-PANEL
	<a href="#">NPR</a>	IY	<a href="#">134-0065</a>	00	001	WIRING GP-ENGINE
	<a href="#">NPR</a>	IY	<a href="#">113-4650</a>	00	001	AIR CLEANER GP
	<a href="#">NPR</a>	I	5P-2586	03	001	OIL
		I	143-5203	00	001	CONVERSION AR
	<a href="#">NPR</a>	IY	<a href="#">8N-5743</a>	08	001	DRIVE GP-ACCESSORY
	<a href="#">NPR</a>	IY	<a href="#">8N-5767</a>	04	001	DRIVE GP-ACCESSORY
	<a href="#">NPR</a>	IY	<a href="#">7C-4803</a>	02	001	ALTERNATOR GP-CHARGING
	<a href="#">NPR</a>	IY	<a href="#">7E-4836</a>	03	001	MOUNTING GP-ALTERNATOR
	<a href="#">NPR</a>	IY	<a href="#">7W-5780</a>	03	001	GUARD GP-BELT
	<a href="#">NPR</a>	IY	<a href="#">133-6468</a>	00	001	WIRE AS-GROUND

	<a href="#">NPR</a>	IY	<a href="#">134-6317</a>	00	001	WIRING GP-PANEL
	<a href="#">NPR</a>	IY	<a href="#">133-9300</a>	01	001	CONTROL GP-ENGINE ELECTRONIC
		I	LA1104	03	001	RELAY DRIVER MODULE AND RELAYS
	<a href="#">NPR</a>	IY	<a href="#">9Y-6497</a>	01	001	BOARD AS-RELAY
	<a href="#">NPR</a>	IY	<a href="#">123-7450</a>	02	001	MODULE GP-RELAY DRIVER
	<a href="#">NPR</a>	IY	<a href="#">125-7089</a>	04	001	BOX GP-INSTRUMENT PANEL
		I	0P-9425		016	SER CHARGE PER HOUR
		I	0P-8707		001	CQ30842-1_____QUOTE NO.
		I	5P-2506	00	001	LITERATURE GP
		I	5Z-3333	00	001	***SPECIAL SETTING REQUEST****
		I	PP9416	02	001	1480 BHP WOF 1500 RPM
		I	2T-9559	00	001	1104 KW @ 1500 RPM (1480 BHP)
	<a href="#">NPR</a>	IY	<a href="#">116-0687</a>	03	001	TURBOCHARGER GP
	<a href="#">NPR</a>	IY	<a href="#">116-7010</a>	03	001	PUMP GP-FUEL INJECTION