

AS SHIPPED [JDY]**SEPTEMBER 06, 2013**For Help Desk Phone Numbers [Click here](#)

The below option will email full breakdown of the serial number
<input checked="" type="radio"/> Excel <input type="radio"/> PDF
<input type="button" value="FullBreakDown"/>

Sales Model: C15

Build Date: 2012-03

Feature Codes

Reference Number	Eng	Chg	Quantity	ASM	LESS	Set	Type	Description
C15DW07	F		1	I				C15 ACERT DIT PET WELL ENG 07
ALT1211	F		1	I				CHARGING ALTERNATOR 12V 115AMP
AIRLG06	F		1	I				AIR LINES - 90 DEGREE
CGTSP04	F		1	S				REM SPEED CONTROL - HAND KNOB
OILDRN1	F		1	S				OIL PAN DRAIN VALVE SL
ALTM00	F		1	I				ALTERNATOR MTG-LH-WIDE MOUNT
PFFWS04	F		1	S				PRI FUEL FILTER/WATER SEP SL
ACGOV00	F		1	I				AIR COMPRESSOR GOVERNOR
MES0001	F		1	S				MESSENGER DISPLAY
EXCCON1	F		1	I				EXHAUST CONNECTION-HALF MARMON
EXCOF01	F		1	S				EXH OUT FLANGE 152 MM (6 IN)
ENGSUP8	F		1	I				REAR ENGINE SUPPORT
EXCDE02	F		1	I				DRY ELBOW 152 MM (6 IN)
CLS0001	F		1	S				COOLANT LEVEL SENSOR SL
OLGAG01	F		1	I				OIL LEVEL GAUGE-LH REAR
OPTDS02	F		1	I				OIL PAN - REAR SUMP
GIPCNT2	F		1	S				CONTROL 12V
ACLDE03	F		1	S				AIR CLEANER-DUAL,SL,ABC RATING
FLYHG11	F		1	I				FLYWHEEL HOUSING SAE NO. 1
AIRCP01	F		1	I				AIR COMPRESSOR BA-921
FULIN04	F		1	I				FUEL LINES - LOW LH MOUNT
OFLT01	F		1	I				TOP OIL FILLER
TOC0004	F		1	I				TRANSMISSION OIL COOLER
ELSM128	F		1	I				ELEC START MOTOR 12V LH 42 MT
FLYAD01	F		1	I				FLYWHEEL ADAPTER -SAE NO. 1
GIPMPU1	F		1	I				MAGNETIC PICKUP
FRSUP03	F		1	I				FRONT ENG SUPPORT-WIDE MOUNT
WIRGP01	F		1	I				HARNES - ECM INTERCONNECT
AIRSO02	F		1	I				AIR SHUTOFF-12V 02
2100RPM	F		1	I				2100 RPM
ATAAC02	F		1	I				AIR TO AIR AFTERCOOLER
EXHREAR	F		1	I				REAR FACING EXHAUST
INDUSTC	F		1	I				IND "C" INTERMITTENT RATING
LUBOIL1	F		1	I				LUBRICATING OIL-38 L
VLT0012	F		1	I				12 VOLT

WELLENG	F	1	I	APPLICATION
MSPETWS	F	1	I	PETRO WELL SERVICING
PBKHCD1	F	1	S	PARTS BOOK-PAPER & ELEC
EUDEDOI	F	1	I	EUROPEAN DIRECTIVE ENGINE DOI
OTHREG0	F	1	I	OTHER REGULATED AREAS LABEL
MSCPBI1	F	1	I	WORKOVER
MWCODED	F	1	I	MECHANICAL DRIVE
HP00540	F	1	I	540 BHP (403 BKW) W/O FAN
EXHMDRY	F	1	I	EXHAUST MANIFOLD DRY

Part Numbers

Reference Number	Eng	Chg	Quantity	ASM LESS	Set Type	Description	BreakDown
PT1235	01		1		I	ENGINE AR - C15 ATAAC (MEUI) 5	BreakDown...
- 3730061	00		1		I	ENGINE AR - CORE	BreakDown...
- 4P5894	06		1		I	DAMPER GP	BreakDown...
- 5P2506	00		1		S	LITERATURE - ENGLISH	BreakDown...
- 4N2481	04		1		I	FASTENER GP	BreakDown...
- 4P6846	02		1		I	FASTENER GP	BreakDown...
- 6I3638	06		1		I	DRIVE GP - PUMP	BreakDown...
- 1074447	03		1		I	INSTRUCTION - TURBO	BreakDown...
- 1076736	02		1		I	BLOCK COVER - TURBO	BreakDown...
- 1076737	01		1		I	BLOCK COVER - OIL FILLER	BreakDown...
- 1082312	05		1		I	FUEL FITTING	BreakDown...
- 1089382	04		1		I	FAN DRIVE MTG FASTENER	BreakDown...
- 1091657	07		1		I	FASTENER (WHEN NO JAKE BRAKE)	BreakDown...
- 1092373	02		1		I	FASTENER	BreakDown...
- 1112088	01		1		I	REAR LIFTING EYE	BreakDown...
- 1245289	01		1		I	SHIELD GP.	BreakDown...
- 1270564	01		1		I	LIFTING GP - FRONT	BreakDown...
- 1356552	05		1		I	MANIFOLD GP-EXH	BreakDown...
- 1504279	09		1		I	FUEL TRANSFER PUMP GP	BreakDown...
- 1596159	07		1		I	CAM COVER	BreakDown...
- 1599107	06		1		I	CONNECTION	BreakDown...
- 1599362	08		1		I	FUMES DISPOSAL	BreakDown...
- 1608329	01		1		I	FASTENER GP (OIL PAN)	BreakDown...
- 1701282	02		1		I	FILTER GP - OIL	BreakDown...
- 1727120	01		1		I	FASTENER GP	BreakDown...
- 1804367	01		1		I	FASTENER GP	BreakDown...
- 2002852	00		1		I	FASTENER GP	BreakDown...
- 2016631	02		1		I	FITTING GP	BreakDown...
- 2098321			1		I	SHIELD GP - HEAT	BreakDown...
- 2240754	01		1		I	FASTENER GP	BreakDown...
- 2243978	04		1		I	PLATE GP -FOR ACERT VALVE COVE	BreakDown...
- 2279495	01		1		I	SUPPORT GP-BRACE	BreakDown...
- 2279864	01		1		I	FASTENER GP	BreakDown...

- 2299965	00	1	I	FASTENER GP	BreakDown...
- 2299966	00	1	I	FASTENER GP	BreakDown...
- 2349184	01	1	I	PLUG GP	BreakDown...
- 2349706	02	1	I	PLUG GP	BreakDown...
- 2361780	03	1	I	CONT GP-MTG& -C	BreakDown...
- 2389384	01	1	I	FASTENER GP	BreakDown...
- 2406053	07	1	I	LINES GP-TURBO OIL	BreakDown...
- 2413006	03	1	I	TURBO GP	BreakDown...
- 2478211	01	1	I	PLUG GP	BreakDown...
- 2554214	02	1	I	INSTRUCTIONS -R	BreakDown...
- 2559248	00	1	I	FASTENER GP	BreakDown...
- 2559250	03	1	I	PLUG GP	BreakDown...
- 2559251	02	1	I	PLUG GP	BreakDown...
- 2560370	01	1	I	FITTING GP	BreakDown...
- 2601544	02	1	I	COVER GP	BreakDown...
- 2692509	03	1	I	HOUSING GP - FRONT	BreakDown...
- 2826846	00	1	I	FASTENER GP	BreakDown...
- 2850028	00	1	I	FASTENER GP	BreakDown...
- 2858628	00	1	I	FASTENER GP	BreakDown...
- 2869120	00	1	I	FASTENER GP	BreakDown...
- 3111441	01	1	I	PLUG GP	BreakDown...
- 3590920	02	1	I	WIRING GP - CONT	BreakDown...
- 3605376	02	3	I	PAINT GP	BreakDown...
- 3645465	02	1	I	INST-PAINT	BreakDown...
1214134	02	1	I	ALTERNATOR - 12V 115 AMP	BreakDown...
1260081	03	1	I	AIR LINES	BreakDown...
1340670	03	1	S	REMOTE SPEED CONTROL- HAND KNOB	BreakDown...
1631383	02	1	S	DRAIN	BreakDown...
1863652	02	1	I	MTG GP - ALT	BreakDown...
2129431	00	1	S	FILTER AS.	BreakDown...
2244501	02	1	I	GOVERNOR GP	BreakDown...
2433820	09	1	S	DISPLAY GP-ELEK	BreakDown...
2577276	00	1	I	CONNECTION GP	BreakDown...
2W7851	00	1	S	EXHAUST OUTLET FLANGE	BreakDown...
4N4286	08	1	I	REAR ENGINE SUPPORTS	BreakDown...
6L2927	12	1	I	DRY ELBOW	BreakDown...
PA7160	09	1	I	COOLANT LEVEL SENSOR	BreakDown...
- 2399957	02	1	S	SENSOR GP-LEVEL	BreakDown...
PA7654	02	1	I	OIL LEVEL GAUGE	BreakDown...
- 3590900	00	1	I	GAUGE GP-O LEVEL	BreakDown...
PA7659	01	1	I	OIL PAN	BreakDown...
- 1627456	04	1	I	PAN GP - OIL	BreakDown...
PA7774	04	1	I	START STOP CONTROL	BreakDown...
- 1950131	00	1	S	WIRING GP - ENGINE	BreakDown...
- 2058657	00	1	S	CONT GP - START	BreakDown...
PQ0044	01	1	I	AIR CLEANER GP	BreakDown...

- 2W6183	06	1	S	CLEANER GP-AIR	BreakDown...
- 2326182	00	1	S	PRECLEANER GP	BreakDown...
PQ0198	04	1	I	HOUSING GP-FLYWHEEL- SAE #1	BreakDown...
- 1357634	06	1	I	HOUSING GP - FLYWHEEL	BreakDown...
- 9N3889	05	1	I	COVER GP-(FLYWHEEL HOUSING)	BreakDown...
- 1275728	02	1	I	COVER	BreakDown...
PQ0209	04	1	I	COMPRESSOR GP-AIR 15.7 CFM	BreakDown...
- 2222879	14	1	I	COMPRESSOR GP - AIR	BreakDown...
- 2240875	03	1	I	FITTING GP	BreakDown...
- 2774857	00	1	I	PLUG GP	BreakDown...
- 2780026	00	1	I	PLUG GP	BreakDown...
- 2799540	01	1	I	PLUG GP	BreakDown...
- 3636215	00	1	I	MANIFOLD GP	BreakDown...
PQ0220	01	1	I	LINES GP-FUEL FILTER (LH LOWER	BreakDown...
- 2242165	02	1	I	PUMP GP-FUEL	BreakDown...
- 1921623	03	1	I	MOUNTING GP - SNSR	BreakDown...
- 3588535	02	1	I	LINES GP - F FIL	BreakDown...
PQ0442	01	1	I	FILLER GP-OIL-TOP MOUNTED	BreakDown...
- 1209847	01	1	I	COVER GP	BreakDown...
- 1872701	01	1	I	COVER GP - MECH	BreakDown...
PQ0450	00	1	I	COOLER GP-TRANSMISSION OIL	BreakDown...
- 1092374	03	1	I	FASTENER	BreakDown...
- 1117303	03	1	I	PIPE THREAD FLANGE	BreakDown...
- 1459276	02	1	I	COVER GP.	BreakDown...
- 2559249	07	1	I	LINES GP - WATER	BreakDown...
PQ0491	00	1	I	MOTOR GP- STARTING (12V) (LH)	BreakDown...
- 1105369	02	1	I	ELECTRIC STARTING MOTOR - 12 V	BreakDown...
PQ0495	02	1	I	FLYWHEEL GP - ADAPTER	BreakDown...
- 1488808	02	1	I	ADAPTER GP - FLYWHEEL	BreakDown...
PQ0497	01	1	I	MAGNETIC PICKUP	BreakDown...
- 5N8757	08	1	I	MAGNETIC PICKUP	BreakDown...
PQ0581	00	1	I	FRONT ENGINE SUPPORT	BreakDown...
- 1354326	03	1	I	SUPPORT GP - ENGINE	BreakDown...
PQ0593	03	1	I	WIRING GP	BreakDown...
- 2642352	01	1	I	WIRING GP	BreakDown...
- 2002310	01	1	S	CONNECTION GP	BreakDown...
PQ1733	01	1	I	FACTORY OIL FILL GP	BreakDown...
- 3505899	01	1	I	LUBRICANT GP	BreakDown...
PQ1759	01	1	I	SHUTOFF GP - AIR	BreakDown...
- 2592472	00	1	I	MOUNTING GP - AIR SHUT OFF	BreakDown...
- 3074646	02	1	I	LINES GP-AIR	BreakDown...

- 2592471	01	1	I	SHUTOFF GP - AIR	BreakDown...
0V1590		1	I	END USE: PETRO WELL SERVICING	BreakDown...
0V1766		1	S	PARTS BOOK - PAPER & ELECTRONI	BreakDown...
3529856	00	1	I	CERTIFICATION GP (EEC DOI)	BreakDown...
3611878	00	1	I	CERTIFICATION - OTHER REG. ARE	BreakDown...
PP6612	00	1	I	540 BHP 402.7 KW WOF 2100 RPM	BreakDown...
- 0K8942		1	I	402.7 BKW (540 BHP) @ 2100 RPM	BreakDown...

Ship Loose

Reference Number	Eng Chg	Quantity	ASM LESS	Set Type	Description	BreakDown
5P2506		1	S		LITERATURE GP	BreakDown...
- LEBM3227		1	S		MESSENGER GUIDE 140021D3(A)	BreakDown...
DUP INC		1	S			BreakDown...
- SEBU6251		1	S		LUBE 140019B2(A)	BreakDown...
- SEBU8400		1	S		OMM FCAB-10 (A)	BreakDown...
- SELF5419		1	S		WARRANTY 140013C2(A)	BreakDown...
- SELF5463		1	S		WARRANTY 14007-D2(A)	BreakDown...
- SELF9001		1	S		SUPP HUT17D2 (A)	BreakDown...
- SERP5291		1	S		PTSCD 140011B1(A)	BreakDown...
1340670		1	S		CONT GP -B	BreakDown...
- 1340670		1	S		CONTROL GP HUT 96 (I)	BreakDown...
1631383		1	S		DRAIN GP-OIL PAN	BreakDown...
- 3E7427		1	S		ADAPTER 1666A1 (F)	BreakDown...
- 7E4761		1	S		VALVE-SHUTOFF 1650G3 (F)	BreakDown...
- 0619458		1	S		SEAL-0-RING 1674G2 (E)	BreakDown...
- 2385080		1	S		SEAL-O-RING 1636K4 (E)	BreakDown...
2129431		1	S		FILTER AS	BreakDown...
- 2129431		1	S		FILTER AS **SUB** (G)	BreakDown...
2433820		1	S		DISPLAY GP-ELEK	BreakDown...
- 2433820		1	S		DISPLAY GP-ELECT HUT37 (D)	BreakDown...
2W7851		1	S		FLANGE GP-EXH	BreakDown...
- 1A1135		4	S		BOLT 16483-12(B)	BreakDown...
- 1B5358		4	S		NUT 1654 2-5(B)	BreakDown...
- 5H8331		1	S		GASKET 16703-10(D)	BreakDown...
- 5N4739		1	S		FLANGE HUT11 (C)	BreakDown...
- 5P8247		8	S		WASHER 1644 D5 (B)	BreakDown...
2399957		1	S		SENSOR GP-LEVEL	BreakDown...
- 2399957		1	S		SENSOR GP-L HUT2A2 (I)	BreakDown...
1950131		1	S		WIRING GP-ENG -A	BreakDown...
- 1950131		1	S		WIRING GP HUT89 (F)	BreakDown...
2058657		1	S		CONT GP-START&	BreakDown...

- 2058657	1	S	CONTROL GP HUT 62 (D)	BreakDown...
2W6183	1	S	CLEANER GP-AIR-E	BreakDown...
- 3B6552	1	S	ELBOW 1674 4-9(F)	BreakDown...
- 5L3233	1	S	FITTING 16503-4 (B)	BreakDown...
- 6V8188	4	S	NUT-FULL 1654 5-7(B)	BreakDown...
- 8N2694	1	S	INDICATOR 16625-12(I)	BreakDown...
- 8T4223	8	S	WASHER-HARD 1670 3-2(B)	BreakDown...
- 8T8917	4	S	BOLT 1658 5-4(B)	BreakDown...
- 1356261	2	S	CLAMP HUT 72 (B)	BreakDown...
- 1622177	1	S	HOSE HUT 19 (F)	BreakDown...
- 1630820	1	S	CLEANER GP FL142 (F)	BreakDown...
2326182	1	S	PRECLEANER GP	BreakDown...
- 1M3419	1	S	SEAL-O-RING 1652B1 (F)	BreakDown...
- 8S6823	1	S	HOOD AS FL114 (F)	BreakDown...
- 8S6824	1	S	CLAMP AS HUT3B1 (F)	BreakDown...
- 1133155	1	S	BODY FL66 (F)	BreakDown...
1488808	1	S	ADAPTER GP-FLY	BreakDown...
- 7N6114	1	S	BUSHING 1650 4-8(B)	BreakDown...
- 9Y6089	1	S	GASKET 1674B1 (D)	BreakDown...
- 0138307	12	S	BOLT-SOCKET 1648D2 (B)	BreakDown...
2002310	1	S	CONNECTION GP -G	BreakDown...
- 8T8732	1	S	RECEPTACLE-CONN 1660E2 (B)	BreakDown...
- 8T8737	36	S	PLUG SEAL 1662B3 (B)	BreakDown...
- 8T9834	1	S	PLUG AS-CONN HUT 22 (B)	BreakDown...
- 9W0844	3	S	SOCKET-CONNECTOR 1652J4 (B)	BreakDown...
- 9X3401	3	S	PIN-CONNECTOR 1652C4 (F)	BreakDown...
- 9X3402	39	S	SOCKET-CONNECTOR 1652H4 (F)	BreakDown...
- 1330969	1	S	SOCKET-CONNECTOR 1656H5 (B)	BreakDown...
- 1516320	2	S	TOOL-REMOVAL 1662I3 (F)	BreakDown...
0V1766	1	S		BreakDown...
- SEBP5291	1	S	PARTSBOOK 140011B1(A)	BreakDown...

Caterpillar Confidential: **Green**

Content Owner: Commercial Processes Division

Web Master(s): [PSG Web Based Systems Support](#)

Current Date: Friday, September 06, 2013 10:41:23 AM

© Caterpillar Inc. 2013 All Rights Reserved.

[Data Privacy Statement](#).