

C9 INDUSTRIAL ENGINE

Engine Serial Prefix - JSC (Build Date - 02/2009, Test Date - 02/2009)

▼ ENGINE - ENTIRE GROUP (JSC)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	C09DI10	F	001	C9 ACERT ATAAC IND ENGINE 10
		S	CGTPS04	F	001	REMOTE SPEED CONT-HAND KNOB
		I	AIH2402	F	001	AIR INLET HEATER - 24 VOLT
		I	RAD0017	F	001	RADIATOR
		I	RADGD04	F	001	RADIATOR GUARD
		I	FLYHG09	F	001	FLYWHEEL HOUSING
		I	FAST001	F	001	FASTENER
		S	PFFWS04	F	001	PRIMARY FUEL FILTER/WATER SEP
		I	EXHMRT0	F	001	REAR TURBO EXHAUST MANIFOLD
		I	AIRCP01	F	001	AIR COMP - 2 CYL N/F/U/W PTO
		I	ACGOV00	F	001	AIR COMPRESSOR GOVERNOR
		I	ENGSP02	F	001	FRONT ENGINE SUPPORT
		I	FANPL21	F	001	FAN PULLEY 0.83:1 RATIO
		I	FANB018	F	001	BLOWER FAN 33 IN
		I	ALT2405	F	001	CHARGING ALTERNATOR 24V 45 AMP
		I	ALTPL00	F	001	ALT PULLEY 3.69 DIA 2 GROOVE
		I	ALTM03	F	001	ALTERNATOR MOUNTING
		S	FLN0002	F	001	FLEXIBLE FUEL LINES
		I	ELSMLH1	F	001	LH ELEC STRT MTR 24V 42MT
		I	TOC0001	F	001	TRANSMISSION OIL COOLER
		I	CLS0001	F	001	COOLANT LEVEL SENSOR
		I	INSPN03	F	001	INSTRUMENT PANEL - 5 HOLE -24V
		S	VLTM024	F	001	VOLTMETER GAUGE 24V
		S	VLTMT01	F	001	VOLTMETER MOUNTING
		S	AMG24V1	F	001	AMMETER GAUGE 24 V
		I	LUBOIL1	F	001	LUBRICATING OIL
		S	BAT2402	F	001	24V BATTERY SET-DRY 1000 CCA
		S	BTRCBL1	F	001	BATTERY CABLES
		S	BTR0001	F	001	BATTERY RACK
		I	EXHREAR	F	001	REAR FACING EXHAUST
		I	INDUSTA	F	001	INDUSTRIAL CONTINUOUS A RATING
		I	INDUSTR	F	001	APPLICATION
		I	2200RPM	F	001	2200 RPM

	S	PBKHCD1	F	001	**OLD**PARTS BOOK-PAPER & ELEC
	I	MSCPB12	F	001	DRILLING
	I	MWCODEE	F	001	PRIME POWER
	I	HP00275	F	001	275 BHP (205 BKW) W/O FAN
	I	MSPETDR	F	001	PETRO DRILLING
	I	ESCNONE	F	001	NO EXTENDED SERVICE COVERAGE
	I	CERTIF5	F	001	EPA/CARB TIER3 & EC STAGE IIIA
					PART NUMBERS
	I	PQ0500	04	001	C9 DIT ATAAC INDUSTRIAL ENGINE
	NPR	IY 252-4430	03	001	ENGINE AR-CORE
		I 263-4087	00	001	INSTRUCTIONS -R
		S 5P-2506	00	001	LITERATURE GP
	NPR	IY 220-2765	05	001	LINES GP-WATER
	NPR	IY 260-1546	02	001	PUMP GP-WATER
	NPR	IY 172-6291	03	001	PUMP GP-FUEL PRIMING
	NPR	IY 247-5716	00	001	COVER GP-FRONT HOUSING
	NPR	IY 256-9751	00	001	DAMPER & PULLEY GP
	NPR	IY 235-8174	04	001	COVER GP-VALVE MECHANISM
	NPR	IY 233-0423	02	001	FASTENER GP-VALVE COVER BASE
	NPR	IY 183-3649	07	001	COVER GP-CYLINDER BLOCK
	NPR	IY 187-3077	05	001	FUMES DISPOSAL GP
	NPR	IY 187-6508	04	001	SEAL GP-CRANKSHAFT
	NPR	IY 192-2832	07	001	LINES GP-ENGINE OIL
	NPR	IY 256-9755	00	001	PULLEY GP-CRANKSHAFT
	NPR	IY 256-9757	00	001	FASTENER GP-DAMPER & PULLEY
	NPR	IY 260-6882	04	001	LINES GP-FUEL FILTER
	NPR	IY 256-6166	00	001	DRIVE GP-WATER PUMP
	NPR	IY 241-7597	03	001	CONTROL & MTG GP-ENGINE ELEK
	NPR	IY 198-6368	01	001	PAN GP-OIL
	NPR	IY 198-6475	02	001	DRAIN GP-ENGINE OIL
	NPR	IY 201-8144	00	001	FILTER GP-FUEL
	NPR	IY 201-9778	06	001	FILTER GP-ENGINE OIL
	NPR	IY 204-1552	00	001	GAUGE GP-OIL LEVEL (DIPSTICK)
		I 208-2845	01	001	INSTRUCTIONS
	NPR	IY 231-1935	06	001	WIRING GP-ENGINE ELECTRONIC
	NPR	IY 257-7268	00	001	FASTENER GP-WIRING HARNESS
	NPR	IY 204-1543	00	001	VALVE GP-FLUID SAMPLING
	NPR	IY 260-6885	01	001	SENSOR GP-ENGINE
	NPR	IY 236-7315	05	001	FASTENER GP-VALVE COVER
	NPR	SY 134-0670	02	001	CONTROL GP-ENGINE SPEED

	I	PA7777	05	001	WIRING - CONTROL (24V)
	NPR	IY 118-7284	03	001	STARTING AID GP
	NPR	IY 209-2108	05	001	STARTING AID GP
	I	PQ0778	03	001	RADIATOR SIDE-BY-SIDE ATAAC/RA
	NPR	IY 194-1093	00	001	MOUNTING GP-FAN DRIVE
	NPR	IY 194-9463	02	001	DRIVE GP-FAN
	NPR	IY 198-7629	00	001	FASTENER GP-FAN DRIVE
	NPR	IY 228-4326	02	001	LINES GP-AIR
	NPR	IY 233-0079	01	001	ELBOW GP-AIR INLET
	NPR	IY 253-7173	02	001	LINES GP-WATER
	NPR	IY 253-7179	03	001	RADIATOR GP
	NPR	IY 231-4545	01	001	ELBOW GP-WATER
	NPR	IY 228-4333	00	001	GUARD GP-RADIATOR
	I	PQ1031	00	001	HOUSING GP-FLYWHEEL
	NPR	I 9Y-9238	05	001	COVER GP-SHIPPING
	NPR	IY 265-0890	01	001	HOUSING GP-FLYWHEEL
	I	PQ0518	02	001	COVER GP - FLYWHEEL
	NPR	IY 117-0178	03	001	PLUG GP-SHIPPING
	I	157-0074	01	001	INSTRUCTIONS-FLYWHEEL
	SY	212-9431	00	001	FILTER GP-WATER SEP & FUEL
	I	PA7782	04	001	REAR TURBO EXHAUST MANIFOLD
	NPR	IY 165-4465	05	001	LINES GP-TURBOCHARGER OIL
	NPR	IY 204-1545	00	001	MANIFOLD GP-EXHAUST
	I	208-0437	00	001	INSTRUCTIONS
	I	PQ0587	03	001	COMPRESSOR GP-AIR (16.5 CFM)
	NPR	IY 166-1763	02	001	LINES GP-AIR COMPRESSOR
	NPR	IY 173-7123	00	001	FASTENER GP-FRONT HOUSING
	NPR	IY 239-6363	01	001	AIR COMPRESSOR GP
	NPR	IY 7E-4832	01	001	GOVERNOR GP-AIR COMPRESSOR
	I	PQ0019	04	001	C-9/3126B SUPPORT GP-FRONT(WID
	NPR	IY 230-2540	00	001	SUPPORT GP-ENGINE
	I	PQ0730	03	001	DRIVE GP-FAN PULLEY (0.83:1)
	NPR	IY 198-7627	00	001	PULLEY GP-FAN
	NPR	IY 2P-1388	00	001	V-BELT SET
	NPR	IY 228-4311	01	001	FAN GP-BLOWER
	NPR	IRY 5N-5692	13	001	ALTERNATOR GP-CHARGING
	NPR	ICLY 2W-8494	01	001	PULLEY-ALTERNATOR
	NPR	IY 253-7176	02	001	MOUNTING GP-ALTERNATOR
	NPR	SY 280-2584	00	001	LINES GP-FLEXIBLE FUEL
	I	PQ0707	01	001	ELECTRIC STARTING MOTOR 24 V,

	NPR	IY	102-5836	04	001	STARTING MOTOR GP-ELECTRIC
		I	PL4059	03	001	COOLER GP-TRANSMISSION OIL
	NPR	IY	228-0780	02	001	COOLER GP-TRANSMISSION OIL
	NPR	IY	228-0784	00	001	PLUG GP-ENGINE
		I	PA7160	09	001	COOLANT LEVEL SENSOR
	NPR	SY	239-9957	01	001	SENSOR GP-LIQUID LEVEL
		I	PQ1048	00	001	INSTRUMENT PANEL & MOUNTING
	NPR	IY	255-0652	00	001	MOUNTING GP-INSTRUMENT PANEL
	NPR	IY	266-2297	00	001	PANEL GP-INSTRUMENT
	NPR	SY	105-1457	00	001	VOLTMETER GP
	NPR	SY	110-8310	01	001	MOUNTING GP-INSTRUMENT
	NPR	SY	3N-9012	03	001	AMMETER GP
		I	PL4088	02	001	LUBRICANT GP
		I	165-4458	04	001	PLATE & FILM GP
	NPR	SY	7L-7871	09	001	BATTERY GP
	NPR	SY	7W-0825	01	001	CABLE GP-BATTERY
	NPR	SY	3N-7056	00	001	SUPPORT GP-BATTERY
		S	0V-1766		001	**OLD**PARTS BOOK-PAPER & ELEC
		I	PP5336	00	001	275 BHP WOF 2200 RPM IND A TIE
		I	0K-4891	00	001	205 KW (275 BHP) @ 2200 'A'
		I	0V-2787		001	END USE: PETRO DRILLING
	NPR	NY	228-4336	01	001	COOLER GP-FUEL
	NPR	NY	230-2561	01	001	LINES GP-FUEL
						SHIPPED LOOSE
	NPR	S	2V-7397		001	CABLE AS
	NPR	S	3K-1715		001	CABLE AS
	NPR	S	3N-5990		001	FILM-GAUGE IDENTIFICATION
	NPR	S	3N-5992		001	AMMETER AS
	NPR	S	3N-7054		001	SUPPORT AS-BATTERY
	NPR	S	3N-7055		001	BOARD
	NPR	S	3V-6785		001	CABLE AS
	NPR	S	5S-0003		004	NUT
	NPR	S	6L-2845		001	BRACKET-MOUNTING
	NPR	S	7C-0100		002	MOUNT-FLEXIBLE
	NPR	S	7N-5274		001	COVER AS-TERMINAL
	NPR	S	8L-8413		002	STRAP-CABLE
	NPR	S	8N-0869		001	COVER-TERMINAL
	NPR	S	8N-1725		001	COVER AS-TERMINAL
	NPR	S	9G-0003		002	COVER AS-TERMINAL
	NPR	S	9G-0004		002	COVER AS-TERMINAL

<input type="checkbox"/>	NPR	S	9G-8909	001	COVER-TERMINAL
<input type="checkbox"/>	NPR	S	9M-1974	004	WASHER-HARD
<input type="checkbox"/>	NPR	S	9X-9720	002	BATTERY
<input type="checkbox"/>	NPR	SY	105-1457	001	VOLTMETER GP
<input type="checkbox"/>	NPR	SY	134-0670	001	CONTROL GP-ENGINE SPEED
<input type="checkbox"/>		SY	212-9431	001	FILTER GP-WATER SEP & FUEL
<input type="checkbox"/>	NPR	S+Y	228-4336	001	COOLER GP-FUEL
<input type="checkbox"/>	NPR	S+Y	230-2561	001	LINES GP-FUEL
<input type="checkbox"/>	NPR	SY	239-9957	001	SENSOR GP-LIQUID LEVEL
<input type="checkbox"/>	NPR	S+Y	280-2584	001	LINES GP-FLEXIBLE FUEL