

3516B LOCOMOTIVE ENGINE

Engine Serial Number - BCK (Build Date - 05/2005, Test Date - 05/2005)

▼ ENGINE - ENTIRE GROUP (BCK)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
	<a href="#">NPR</a>	ILY	<a href="#">133-9300</a>	01	001	<b>PART NUMBERS</b> CONTROL GP-ENGINE ELECTRONIC
		IL	LA3601	04	001	3516B HD MID-SPEED LOCOMOTIVE
	<a href="#">NPR</a>	ILY	<a href="#">183-2815</a>	07	001	ENGINE AR
		IL	5P-2506	00	001	LITERATURE GP
	<a href="#">NPR</a>	ILY	<a href="#">8N-9639</a>	04	001	GUARD GP-DAMPER
	<a href="#">NPR</a>	ILY	<a href="#">151-9214</a>	05	001	WIRING GP-ENGINE
	<a href="#">NPR</a>	ILY	<a href="#">151-9216</a>	01	001	CONNECTION GP-ELECTRICAL
	<a href="#">NPR</a>	ILY	<a href="#">151-9218</a>	05	001	BOX GP-JUNCTION
	<a href="#">NPR</a>	ILY	<a href="#">186-4216</a>	00	001	ADAPTER GP-TURBOCHARGER
	<a href="#">NPR</a>	ILY	<a href="#">232-0254</a>	00	001	SUPPORT GP-TURBOCHARGER
		IL	5N-9581		001	LOW EMISSIONS STRATEGY
	<a href="#">NPR</a>	ILY	<a href="#">115-1063</a>	03	001	PUMP GP-FUEL PRIMING
	<a href="#">NPR</a>	ILY	<a href="#">2W-5616</a>	05	001	COVER GP-OIL PAN
	<a href="#">NPR</a>	ILY	<a href="#">8N-3896</a>	16	001	STARTING MOTOR GP-ELECTRIC
		IL	LA2259	01	001	DIESEL HYDRAULIC COOLING CONV
	<a href="#">NPR</a>	ILY	<a href="#">155-2559</a>	05	001	CONNECTION GP-WATER
	<a href="#">NPR</a>	ILY	<a href="#">155-2560</a>	01	001	CONNECTION GP-WATER
	<a href="#">NPR</a>	ILY	<a href="#">186-4228</a>	00	001	CONNECTION GP-INLET
	<a href="#">NPR</a>	ILY	<a href="#">8N-6435</a>	02	001	FILTER GP-PRIMARY FUEL
	<a href="#">NPR</a>	IL	176-1677	02	001	PULLEY GP-ALTERNATOR
	<a href="#">NPR</a>	IL	107-7361	03	001	DRIVE GP-ACCESSORY
	<a href="#">NPR</a>	ILY	<a href="#">147-3738</a>	01	001	VALVE GP-FLUID SAMPLING
	<a href="#">NPR</a>	ILY	<a href="#">260-8644</a>	00	001	RAIL GP-ENGINE SUPPORT
	<a href="#">NPR</a>	ILY	<a href="#">140-2175</a>	00	001	CONTROL GP-REMOTE SPEED
	<a href="#">NPR</a>	ILY	<a href="#">5N-2438</a>	05	001	LINES GP-FLEXIBLE FUEL
	<a href="#">NPR</a>	ILY	<a href="#">194-4903</a>	01	001	MOUNTING GP-ENGINE OIL FILTER
	<a href="#">NPR</a>	IL	222-1408	03	001	BOX GP-JUNCTION
	<a href="#">NPR</a>	IL	244-6002	00	001	SWITCH GP-MAGNETIC
		IL	0V-2330		001	DTO QUOTE CORRECTION
		IL	0V-8707		001	DTO QUOTE DESIGN FEE
		IL	0V-1080		001	END USE: LOCOMOTIVE IND
		IL	LL5283	00	001	3004 BHP WOF @ 1800 RPM
		IL	0K-2413		001	2240 KW @ 1800 RPM (3004 BHP)

**SHIPPED LOOSE**

	S		001	
<a href="#">NPR</a>	SY	<a href="#">5N-2438</a>	001	LINES GP-FLEXIBLE FUEL
	SY	<a href="#">6L-4502</a>	001	CHART-PLATE & FILM
<a href="#">NPR</a>	SY	<a href="#">8N-6435</a>	001	FILTER GP-PRIMARY FUEL
<a href="#">NPR</a>	SY	<a href="#">133-9300</a>	001	CONTROL GP-ENGINE ELECTRONIC
<a href="#">NPR</a>	SY	<a href="#">140-2175</a>	001	CONTROL GP-REMOTE SPEED
<a href="#">NPR</a>	SY	<a href="#">151-9214</a>	002	WIRING GP-ENGINE
<a href="#">NPR</a>	SY	<a href="#">151-9216</a>	001	CONNECTION GP-ELECTRICAL
<a href="#">NPR</a>	SY	<a href="#">151-9218</a>	040	BOX GP-JUNCTION
<a href="#">NPR</a>	SY	<a href="#">186-4228</a>	024	CONNECTION GP-INLET