

## ▼ ENGINE - ENTIRE GROUP (CTP)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						<b>FEATURE CODES</b>
		I	412GE05	F	001	G3412TA 450 EKW 60HZ PGS
		I	FDV0039	F	001	FAN DRIVE
		I	RADRM32	F	001	RADIATOR REMOVAL
		I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL
		I	PTSRR01	F	001	REAR POWER TERMINAL STRIP
		I	60H-0480	F	001	60HZ 480 VOLTS
		I	CONTINU	F	001	CONTINUOUS APPLICATION
		I	MSEPGGN	F	001	GENERAL EPG
		I	TRSGEN2	F	001	PGS TEST REPORT @ 1.0 PF
		I	MSCEC70	F	001	ENERGY UTILITIES
		I	MWCODEH	F	001	COGENERATION
		I	PSTSPCL	F	001	*SPECIAL SETTING REQUEST* 01
		I	CTSPCL0	F	001	CURRENT TRANSF., SPECIAL
	<a href="#">NPR</a>	ILY	<a href="#">170-8400</a>	F	001	COVER GP-CONTROL PANEL
	<a href="#">NPR</a>	ILY	<a href="#">143-9517</a>	F	001	REGULATOR GP-VOLTAGE
	<a href="#">NPR</a>	I	121-6202	F	001	REGULATOR GP-VOLTAGE
	<a href="#">NPR</a>	ILY	<a href="#">204-6818</a>	F	001	PANEL GP-ELECTRONIC
	<a href="#">NPR</a>	IY	<a href="#">119-0978</a>	F	001	TRANSFORMER-CURRENT
	<a href="#">NPR</a>	ILY	<a href="#">209-3660</a>	F	001	CONTROL GP-GOVERNOR
						<b>PART NUMBERS</b>
		I	LE4009	23	001	ENGINE AR-G3412 TA STANDBY/CON
	<a href="#">NPR</a>	IY	<a href="#">205-0994</a>	00	001	GENERAL AR
	<a href="#">NPR</a>	IY	<a href="#">2S-7227</a>	18	001	STARTING MOTOR GP-ELECTRIC
	<a href="#">NPR</a>	IY	<a href="#">2W-2949</a>	07	001	CONTROL GP-CARBURETOR
	<a href="#">NPR</a>	IY	<a href="#">2W-4237</a>	03	001	LINES GP-OIL SUPPLY
	<a href="#">NPR</a>	IY	<a href="#">2W-4685</a>	10	001	LINES GP-TURBOCHARGER OIL
		I	3L-0303		001	ADJUSTING-WW 2301 CONTROL SYS
	<a href="#">NPR</a>	IY	<a href="#">3N-8594</a>	06	001	COVER GP-ENGINE LIFTING EYE
	<a href="#">NPR</a>	IY	<a href="#">4P-3030</a>	04	001	AFTERCOOLER GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">4P-3449</a>	03	001	LINES GP-AIR
	<a href="#">NPR</a>	IY	<a href="#">4P-6023</a>	13	001	BYPASS GP-EXHAUST
	<a href="#">NPR</a>	IY	<a href="#">4P-6715</a>	02	001	MOUNTING GP-AIR CLEANER
	<a href="#">NPR</a>	IY	<a href="#">4P-6717</a>	01	001	AIR CLEANER GP
	<a href="#">NPR</a>	IY	<a href="#">4P-6720</a>	01	001	CARBURETOR GP

<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">4P-6721</a>	05	001	REGULATOR GP-GAS PRESSURE
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">4W-6321</a>	02	001	TURBOCHARGER GP
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">6I-2160</a>	02	001	ACTUATOR AS-GOVERNOR
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">7L-7871</a>	09	001	BATTERY GP
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">9Y-1268</a>	04	001	PUMP GP-AUXILIARY WATER
<input type="checkbox"/>	<a href="#">NPR</a>	I	106-9222	06	001	COVER GP
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">111-6836</a>	08	001	LINES GP-WATER
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">119-6230</a>	05	001	MANIFOLD GP-EXHAUST
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">135-6298</a>	04	001	LINES GP-WATER
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">135-8583</a>	00	001	PULLEY GP-CRANKSHAFT
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">139-9028</a>	02	001	DAMPER & PULLEY GP
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">149-7876</a>	07	001	FASTENER GP-GENERATOR COUPLING
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">151-7794</a>	04	001	MOUNTING GP-ENGINE FLEXIBLE
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">169-0240</a>	04	001	COVER GP-GENERATOR
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">169-0247</a>	14	001	BOX GP-EXTENSION TERMINAL
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">169-0256</a>	07	001	MOUNTING GP-BUS BAR
<input type="checkbox"/>	<a href="#">NPR</a>	I	283-0781	00	170	OIL
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">195-8022</a>	02	001	HARNESS AS-WIRING
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">195-8025</a>	03	001	HARNESS AS-WIRING
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">195-8030</a>	03	001	WIRING GP-ENGINE
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">195-8033</a>	01	001	FASTENER GP-WIRING HARNESS
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">202-1316</a>	06	001	ENGINE AR
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">204-2515</a>	02	001	WIRING GP-GENERATOR
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">207-8040</a>	04	001	BASE GP-ENGINE & GENERATOR
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">208-5385</a>	00	001	MOUNTING GP-ELECTRONIC CONTROL
<input type="checkbox"/>	<a href="#">NPR</a>	I	1W-1340	04	001	MOUNTING GP-ALTERNATOR
<input type="checkbox"/>	<a href="#">NPR</a>	I	5N-0369	06	001	CIRCUIT BREAKER GP
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">204-7439</a>	01	001	LINES GP-ENGINE OIL DRAIN
<input type="checkbox"/>	<a href="#">NPR</a>	SY	<a href="#">2W-7848</a>	01	001	FITTING GP-EXHAUST
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">216-6070</a>	00	001	SWITCH GP-DISCONNECT
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">4W-6328</a>	08	001	PANEL GP-INSTRUMENT
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">202-7402</a>	02	001	CONNECTION GP-GENERATOR LEADS
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">189-6395</a>	01	001	CONNECTION GP-GENERATOR LEADS
<input type="checkbox"/>	<a href="#">NPR</a>	IRY	<a href="#">5N-5692</a>	12	001	ALTERNATOR GP-CHARGING
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">205-7860</a>	08	001	FILM GP
<input type="checkbox"/>	<a href="#">NPR</a>	I	8M-7892	20	001	AMMETER GP
<input type="checkbox"/>		I	3L-0462		001	TEST- GAS GENSET
<input type="checkbox"/>		I	3L-0436		001	CHART-SPECIFICATION
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">198-8793</a>	00	001	SUPPORT GP-BATTERY
<input type="checkbox"/>	<a href="#">NPR</a>	IY	<a href="#">168-3245</a>	01	001	LINES GP-ENGINE OIL DRAIN

	<a href="#">NPR</a>	IY	<a href="#">163-6112</a>	03	001	DRIVE GP-GOVERNOR
	<a href="#">NPR</a>	IY	<a href="#">101-8639</a>	01	001	WIRING GP-ALTERNATOR
		S	5P-2506	00	001	LITERATURE GP
	<a href="#">NPR</a>	I	9Y-6061	05	001	VALVE GP-SOLENOID
	<a href="#">NPR</a>	IY	<a href="#">212-6251</a>	01	001	SHUTOFF GP-ELECTRICAL
	<a href="#">NPR</a>	IY	<a href="#">211-1629</a>	03	001	IGNITION GP-GAS ENGINE
	<a href="#">NPR</a>	IY	<a href="#">208-7866</a>	02	001	PLATE & FILM GP
		I	LE4087	02	001	FAN DRIVE
		I	LE4050	08	001	RADIATOR REMOVAL FOR G3412 TA
	<a href="#">NPR</a>	IY	<a href="#">7E-9051</a>	01	001	GUARD GP-DAMPER
	<a href="#">NPR</a>	IY	<a href="#">221-3040</a>	00	001	GUARD GP-BELT
	<a href="#">NPR</a>	IY	<a href="#">224-0832</a>	02	001	FUMES DISPOSAL GP
		I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
		I	9Y-8164		001	CONTINUOUS POWER APPLICATION
		I	0V-1065		001	END USE: GENERAL EPG
		I	0P-1910		001	STD. GEN SET TEST CHARGE
		I	0V-2319		001	NEW UPS 150KVA 50HZ 400V 4WIRE
		I	306-2768	00	001	GENERATOR AR-SR4B 591 FRAME PM
		I	0V-2330		002	DTO QUOTE CORRECTION
	<a href="#">NPR</a>	ILY	<a href="#">206-5551</a>	01	001	WIRING GP-GENERATOR
		IL	121-4713	00	001	INSTRUCTIONS
	<a href="#">NPR</a>	ILY	<a href="#">169-4450</a>	05	001	HARNESS AS-WIRING
	<a href="#">NPR</a>	IY	<a href="#">247-4217</a>	03	001	REGULATOR GP-VOLTAGE
		I	3L-0456		001	PROCEDURE - DVR PROG AND TEST
	<a href="#">NPR</a>	ILY	<a href="#">230-1352</a>	00	003	TRANSFORMER GP-CURRENT
		IL	208-7482	00	001	TEST - GEN ELE SYS LE
		ILY	<a href="#">136-6633</a>	00	001	GENERATOR AR
	<a href="#">NPR</a>	ILY	<a href="#">183-4729</a>	06	001	COVER GP-ACCESS
		I	9E-5927	01	001	MOUNTING GROUP
	<a href="#">NPR</a>	SY	<a href="#">131-5451</a>	02	001	CONTROL AS-GOVERNOR
		I	0V-8707		001	DTO QUOTE DESIGN FEE
		IL	LE6543	00	001	CURRENT TRANSFORMER SIZING AND
		IL	5Z-3333	00	001	***SPECIAL SETTING REQUEST****
		I	GG9119	00	001	534 BHP 375 GEN KW 60 HZ CONT
		I	0K-6123		001	463 BKW (621 BHP) @ 1800 RPM
						<b>SHIPPED LOOSE</b>
		S			006	
		S	ESO		001	(PRNT ESO COPY)
		S	PML		001	*REQUIRED DECALS
	<a href="#">NPR</a>	S	1B-5357		008	NUT-FULL

<input type="checkbox"/>	<a href="#">NPR</a>	SY	<a href="#">2W-7848</a>	001	FITTING GP-EXHAUST
<input type="checkbox"/>	<a href="#">NPR</a>	S	5L-3773	001	GASKET-EXHAUST ELBOW
<input type="checkbox"/>	<a href="#">NPR</a>	S	5P-5855	008	BOLT-12 POINT HEAD
<input type="checkbox"/>		SY	<a href="#">6L-4502</a>	001	CHART-PLATE & FILM
<input type="checkbox"/>	<a href="#">NPR</a>	SY	<a href="#">131-5451</a>	001	CONTROL AS-GOVERNOR
<input type="checkbox"/>	<a href="#">NPR</a>	S	214-6045	001	BELLOWS AS
<input type="checkbox"/>		S	SEBU6400	001	LUBE
<input type="checkbox"/>		S	SEBU7572	001	OMM
<input type="checkbox"/>		S	SELF5405	001	WARRANTY
<input type="checkbox"/>		S	SERP3444	001	PTSCD