

C-15 INDUSTRIAL ENGINE

Engine Serial Prefix - BEM (Build Date - 05/2001, Test Date - 05/2001, Ship Date - 05/2001)

- ENTIRE GROUP (BEM)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
<input type="checkbox"/>		I	HP00425	F	001	425 BHP (317 BKW) W/O FAN
<input type="checkbox"/>		I	C15DI00	F	001	C-15 DIT ATAAC IND ENGINE
<input type="checkbox"/>		I	EXCCON0	F	001	EXHAUST CONNECTION
<input type="checkbox"/>		I	RAD0004	F	001	RADIATOR STD CAP
<input type="checkbox"/>		I	ALT2439	F	001	CHARGING ALTERNATOR 24V 45 AMP
<input type="checkbox"/>		I	ENGSUP0	F	001	ENGINE SUPPORTS
<input type="checkbox"/>		I	BELTGD1	F	001	BELT GUARD
<input type="checkbox"/>		I	INSPN08	F	001	INSTRUMENT PANEL AND CONTROL
<input type="checkbox"/>		I	FULCOL1	F	001	FUEL COOLER
<input type="checkbox"/>		I	ACLDE01	F	001	AIR CLEANER - DUAL ELEMENT
<input type="checkbox"/>		I	LUBOIL3	F	001	LUBRICATING OIL
<input type="checkbox"/>		I	CGTPS05	F	001	REMOTE SPEED CONT-HAND LEVER
<input type="checkbox"/>		I	GIPDT02	F	001	DIGITAL TACHOMETER
<input type="checkbox"/>		I	VLTM024	F	001	VOLTMETER GAUGE 24V
<input type="checkbox"/>		I	SASETH3	F	001	ETHER STARTING AID
<input type="checkbox"/>		I	AIRSI01	F	001	AIR START SILENCER
<input type="checkbox"/>		I	ASMLH03	F	001	AIR STARTING MOTOR LH
<input type="checkbox"/>		I	CDCCC04	F	001	DRY CHARGE COOLANT CONDITIONER
<input type="checkbox"/>		I	MSINDOE	F	001	INDUSTRIAL
<input type="checkbox"/>		I	DPX0002	F	001	DOMESTIC PACK FOR EXPORT
<input type="checkbox"/>		I	INDUSTR	F	001	APPLICATION
<input type="checkbox"/>		I	CERTIF2	F	001	EPA & CARB TIER II
<input type="checkbox"/>		I	INDUSTA	F	001	INDUSTRIAL CONTINUOUS A RATING
<input type="checkbox"/>		I	2100RPM	F	001	2100 RPM
<input type="checkbox"/>		I	VLT0024	F	001	24 VOLT
<input type="checkbox"/>		I	SUCTION	F	001	SUCTION FAN
						PART NUMBERS
<input type="checkbox"/>		I	PP4784	02	001	425 BHP WOF 2100 RPM IND "A"
<input type="checkbox"/>		I	PA7554	07	001	C-15 DIT-ATAAC IND ENGINE

	NPR	IY	197-1393	02	001	ENGINE AR-CORE
	NPR	IY	4N-5394	12	001	LINES GP-TURBOCHARGER OIL
	NPR	IY	4P-5894	05	001	DAMPER & PULLEY GP
		I	5P-2506	00	001	LITERATURE GP
	NPR	IY	7N-3060	07	001	FLYWHEEL GP
	NPR	IY	9N-3889	03	001	COVER GP-FLYWHEEL HOUSING
	NPR	I	107-4447	02	001	INSTRUCTION-TURBOCHARGER
	NPR	IY	107-6736	01	001	COVER GP-CYLINDER BLOCK
	NPR	IY	107-6737	00	001	COVER GP-CYLINDER BLOCK
	NPR	IY	108-2312	02	001	FITTING GP-QUICK DISCONNECT
	NPR	IY	109-1657	01	001	FASTENER GP-VALVE MECHANISM
	NPR	I	109-4186	01	001	PLATE & FILM GP
	NPR	IY	109-4202	01	001	ELBOW GP-AIR INLET
	NPR	IY	110-1116	02	001	PLUG GP-CYLINDER HEAD
	NPR	IY	111-2088	00	001	LIFTING GP-ENGINE
	NPR	IY	121-0168	02	001	COVER GP-CYLINDER BLOCK
	NPR	I	121-0499	02	001	COVER GP-STORAGE
	NPR	IY	124-0657	01	001	SHIELD GP-MANIFOLD
	NPR	IY	127-0564	00	001	LIFTING GP-ENGINE
	NPR	IY	127-5728	00	001	COVER GP-FLYWHEEL HOUSING
	NPR	IY	134-8201	02	001	WIRING GP-ENGINE
	NPR	IY	135-7634	03	001	HOUSING GP-FLYWHEEL
	NPR	IY	140-9746	00	001	COVER GP-CYLINDER BLOCK
	NPR	IY	141-8953	00	001	FASTENER GP-FUEL LINES
	NPR	IY	145-6851	01	001	PLUG GP-CYLINDER BLOCK
	NPR	IY	150-4279	01	001	PUMP & MTG GP-FUEL TRANSFER
	NPR	IY	151-5366	00	001	FASTENER GP-ENGINE
	NPR	IY	154-4325	01	001	FILTER GP-ENGINE OIL
		IY	159-1598	00	001	PLUG GP-WATER LINES
	NPR	IY	159-9107	02	001	CONNECTION GP-ELECTRICAL
	NPR	IY	159-9362	04	001	FUMES DISPOSAL GP
	NPR	IY	160-8328	00	001	PAN GP-OIL
		IY	160-8329	00	001	FASTENER GP-OIL PAN
	NPR	IY	164-4637	00	001	MANIFOLD GP-EXHAUST
	NPR	IY	171-2094	00	001	FILLER GP-ENGINE OIL
	NPR	IY	180-4367	00	001	FASTENER GP-FRONT COVER

	NPR	IY	186-2377	03	001	HOUSING GP-FRONT
	NPR	IY	187-0673	00	001	GUIDE GP-OIL LEVEL GAUGE
	NPR	IY	187-1328	00	001	COVER GP-VALVE MECHANISM
	NPR	IY	187-8925	01	001	LINES GP-WATER
	NPR	IY	188-2098	01	001	LINES GP-FUEL
	NPR	IY	191-0583	00	001	MANIFOLD GP-FUEL
	NPR	IY	191-5054	00	001	PUMP GP-FUEL PRM & SEC FILTER
	NPR	IY	191-6130	01	001	WIRING GP-ELECTRONIC CONTROL
	NPR	IY	191-6520	01	001	PLUG GP-CYLINDER BLOCK
	NPR	IY	193-1716	00	001	WIRING GP-ELECTRONIC CONTROL
	NPR	IY	194-3967	02	001	MOUNTING GP-SENSOR
	NPR	IY	201-6631	01	001	FITTING GP-FUEL LINES
	NPR	IY	133-5671	02	001	FILTER GP-WATER SEP & FUEL
	NPR	IY	199-8377	00	001	LINES GP-FUEL FILTER
	NPR	IY	200-2852	00	001	FASTENER GP-WATER LINES
	NPR	IY	200-2310	01	001	CONNECTION GP-ELECTRICAL
	NPR	IY	193-1005	00	001	CONNECTION GP-EXHAUST
		I	PA7600	01	001	RADIATOR
	NPR	IY	129-9703	00	001	LINES GP-AIR
	NPR	IY	130-8372	03	001	DRIVE GP-FAN
	NPR	IY	178-7543	02	001	RADIATOR GP
	NPR	IY	193-3953	00	001	COVER GP-FRONT HOUSING
	NPR	IY	193-3957	02	001	TANK GP-EXPANSION
	NPR	IY	4N-3094	08	001	FAN GP-SUCTION
		I	PA6417	04	001	CHARGING ALTERNATOR 24V 45 AMP
	NPR	IRY	5N-5692	12	001	ALTERNATOR GP-CHARGING
	NPR	IY	135-5077	00	001	MOUNTING GP-ALTERNATOR
	NPR	IY	135-6396	00	001	MOUNTING GP-CIRCUIT BREAKER
		I	PA7641	00	001	ENGINE SUPPORTS
	NPR	IY	4N-4286	05	001	SUPPORT GP-ENGINE
	NPR	IY	135-4326	00	001	SUPPORT GP-ENGINE
		I	PA7622	00	001	BELT GUARD
	NPR	IY	194-4616	00	001	GUARD GP-BELT
	NPR	IY	194-4784	00	001	FASTENER GP-BELT GUARD
		I	PA7647	01	001	INSTRUMENT PANEL & CONTROL
	NPR	IY	137-7021	00	001	PLUG GP-INSTRUMENT PANEL

NPR	IY	137-7023	00	001	PLUG GP-INSTRUMENT PANEL
NPR	IY	194-4280	00	001	CONTROL & MTG GP-ENGINE ELEK
NPR	IY	194-4754	00	001	WIRING GP-SENSOR
NPR	IY	198-3801	00	001	MOUNTING GP-INSTRUMENT PANEL
	I	195-0126	01	001	DIAGRAM-WIRING
NPR	IY	195-1348	00	001	COOLER GP-FUEL
NPR	IY	124-3643	03	001	AIR CLEANER GP
	I	0P-9400		001	LUBRICATING OIL
NPR	IY	134-0597	03	001	CONTROL GP-ENGINE SPEED
	I	PA7087	01	001	DIGITAL TACHOMETER
NPR	IY	7C-1072	02	001	TACHOMETER GP-ELECTRIC
NPR	IY	7W-3355	05	001	SENSOR GP-SPEED
	I	PA6544	01	001	VOLTMETER GAUGE - 24 VOLT
NPR	IY	138-3142	00	001	VOLTMETER GP
NPR	IY	143-8872	00	001	STARTING AID GP-ETHER
NPR	IY	138-2544	00	001	SILENCER-AIR STARTING
	I	PA6759	03	001	AIR STARTING MOTOR LH
NPR	IY	136-2641	02	001	STARTING MOTOR GP-AIR
	I	PA7605	00	001	DRY CHARGE COOLANT CONDITIONER
NPR	IY	171-8960	00	001	COOLANT CONDITIONER GP
	I	0V-1085		001	END USE: INDUSTRIAL
	I	0P-1914		001	DOMESTIC PACK FOR EXPORT
	I	PP4784	02	001	425 BHP WOF 2100 RPM IND "A"
	I	0K-2367	00	001	317 KW @ 2100 RPM (425 BHP)
	I	0P-1500		001	0P1500 OEMWHOLESALE PGMPSD0504
					SHIPPED LOOSE
NPR	S	0S-1590		002	BOLT
NPR	S	1A-2029		002	BOLT
NPR	S	1F-7958		004	NUT-FULL
NPR	S	1M-3419		001	SEAL-O-RING
NPR	S	2A-0047		003	WASHER
NPR	S	3B-6552		001	ELBOW-PIPE
NPR	S	3B-6768		001	BUSHING-REDUCER
NPR	S	3E-3360		001	PLUG AS-CONNECTOR
NPR	S	3E-3362		001	WEDGE-PLUG LOCK
NPR	S	3E-5239		001	RELAY AS

NPR	S	3E-6333	001	VALVE AS-SOLENOID
NPR	S	5L-3233	001	FITTING-CONNECTOR
NPR	S	5P-0640	001	WIRE-ELECTRICAL
NPR	S	5P-2948	001	FITTING AS
NPR	S	5P-3860	002	CLAMP-HOSE
NPR	S	5P-8247	003	WASHER-HARD
NPR	S	7B-3235	004	BOLT
NPR	S	7D-1649	008	WASHER-HARD
NPR	S	7E-7100	001	HOSE
NPR	S	7E-8866	004	TERMINAL-BLADE
NPR	S	7N-0140	001	TUBE AS-COIL
NPR	S	7N-0296	001	CYLINDER AS-ETHER
NPR	S	7N-2059	001	CLAMP AS
NPR	S	8N-2694	001	INDICATOR-AIR FILTER CHANGE
NPR	S	8N-3536	001	TUBE-STEEL
NPR	S	8S-6823	001	HOOD AS
NPR	S	8T-8730	002	SOCKET-CONNECTOR
NPR	S	8T-8732	001	RECEPTACLE-CONNECTOR
NPR	S	8T-8737	036	PLUG-SEAL
NPR	S	8T-9834	001	PLUG AS-CONNECTOR
NPR	S	9L-9132	004	WASHER
NPR	S	9W-0844	003	SOCKET-CONNECTOR
NPR	S	9X-3401	003	PIN-CONNECTOR
NPR	S	9X-3402	039	SOCKET-CONNECTOR
NPR	S	9X-8881	003	BOLT
	S	REHS0753	001	WARR REGISTRATION 140010D2(A)
	S	SEBP3261	004	PARTS BOOK 140021C2(A)
	S	SEBU6251	004	LUBE 140019B2(A)
	S	SEBU6984	004	SUPP
	S	SEBU7517	004	OMM 140018G1(A)
	S	SELF5326	004	WARRANTY 140013C2(A)
	S	SMBU6981	004	SUPP
NPR	S	091-0081	002	SPACER
NPR	S	109-0072	001	SEAL-O-RING
NPR	S	113-3155	001	BODY
NPR	S	124-0655	001	BRACKET AS

<input type="checkbox"/>	NPR	S	126-2441	001	BRACKET
<input type="checkbox"/>	NPR	S	127-7443	001	ATOMIZER AS
<input type="checkbox"/>	NPR	S	133-0969	001	CONNECTOR-SOCKET
<input type="checkbox"/>	NPR	SY	134-0597	001	CONTROL GP-ENGINE SPEED
<input type="checkbox"/>	NPR	SY	138-2544	001	SILENCER-AIR STARTING
<input type="checkbox"/>	NPR	S	151-6320	002	TOOL-WIRE REMOVAL
<input type="checkbox"/>	NPR	SY	163-0820	001	AIR CLEANER GP
<input type="checkbox"/>		S+	195-0126	001	DIAGRAM-WIRING

Key:

I Installed

Y Separate Illustration

R REMFG PART MAY BE AVAILABLE

S Shipped Loose