

**AS SHIPPED [HRA]****NOVEMBER 12, 2013**For Help Desk Phone Numbers [Click here](#)

The below option will email full breakdown of the serial number
<input checked="" type="radio"/> Excel <input type="radio"/> PDF
<input type="button" value="FullBreakDown"/>

Sales Model:  
C11

Build Date: 2011-08

**Feature Codes**

Reference Number	Eng Chg	Quantity	ASM LESS	Set Type	Description
C11D11	F	1	I		C11 ACERT ATAAC IND ENGINE 11
FLYHG08	F	1	I		FLY. HSG SAE NO. 1 CAST IRN 08
AIRCP01	F	1	I		AIR COMP - 2 CYL N/F/U/W PTO
FANADB2	F	1	I		BLOWER FAN ADAPTER B2
FNH0482	F	1	I		FAN HEIGHT-482.6 MM (19.00 IN)
ALT2495	F	1	I		CHARGING ALT 24V 95 AMP
ALTPL00	F	1	I		ALT PULLEY 3.69 DIA 2 GROOVE
ALMT01	F	1	I		ALTERNATOR MOUNTING
FLY0006	F	1	I		FLYWHEEL 06
PFFWS04	F	1	S		PRIMARY FF/WATER SEP - SL
ACL9001	F	1	I		AIR CLEANER 01
ELSMLH1	F	1	I		LH ELEC STRT MTR 24V 42MT
OPTDS01	F	1	I		DEEP SUMP OIL PAN-40 L
OLGAG04	F	1	I		LUBRICATION OPTIONS (ADDL)
LUBOIL1	F	1	I		LUBRICATING OIL - 40 LITERS
OILDRN1	F	1	S		OIL PAN DRAIN VALVE
PCL0001	F	1	S		PRECLEANER - AIR CLEANR HOOD
EXCEL01	F	1	S		ELBOW - TURBO OUTLET 90 DEG
EXCAD01	F	1	S		STRAIGHT EXH ADAPTER - 5"
WIRGP01	F	1	I		WIRING GP-ECM INTERCONNECT
CLS0001	F	1	S		COOLANT LEVEL SENSOR
RAD0016	F	1	I		RADIATOR - FRONT EXH
FANPL36	F	1	I		FAN PULLEY 0.800 RATIO
ENGSP03	F	1	I		FRONT ENGINE SUPPORT P3
FANB003	F	1	I		BLOWER FAN 40 IN. - INSTALLED
FUMDIS1	F	1	I		FUMES DISPOSAL
2100RPM	F	1	I		2100 RPM
CGTEPS0	F	1	I		CUST THROTTLE POSITION SENSOR
EXHFRNT	F	1	I		FRONT FACING EXHAUST
INDUSTD	F	1	I		INDUSTRIAL D RATING
INDUSTR	F	1	I		INDUSTRIAL ENGINE
VLT0024	F	1	I		24 VOLT
PBKHCD1	F	1	S		PARTS BOOK-PAPER & ELECTRONIC
LITENGE	F	2	S		EXTRA ENGLISH LITERATURE (1-6)
EUDEDOI	F	1	I		EUROPEAN DIRECTIVE ENGINE DOI

EPAFLEX	F	1	I	OEM EPA ENGINE FLEX LABEL
MSCPB20	F	1	I	COMPLETION STIMULATION
MWCODEA	F	1	I	PRIMARY DRIVE
HP00420	F	1	I	420 BHP (313 BKW) W/O FAN
MSPETDR	F	1	I	PETRO DRILLING
ESCNONE	F	1	I	NO EXTENDED SERVICE COVERAGE
OEM	F	1		OEM
6N6598	F	1	N	OEM

## Part Numbers

Reference Number	Eng Chg	Quantity	ASM LESS	Set Type	Description	BreakDown
PQ1804	00	1	I		C11 ACERT DIT-ATAAC IND ENGINE	<a href="#">BreakDown...</a>
- 3606752	01	1	I		ENGINE AR-CORE	<a href="#">BreakDown...</a>
- 5P2506	00	1	S		LITERATURE - ENGLISH	<a href="#">BreakDown...</a>
- 1138987	04	1	I		COVER GP	<a href="#">BreakDown...</a>
- 1161091	05	1	I		CRANKSHAFT SEAL	<a href="#">BreakDown...</a>
- 1165436	01	1	I		FILTER GROUP-FUEL	<a href="#">BreakDown...</a>
- 1170165	02	1	I		BLOCK PLUG	<a href="#">BreakDown...</a>
- 1172766	07	1	I		DAMPER	<a href="#">BreakDown...</a>
- 1172786	02	1	I		COVER	<a href="#">BreakDown...</a>
- 1382550	01	1	I		MOUNTING - FRONT STUD	<a href="#">BreakDown...</a>
- 1382579	01	1	I		PULLY GROUP	<a href="#">BreakDown...</a>
- 1805168	00	1	I		FASTENER	<a href="#">BreakDown...</a>
- 1899183	02	1	I		COVER	<a href="#">BreakDown...</a>
- 2187272	09	1	I		HOUSING GP-FRONT	<a href="#">BreakDown...</a>
- 2223092	12	1	I		MANIFOLD GP-INTAKE	<a href="#">BreakDown...</a>
- 2233875	04	1	I		PLUG GP	<a href="#">BreakDown...</a>
- 2240880	02	1	I		LIFTING GP	<a href="#">BreakDown...</a>
- 2247662	04	1	I		PLUG GP-OIL COOLER	<a href="#">BreakDown...</a>
- 2275518	02	1	I		PLUG GP	<a href="#">BreakDown...</a>
- 2275723	12	1	I		PUMP GP-F XFR&-C	<a href="#">BreakDown...</a>
- 2279545	03	1	I		PLUG GP	<a href="#">BreakDown...</a>
- 2298084	04	1	I		MTG GP-V MECH	<a href="#">BreakDown...</a>
- 2298437	05	1	I		CONTROL GP - MTG	<a href="#">BreakDown...</a>
- 2304523	12	1	I		COOLER GP-ENG OIL	<a href="#">BreakDown...</a>
- 2313492	03	1	I		FILTER GP - OIL	<a href="#">BreakDown...</a>
- 2386725	04	1	I		LINES GP-WATER	<a href="#">BreakDown...</a>
- 2404815	03	1	I		LINES GP-TURBO O	<a href="#">BreakDown...</a>
- 2448677	02	1	I		FILLER GP - OIL	<a href="#">BreakDown...</a>
- 2479665	02	1	I		BASE GP-O FILTER	<a href="#">BreakDown...</a>
- 2550997	00	1	I		INSTRUCTIONS -Ratings	<a href="#">BreakDown...</a>
- 2559253	01	1	I		FITTING GP	<a href="#">BreakDown...</a>
- 2559254	01	1	I		FITTING GP	<a href="#">BreakDown...</a>
- 2584484	01	1	I		DISPOSAL GP	<a href="#">BreakDown...</a>
- 2624166	02	1	I		PLUG GP	<a href="#">BreakDown...</a>
- 2673476	05	1	I		MANIFOLD GP - EXH	<a href="#">BreakDown...</a>
- 2726657	01	1	I		FITTING GP	<a href="#">BreakDown...</a>

- 2751292	02	1	I	TURBO GP - A	<a href="#">BreakDown...</a>
- 3479741	00	1	I	COVER GP - V MECH	<a href="#">BreakDown...</a>
- 3570524	01	1	I	WIRING GP - CONT	<a href="#">BreakDown...</a>
- 3601589	00	1	I	LINES GP - F FIL	<a href="#">BreakDown...</a>
- 3605376	02	2	I	PAINT GP	<a href="#">BreakDown...</a>
- 3657885	00	1	I	INST - PAINT	<a href="#">BreakDown...</a>
PQ0099	02	1	I	FLYWHEEL HOUSING	<a href="#">BreakDown...</a>
- 9Y9238	05	1	I	FLYWHEEL HOUSING COVER	<a href="#">BreakDown...</a>
- 2644643	02	1	I	HOUSING GP - FLYWHEEL	<a href="#">BreakDown...</a>
- 1275728	01	1	I	COVER	<a href="#">BreakDown...</a>
PQ0558	02	1	I	COMPRESSOR GP-AIR (CAT- 290)	<a href="#">BreakDown...</a>
- 2325186	06	1	I	COMPRESSOR GP	<a href="#">BreakDown...</a>
- 2774857	00	1	I	PLUG GP	<a href="#">BreakDown...</a>
- 2780026	00	1	I	PLUG GP	<a href="#">BreakDown...</a>
1317700	01	1	I	BLOWER FAN ADAPTER	<a href="#">BreakDown...</a>
2653872	00	1	I	INSTRUCTION-FAN	<a href="#">BreakDown...</a>
1978820	01	1	I	ALTERNATOR - GP	<a href="#">BreakDown...</a>
2W8494	01	1	I	ALTERNATOR PULLEY	<a href="#">BreakDown...</a>
2433019	03	1	I	MTG GP - ALT	<a href="#">BreakDown...</a>
PQ0534	02	1	I	FLYWHEEL GP	<a href="#">BreakDown...</a>
- 1556615	01	1	I	FLYWHEEL	<a href="#">BreakDown...</a>
- 1554313	01	1	I	FLYWHEEL FASTENER	<a href="#">BreakDown...</a>
2129431	00	1	S	FILTER AS.	<a href="#">BreakDown...</a>
2433032	04	1	I	CLEANER GP - AIR	<a href="#">BreakDown...</a>
PQ0540	00	1	I	STARTER GROUP	<a href="#">BreakDown...</a>
- 1025836	04	1	I	ELECT. STARTING MOTOR 24V - LH	<a href="#">BreakDown...</a>
PQ0103	03	1	I	PAN GP-OIL (REAR)	<a href="#">BreakDown...</a>
- 2159007	09	1	I	PAN GP - OIL REAR SUMP	<a href="#">BreakDown...</a>
PQ0560	02	1	I	GAGE GP-OIL (LH & RH- REAR)	<a href="#">BreakDown...</a>
- 2701758	03	1	I	GAGE - GP OIL LEVEL	<a href="#">BreakDown...</a>
PQ0529	01	1	I	FACTORY OIL FILL GP	<a href="#">BreakDown...</a>
- 3568341	00	1	I	LUBRICANT GP	<a href="#">BreakDown...</a>
1631383	02	1	S	DRAIN	<a href="#">BreakDown...</a>
2326182	00	1	S	PRECLEANER GP	<a href="#">BreakDown...</a>
1558536	01	1	S	ELBOW	<a href="#">BreakDown...</a>
4W9183	03	1	S	EXHAUST OUTLET PIPE	<a href="#">BreakDown...</a>
PQ0464	01	1	I	WIRING GP	<a href="#">BreakDown...</a>
- 2642357	05	1	I	WIRING GP	<a href="#">BreakDown...</a>
- 2002310	01	1	S	CONNECTION GP	<a href="#">BreakDown...</a>
PA7160	09	1	I	COOLANT LEVEL SENSOR	<a href="#">BreakDown...</a>
- 2399957	02	1	S	SENSOR GP-LEVEL	<a href="#">BreakDown...</a>
PQ1040	00	1	I	RADIATOR GP (FORWARD FACING EX	<a href="#">BreakDown...</a>
- 2864991	03	1	I	RADIATOR GP	<a href="#">BreakDown...</a>
- 2388720	03	1	I	LINES GP - WATER	<a href="#">BreakDown...</a>

- 1283415	03	1	I	FAN DRIVE - MULTI-POSITION	<a href="#">BreakDown...</a>
- 2433023	02	1	I	MTG GP - FAN DRIVE	<a href="#">BreakDown...</a>
- 2865000	01	1	I	LINES GP-AIR	<a href="#">BreakDown...</a>
PQ1043	00	1	I	PULLEY GP-FAN 0.80:1 RATIO	<a href="#">BreakDown...</a>
- 1319141	03	1	I	FAN PULLEY .80:1 RATIO	<a href="#">BreakDown...</a>
- 7M4710	00	1	I	VEE BELT SET.	<a href="#">BreakDown...</a>
PQ1045	00	1	I	FRONT ENGINE SUPPORT	<a href="#">BreakDown...</a>
- 2915524	00	1	I	SUPPORT GP - ENG	<a href="#">BreakDown...</a>
4N3093	09	1	I	BLOWER FAN	<a href="#">BreakDown...</a>
2915530	01	1	I	DISPOSAL GP - FUMES	<a href="#">BreakDown...</a>
0V1766		1	S	PARTS BOOK - PAPER & ELECTRONI	<a href="#">BreakDown...</a>
0P9715		2	S	EXTRA LITERATURE - ENGLISH	<a href="#">BreakDown...</a>
3529856	00	1	I	CERTIFICATION GP (EEC DOI)	<a href="#">BreakDown...</a>
3611891	00	1	I	CERTIFICATION - OEM EPA ENG FL	<a href="#">BreakDown...</a>
PP5389	00	1	I	313 KW (420 BHP) @ 2100 RPM	<a href="#">BreakDown...</a>
- 0K6182		1	I	313 KW @ 2100 RPM (420 BHP)	<a href="#">BreakDown...</a>
0V2787		1	I	END USE: PETRO DRILLING	<a href="#">BreakDown...</a>
6N6598	05	1	N	ADAPTER GP - FAN	<a href="#">BreakDown...</a>

## Ship Loose

Reference Number	Eng	Chg	Quantity	ASM	LESS	Set	Type	Description	BreakDown
5P2506			1				S	LITERATURE GP	<a href="#">BreakDown...</a>
- REHS0753			1				S	WARRANTY DATE RESET140019D2(A)	<a href="#">BreakDown...</a>
SEBU7901			3				S	OMM 1400 3C1(A)	<a href="#">BreakDown...</a>
- SELF5463			1				S	WARRANTY 14007-D2(A)	<a href="#">BreakDown...</a>
- SELF9001			1				S	SUPP 140011C2(A)	<a href="#">BreakDown...</a>
- SERP4127			1				S	PTSCD 140017D1(A)	<a href="#">BreakDown...</a>
2129431			1				S	FILTER AS	<a href="#">BreakDown...</a>
- 2129431			1				S	FILTER AS **SUB** (G)	<a href="#">BreakDown...</a>
1631383			1				S	DRAIN GP-OIL PAN	<a href="#">BreakDown...</a>
- 3E7427			1				S	ADAPTER 1666 1-1(F)	<a href="#">BreakDown...</a>
- 7E4761			1				S	VALVE-SHUTOFF 1650 3-7(F)	<a href="#">BreakDown...</a>
- 8L2786			1				S	SEAL-O RING 1650 3-6(B)	<a href="#">BreakDown...</a>
- 0619458			1				S	SEAL-O-RING 1674 2-7(E)	<a href="#">BreakDown...</a>
2326182			1				S	PRECLEANER GP	<a href="#">BreakDown...</a>
- 1M3419			1				S	SEAL-O-RING 1652 1-1(F)	<a href="#">BreakDown...</a>
- 8S6823			1				S	HOOD AS FL114 (F)	<a href="#">BreakDown...</a>
- 8S6824			1				S	CLAMP AS HUT 3 (F)	<a href="#">BreakDown...</a>
- 1133155			1				S	BODY FL66 (F)	<a href="#">BreakDown...</a>
1558536			1				S	ELBOW GP-EXHAUST	<a href="#">BreakDown...</a>
- 5N4437			1				S	BOOT HUT45 (F)	<a href="#">BreakDown...</a>

- 1558538	1	S	ELBOW FL 81 (F)	<a href="#">BreakDown...</a>
4W9160	2	S	CLAMP-V-BAN HUT 3 (F)	<a href="#">BreakDown...</a>
4W9183	1	S	CONNECTION GP -K	<a href="#">BreakDown...</a>
- 9N1940	1	S	ADAPTER HUT100 (F)	<a href="#">BreakDown...</a>
2002310	1	S	CONNECTION GP -G	<a href="#">BreakDown...</a>
- 8T8732	1	S	RECEPTACLE-CONN 16602-5 (B)	<a href="#">BreakDown...</a>
- 8T8737	36	S	PLUG SEAL 1662 3-2(B)	<a href="#">BreakDown...</a>
- 8T9834	1	S	PLUG AS-CONN HUT 22 (B)	<a href="#">BreakDown...</a>
- 9W0844	3	S	SOCKET-CONNECTOR 16524-10(B)	<a href="#">BreakDown...</a>
- 9X3401	3	S	PIN-CONNECTOR 1652 4-3(F)	<a href="#">BreakDown...</a>
- 9X3402	39	S	SOCKET-CONNECTOR 1652 4-8(F)	<a href="#">BreakDown...</a>
- 1330969	1	S	SOCKET-CONNECTOR 1656 5-8(B)	<a href="#">BreakDown...</a>
- 1516320	2	S	TOOL-REMOVAL 1662 3-9(F)	<a href="#">BreakDown...</a>
2399957	1	S	SENSOR GP-LEVEL	<a href="#">BreakDown...</a>
- 2399957	1	S	SENSOR GP-L HUT 92 (I)	<a href="#">BreakDown...</a>
SEBP4127	3	S	PARTSBOOK 14001C1 (A)	<a href="#">BreakDown...</a>
SEBU6251	3	S	LUBE 140019B2(A)	<a href="#">BreakDown...</a>
6N6598	1	S	ADAPTER-FAN	<a href="#">BreakDown...</a>
- 6N6598	1	S	ADAPTER-FAN S-X (F)	<a href="#">BreakDown...</a>
1662	1	S		<a href="#">BreakDown...</a>
- 1182136	1	S	FILM-MAINT(3176/3196 C-10/C-12)	<a href="#">BreakDown...</a>

Caterpillar Confidential: **Green**

Content Owner: Commercial Processes Division

Web Master(s): [PSG Web Based Systems Support](#)

Current Date: Tuesday, November 12, 2013 12:42:38 PM

© Caterpillar Inc. 2013 All Rights Reserved.

[Data Privacy Statement](#).