

C18 MARINE ENGINE

Engine Serial Prefix - C1J (Build Date - 06/2005, Test Date - 06/2005)

▼ ENGINE - ENTIRE GROUP (C1J)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						<b>FEATURE CODES</b>
		I	C18DM16	F	001	C18 DITA MAR PROP - PORT
		I	ELSMRH1	F	001	ELEC START MTR 24V
		I	PFF0005	F	001	PRIMARY FUEL FIL/WATER SEP
		I	CHE0020	F	001	HEAT EXCHANGER - FUEL COOLED
		I	AMM2401	F	001	AMMETER GAUGE 24 V
		I	ALT2412	F	001	CHARGING ALT 24V 60 AMP
		I	EXCFF01	F	001	FLEXIBLE FITTING
		I	EXCDE01	F	001	DRY ELBOW
		I	PHIP003	F	001	PILOT HOUSE INSTRUMENT PANEL
		I	PNLIGN2	F	001	PANEL AS-IGNITION 02
		I	GIPDT01	F	001	DIGITAL TACHOMETER
		I	DGTMT01	F	001	DIGITAL TACH MTG GP
		I	GIPMPU1	F	001	MAGNETIC PICKUP
		I	SMPPMP2	F	001	MANUAL SUMP PUMP - RH
		I	DAMPGD0	F	001	DAMPER GUARD
		I	CGTPS03	F	001	ROTARY SENSOR CONTROL
		I	VLT0024	F	001	24 VOLT
		I	PBKCD01	F	001	PARTS BOOK-ELECTRONIC
		I	LWPENG1	F	001	ENGINE PROTECTIVE COVER
		I	COMMCTY	F	001	COMMERCIAL CAT YELLOW
		I	MSCMA11	F	001	FISHING
		I	MWCODEA	F	001	PRIMARY DRIVE
		I	HPM0608	F	001	608 MHP (447.5 BKW) W/O FAN
		I	MSMARPR	F	001	MARINE PROPULSION COMMERCIAL
		I	DPX0002	F	001	DOMESTIC PACK FOR EXPORT
		I	CSTHEXC	F	001	HEAT EXCHANGER COOLED
		I	MARCOMM	F	001	COMMERCIAL
		I	MARINEB	F	001	MARINE HEAVY DUTY B RATING
		I	MARPROP	F	001	MARINE PROPULSION ENGINE
		I	PORTSID	F	001	PORT SIDE
		I	SINGENG	F	001	SINGLE ENGINE INSTALLATION
		I	COMMFIN	F	001	COMMERCIAL FINISH
		I	IMANONE	F	001	NO IMO ABS ENGINE CERT

	I	IMONONE	F	001	NO IMO ENGINE CERTIFICATIONS
	I	TVANONE	F	001	TVANONE
					<b>PART NUMBERS</b>
	I	PQ0223		03 001	C18 DITA MARINE HEAT EXC (RH)
<a href="#">NPR</a>	IY	<a href="#">241-9635</a>		03 001	ENGINE AR-CORE
<a href="#">NPR</a>	IY	<a href="#">7N-3060</a>		07 001	FLYWHEEL GP
<a href="#">NPR</a>	IY	<a href="#">102-9220</a>		02 001	RECOVERY GP-COOLANT
<a href="#">NPR</a>	IY	<a href="#">107-6737</a>		01 001	COVER GP-CYLINDER BLOCK
<a href="#">NPR</a>	I	234-9776		01 001	PLUG GP-ENGINE
<a href="#">NPR</a>	IY	<a href="#">127-0564</a>		00 001	LIFTING GP-ENGINE
<a href="#">NPR</a>	IY	<a href="#">120-9847</a>		00 001	COVER GP-FRONT HOUSING
<a href="#">NPR</a>	IY	<a href="#">124-3388</a>		01 001	SUPPORT GP-ENGINE
<a href="#">NPR</a>	IY	<a href="#">124-6328</a>		01 001	LIFTING GP-ENGINE
<a href="#">NPR</a>	IY	<a href="#">126-5052</a>		04 001	MANIFOLD GP-EXHAUST
<a href="#">NPR</a>	IY	<a href="#">130-6521</a>		06 001	LINES GP-AIR
<a href="#">NPR</a>	IY	<a href="#">131-8270</a>		04 001	PUMP GP-FUEL TRANSFER
<a href="#">NPR</a>	I	134-4462		03 001	PLATE & FILM GP
<a href="#">NPR</a>	IY	<a href="#">140-6330</a>		00 001	FITTING GP-OIL PAN
<a href="#">NPR</a>	IY	<a href="#">140-9746</a>		00 001	COVER GP-CYLINDER BLOCK
<a href="#">NPR</a>	IY	<a href="#">153-9084</a>		00 001	LINES GP-FLEXIBLE FUEL
<a href="#">NPR</a>	IY	<a href="#">159-6159</a>		05 001	COVER GP-FRONT HOUSING
<a href="#">NPR</a>	IY	<a href="#">174-5986</a>		00 001	PUMP GP-WATER
<a href="#">NPR</a>	IY	<a href="#">241-4187</a>		00 001	FILTER GP-ENGINE OIL
<a href="#">NPR</a>	IY	<a href="#">187-3316</a>		00 001	COVER GP-VALVE MECHANISM
<a href="#">NPR</a>	IY	<a href="#">240-9016</a>		01 001	CONTROL & MTG GP-ENGINE ELEK
<a href="#">NPR</a>	IY	<a href="#">194-2450</a>		05 001	PUMP GP-AUXILIARY SEA WATER
<a href="#">NPR</a>	IY	<a href="#">212-1404</a>		01 001	MOUNTING GP-SENSOR
<a href="#">NPR</a>	IY	<a href="#">196-9223</a>		03 001	LINES GP-WATER
<a href="#">NPR</a>	IY	<a href="#">198-3433</a>		08 001	AFTERCOOLER GP-RAW WATER
<a href="#">NPR</a>	IY	<a href="#">228-1644</a>		03 001	PAN GP-OIL
<a href="#">NPR</a>	IY	<a href="#">131-8298</a>		01 001	MOUNTING GP-CONTROL
<a href="#">NPR</a>	IY	<a href="#">201-1400</a>		03 001	LINES GP-WATER
<a href="#">NPR</a>	IY	<a href="#">201-2067</a>		03 001	GAUGE GP-OIL LEVEL (DIPSTICK)
<a href="#">NPR</a>	IY	<a href="#">201-8358</a>		00 001	FASTENER GP-FRONT HOUSING
<a href="#">NPR</a>	IY	<a href="#">202-2085</a>		06 001	WIRING GP-ENGINE
<a href="#">NPR</a>	IY	<a href="#">244-5850</a>		00 001	WIRING GP-ELECTRONIC CONTROL
<a href="#">NPR</a>	IY	<a href="#">202-9646</a>		00 001	FILLER GP-ENGINE OIL
<a href="#">NPR</a>	IY	<a href="#">203-0100</a>		00 001	FILTER GP-FUEL
<a href="#">NPR</a>	IY	<a href="#">240-7051</a>		01 001	PLUG GP-CYLINDER BLOCK
<a href="#">NPR</a>	IY	<a href="#">203-4624</a>		02 001	CONTROL GP-AUTO START/STOP

	<a href="#">NPR</a>	IY	<a href="#">203-9031</a>	01	001	PLUG GP-CYLINDER BLOCK
	<a href="#">NPR</a>	IY	<a href="#">196-0220</a>	01	001	LINES GP-TURBOCHARGER OIL
	<a href="#">NPR</a>	IY	<a href="#">195-4722</a>	02	001	LINES GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">201-1270</a>	06	001	AIR CLEANER GP
	<a href="#">NPR</a>	IY	<a href="#">206-1211</a>	03	001	HOUSING GP-FRONT
	<a href="#">NPR</a>	I	234-6125	00	001	PRESERVATION GP
	<a href="#">NPR</a>	IY	<a href="#">198-1295</a>	01	001	HOUSING GP-FLYWHEEL
	<a href="#">NPR</a>	IY	<a href="#">224-2382</a>	00	001	LINES GP-AFTERCOOLER DRAIN
	<a href="#">NPR</a>	IY	<a href="#">9N-3889</a>	03	001	COVER GP-FLYWHEEL HOUSING
	<a href="#">NPR</a>	IY	<a href="#">235-2387</a>	00	001	PLUG GP-CYLINDER BLOCK
	<a href="#">NPR</a>	IY	<a href="#">209-2786</a>	04	001	DAMPER & PULLEY GP
	<a href="#">NPR</a>	IY	<a href="#">234-9222</a>	01	001	PLUG GP-CYLINDER BLOCK
	<a href="#">NPR</a>	IY	<a href="#">234-9219</a>	01	001	PLUG GP-CYLINDER HEAD
	<a href="#">NPR</a>	IY	<a href="#">109-1223</a>	00	001	COVER GP-CYLINDER BLOCK
	<a href="#">NPR</a>	IY	<a href="#">246-0709</a>	01	001	PLUG GP-ENGINE
	<a href="#">NPR</a>	IY	<a href="#">131-3401</a>	03	001	STARTING MOTOR GP-ELECTRIC
	<a href="#">NPR</a>	IY	<a href="#">130-2960</a>	00	001	FILTER GP-FUEL
		I	PA7385	01	001	HEAT EXCHANGER - FUEL COOLED
	<a href="#">NPR</a>	IY	<a href="#">201-6757</a>	03	001	HEAT EXCHANGER GP-SEA WATER
	<a href="#">NPR</a>	IY	<a href="#">199-3154</a>	12	001	LINES GP-FUEL
	<a href="#">NPR</a>	IY	<a href="#">8M-7892</a>	18	001	AMMETER GP
		I	PA7836	02	001	ALTERNATOR GP-CHARGING-24V 60A
	<a href="#">NPR</a>	IY	<a href="#">4N-3986</a>	15	001	ALTERNATOR GP-CHARGING
	<a href="#">NPR</a>	IY	<a href="#">141-6175</a>	02	001	CIRCUIT BREAKER GP
	<a href="#">NPR</a>	IY	<a href="#">253-5677</a>	00	001	MOUNTING GP-ALTERNATOR
	<a href="#">NPR</a>	IY	<a href="#">2W-7847</a>	00	001	FITTING GP-EXHAUST
	<a href="#">NPR</a>	IY	<a href="#">6N-6093</a>	04	001	ELBOW GP-EXHAUST
		I	PA6591	03	001	PILOT HOUSE INSTRUMENT PANEL
	<a href="#">NPR</a>	I	100-3055	04	001	SENSOR GP-TEMPERATURE
	<a href="#">NPR</a>	I	117-9015	03	001	MODULE GP-QUAD GAUGE
	<a href="#">NPR</a>	IY	<a href="#">121-4017</a>	04	001	HARNES AS-WIRING
	<a href="#">NPR</a>	I	131-0209	02	001	CONTROL GP-MONITOR
	<a href="#">NPR</a>	I	144-0890	01	001	MODULE GP-SPEEDOMETER & TACH
	<a href="#">NPR</a>	IY	<a href="#">161-9932</a>	05	001	SENSOR GP-PRESSURE
	<a href="#">NPR</a>	I	118-5075	01	001	LAMP
		I	PA7865	06	001	PANEL AS-IGNITION
	<a href="#">NPR</a>	IY	<a href="#">217-3865</a>	00	001	PANEL GP-CONTROL
	<a href="#">NPR</a>	IY	<a href="#">7C-1072</a>	02	001	TACHOMETER GP-ELECTRIC
	<a href="#">NPR</a>	IY	<a href="#">7L-4535</a>	09	001	MOUNTING GP-TACHOMETER
	<a href="#">NPR</a>	IY	<a href="#">5N-8757</a>	07	001	SENSOR GP-SPEED

		I	PA7857	00	001	PUMP GP-SUMP
	<a href="#">NPR</a>	IY	<a href="#">200-3123</a>	03	001	PUMP GP-SUMP
	<a href="#">NPR</a>	IY	<a href="#">254-6039</a>	00	001	GUARD GP-DAMPER
	<a href="#">NPR</a>	IY	<a href="#">9X-9647</a>	01	001	SENSOR GP-POSITION
		I	0V-1767		001	PARTS BOOK - ELECTRONIC
		I	0V-1983		001	ENGINE PROTECTIVE COVER 3406
		I	PQ0353	00	001	COMMERCIAL FINISH - CAT YELLOW
		I	5N-6957	01	001	LITERATURE GP
		I	PP5230	00	001	608 MHP WOF 1800 RPM MAR "B"
		I	0K-5618		001	447.5 BKW (600 BHP) @ 1800 RPM
		I	0V-1045		001	MARINE PROPULSION COMMERCIAL
		I	0P-1914		001	DOMESTIC PACK FOR EXPORT
						<b>SHIPPED LOOSE</b>
	<a href="#">NPR</a>	S	0T-0102		004	BOLT
	<a href="#">NPR</a>	S	1B-5358		004	NUT-FULL
	<a href="#">NPR</a>	S	1P-4278		002	CLAMP-HOSE
	<a href="#">NPR</a>	S	1W-2194		001	COVER-EXHAUST ELBOW
	<a href="#">NPR</a>	S	1W-8914		001	AMMETER AS
	<a href="#">NPR</a>	S	3J-5389		002	PLUG
	<a href="#">NPR</a>	S	3N-3017		001	ADAPTER AS
	<a href="#">NPR</a>	S	4N-3955		001	GASKET
	<a href="#">NPR</a>	S	4N-4967		001	ELBOW-EXHAUST
	<a href="#">NPR</a>	S	5H-8331		001	GASKET
	<a href="#">NPR</a>	S	5K-0906		002	BOLT
	<a href="#">NPR</a>	SY	<a href="#">5N-8757</a>		001	SENSOR GP-SPEED
	<a href="#">NPR</a>	S	5P-8247		008	WASHER-HARD
	<a href="#">NPR</a>	S	6N-0561		004	CLIP
	<a href="#">NPR</a>	S	6V-3507		001	SEAL-RECTANGULAR
	<a href="#">NPR</a>	S	6V-5048		006	SEAL-O-RING
	<a href="#">NPR</a>	S	6V-8189		002	NUT
	<a href="#">NPR</a>	S	7L-4536		001	BRACKET-TACHOMETER
	<a href="#">NPR</a>	S	8C-3681		001	HOSE
	<a href="#">NPR</a>	S	8L-3282		001	CONNECTOR
	<a href="#">NPR</a>	S	8S-9092		004	BOLT
	<a href="#">NPR</a>	S	8T-4224		002	WASHER-HARD
	<a href="#">NPR</a>	S	9S-8002		006	PLUG-O-RING
	<a href="#">NPR</a>	SY	<a href="#">9X-9647</a>		001	SENSOR GP-POSITION
		S	SEBP4018		001	PTSBK 1400 (A)
		S	SERP4018		001	PTSCD 1400 (A)
		S	SSBU7689		001	OMM 1400 (A)

<input type="checkbox"/>	<a href="#">NPR</a>	S	100-3055	001	SENSOR GP-TEMPERATURE
<input type="checkbox"/>	<a href="#">NPR</a>	S	102-9223	001	TANK GP-COOLANT
<input type="checkbox"/>	<a href="#">NPR</a>	S	116-2578	001	HOSE AS
<input type="checkbox"/>	<a href="#">NPR</a>	S	117-9015	001	MODULE GP-QUAD GAUGE
<input type="checkbox"/>	<a href="#">NPR</a>	S	118-0280	001	COUPLING
<input type="checkbox"/>	<a href="#">NPR</a>	S	118-5075	004	LAMP
<input type="checkbox"/>	<a href="#">NPR</a>	SY	<a href="#">121-4017</a>	001	HARNESS AS-WIRING
<input type="checkbox"/>	<a href="#">NPR</a>	S	127-0291	001	BASE AS
<input type="checkbox"/>	<a href="#">NPR</a>	S	129-0372	001	FILTER AS-WATER SEP & FUEL
<input type="checkbox"/>	<a href="#">NPR</a>	S	131-0209	001	CONTROL GP-MONITOR
<input type="checkbox"/>	<a href="#">NPR</a>	S	144-0890	001	MODULE GP-SPEEDOMETER & TACH
<input type="checkbox"/>	<a href="#">NPR</a>	S	153-9085	001	HOSE AS
<input type="checkbox"/>	<a href="#">NPR</a>	SY	<a href="#">161-9932</a>	001	SENSOR GP-PRESSURE
<input type="checkbox"/>	<a href="#">NPR</a>	S	197-7348	001	TACHOMETER GP
<input type="checkbox"/>	<a href="#">NPR</a>	SY	<a href="#">217-3865</a>	001	PANEL GP-CONTROL