

C18 INDUSTRIAL ENGINE

Engine Serial Prefix - WJH (Build Date - 09/2010, Test Date - 10/2010)

[View Latest Kit Information](#)

▼ ENGINE - ENTIRE GROUP (WJH)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	C18DI02	F	001	C18 DIT-ATAAC IND ENGINE 02
		I	FLYHG11	F	001	FLYWHEEL HOUSING SAE NO. 1
		I	PFFWS02	F	001	PR FUEL FILTER/WATER SEP
		I	AIRLG06	F	002	AIR LINES-90 DEG
		I	ALT2495	F	001	CHARGING ALT 24V 95 AMP
		I	ALMT03	F	001	ALTERNATOR MOUNTING RH 03
		I	FDV0013	F	001	FAN DRIVE 0.940 RATIO 13
		S	AIRLG08	F	005	AFTCLR LINES AIRLG08_S (1-4)
		I	FLY0010	F	001	FLYWHEEL - SAE NO. 1 10
		I	FRSUP05	F	001	FRONT ENGINE SUPPORT-NARROW
		I	ELSML11	F	001	ELEC START MTR LH 24V 11
		I	OSPENG1	F	001	OVERSEAS PRESERVATION 02
		S	SASETH5	F	001	ETHER STARTING AID 24V SL
		I	HPDR002	F	001	HYDRAULIC PUMP DRIVE
		I	FNH0482	F	001	FAN HEIGHT-482.6 MM (19.00 IN)
		I	2100RPM	F	001	2100 RPM
		I	CGTOTHR	F	001	THROTTLE POSITION SENSOR-OTHER
		I	INDUSTC	F	001	INDUST INTERMITTENT C RATING
		I	INDUSTR	F	001	INDUSTRIAL ENGINE
		I	NOBRAKE	F	001	NO COMPRESSION BRAKE
		I	VLT0024	F	001	24 VOLT
		S	PBKHCD1	F	001	PARTS BOOK-PAPER & ELEC
		S	LITENGE	F	001	EXTRA ENGLISH LITERATURE (1-6)
		S	LITGERE	F	001	EXTRA GERMAN LITERATURE(1-6)
		I	CERTIF5	F	001	EPA/CARB TIER 3, EC STG IIIA
		I	EUDEDOI	F	001	EUROPEAN DIRECTIVE ENGINE DOI

	I	MSCIK12	F	001	BORE/DRILL RIGS (NON-MINING)
	I	MWCODEA	F	001	PRIMARY DRIVE
	I	HP00700	F	001	700 BHP (522 BKW) W/O FAN
	I	MSINDOE	F	001	INDUSTRIAL/OEM
	I	DPX0002	F	001	DOMESTIC PACK FOR EXPORT
	I	ESCNONE	F	001	NO EXTENDED SERVICE COVERAGE
					PART NUMBERS
	I	PQ0094	22	001	ENGINE AR-C18 DIT ATAAC
	NPR	IY 241-0021	09	001	ENGINE AR-CORE
	NPR	IY 237-4286	02	001	DAMPER & PULLEY GP
	S	5P-2506	00	001	LITERATURE GP
	NPR	I 107-4447	03	001	INSTRUCTION-TURBOCHARGER
	NPR	IY 107-6737	01	001	COVER GP-CYLINDER BLOCK
	NPR	IY 108-2312	04	001	FITTING GP-QUICK DISCONNECT
	NPR	IY 109-1657	06	001	FASTENER GP-VALVE MECHANISM
	NPR	IY 109-3287	10	001	PAN GP-OIL
	NPR	IY 109-3290	02	001	FASTENER GP-OIL PAN
	NPR	IY 255-9250	03	001	PLUG GP-WATER LINES
	NPR	IY 109-2373	02	001	FASTENER GP-WATER PUMP
	NPR	IY 109-4202	06	001	ELBOW GP-AIR INLET
	NPR	IY 111-2088	01	001	LIFTING GP-ENGINE
	NPR	IY 359-0920	01	001	WIRING GP-ELECTRONIC CONTROL
	NPR	IY 358-8534	00	001	LINES GP-FUEL FILTER
	NPR	IY 362-9031	00	001	SPACER GP-BLOCK
	NPR	I 359-0901	00	001	GAUGE GP-OIL LEVEL (DIPSTICK)
	NPR	I 260-1545	02	001	COVER GP
	NPR	IY 127-0564	01	001	LIFTING GP-ENGINE
	NPR	IY 150-4279	08	001	PUMP & MTG GP-FUEL TRANSFER
	NPR	IY 255-9251	02	001	PLUG GP-WATER LINES
	NPR	IY 159-6159	07	001	COVER GP-FRONT HOUSING
	NPR	IY 192-0772	04	001	MANIFOLD GP-EXHAUST
	NPR	IY 171-2094	01	001	FILLER GP-ENGINE OIL
	NPR	IY 172-7120	01	001	FASTENER GP-ENGINE
	NPR	IY 269-2509	03	001	HOUSING GP-FRONT
	NPR	IY 222-4412	01	001	COVER GP-VALVE MECHANISM
	NPR	IY 255-9246	05	001	LINES GP-WATER

	NPR	IY	191-0583	00	001	MANIFOLD GP-FUEL
	NPR	IY	191-5054	02	001	PUMP GP-FUEL PRM & SEC FILTER
	NPR	IY	236-1780	03	001	CONTROL & MTG GP-ENGINE ELEK
	NPR	IY	194-3967	03	001	MOUNTING GP-SENSOR
	NPR	SY	240-6054	02	001	CONNECTION GP-ELECTRICAL
	NPR	IY	200-2852	00	001	FASTENER GP-WATER LINES
	NPR	IY	201-6631	02	001	FITTING GP-FUEL LINES
	NPR	IY	234-9184	01	001	PLUG GP-CYLINDER HEAD
	NPR	IY	234-9706	02	001	PLUG GP-CYLINDER BLOCK
	NPR	IY	234-9776	03	001	PLUG GP-ENGINE
	NPR	IY	227-9495	01	001	SUPPORT GP-ENGINE
	NPR	IY	229-9965	00	001	FASTENER GP-FRONT HOUSING
	NPR	IY	229-9966	00	001	FASTENER GP-FRONT HOUSING
	NPR	IY	238-9384	01	001	FASTENER GP-WIRING HARNESS
		I	255-4219	00	001	INSTRUCTIONS
	NPR	IY	232-1829	04	001	LINES GP-EXHAUST
	NPR	IY	260-1550	03	001	LINES GP-TURBOCHARGER OIL
	NPR	IY	266-0050	01	001	PLUG GP-CYLINDER BLOCK
	NPR	IY	212-2765	04	001	FUMES DISPOSAL GP
	NPR	I	211-4834	03	001	PLATE & FILM GP
	NPR	IY	268-6625	02	001	FILTER GP-ENGINE OIL
	NPR	IY	255-9248	00	001	FASTENER GP-WATER PUMP
	NPR	IY	255-9252	02	001	PLUG GP-WATER LINES
	NPR	IY	286-9120	00	001	FASTENER GP-WIRING HARNESS
	NPR	IY	282-6846	00	001	FASTENER GP-FRONT COVER
	NPR	IY	285-8628	00	001	FASTENER GP-FRONT COVER
	NPR	IY	180-4367	01	001	FASTENER GP-FRONT COVER
	NPR	IY	311-1441	01	001	PLUG GP-WATER LINES
		I	PQ0198	03	001	HOUSING GP-FLYWHEEL-SAE #1
	NPR	IY	141-8953	01	001	FASTENER GP-FUEL LINES
	NPR	IY	135-7634	06	001	HOUSING GP-FLYWHEEL
	NPR	IY	9N-3889	05	001	COVER GP-FLYWHEEL HOUSING
	NPR	IY	127-5728	01	001	COVER GP-FLYWHEEL HOUSING
	NPR	I	204-5325	02	001	COVER GP-SHIPPING
	NPR	IY	135-8015	01	001	PLUG GP-FLYWHEEL HOUSING
		I	PQ0207	03	001	PRIMARY FUEL FILTER / WATER SE

	IY	212-9431	00	001	FILTER GP-WATER SEP & FUEL
NPR	IY	237-4290	03	001	LINES GP-FUEL FILTER
NPR	IY	126-0081	03	002	LINES GP-AIR
NPR	IRY	197-8820	01	001	ALTERNATOR GP-CHARGING
	I	PQ0212	07	001	ALTERNATOR MOUNTING RH
NPR	IY	118-3419	05	001	MOUNTING GP-ALTERNATOR
	I	PA6451	03	001	FAN DRIVE 0.940 RATIO 13
NPR	IY	120-4230	04	001	DRIVE GP-FAN
NPR	SY	184-5367	00	005	LINES GP-AIR
NPR	IY	7N-3060	08	001	FLYWHEEL GP
	I	PQ0444	01	001	FRONT ENGINE SUPPORT
NPR	IY	244-8681	01	001	SUPPORT GP-ENGINE
	I	PA6446	02	001	ELECTRIC STARTING MOTOR 24V LH
NPR	IY	120-9100	04	001	STARTING MOTOR GP-ELECTRIC
	I	305-7985	00	001	PRESERVATION GP
NPR	SY	260-3934	03	001	STARTING AID GP-ETHER
	I	PQ0571	00	001	HYDRAULIC PUMP DRIVE
NPR	IY	262-2765	04	001	DRIVE GP-ACCESSORY
	I	283-1605	00	001	INSTRUCTIONS
	S	0V-1766		001	PARTS BOOK - PAPER & ELECTRONI
	S	0P-9715		001	EXTRA LITERATURE - ENGLISH
	S	0P-1524		001	EXTRA LITERATURE - GERMAN
NPR	I	350-8622	00	001	CERTIFICATION AR
	I	352-9856	00	001	PLATE & FILM GP
	I	PP5949	01	001	700 BHP (522 BKW) WOF 2100 RPM
	I	0K-9419	00	001	522 KW (700 BHP) @ 2100 RPM
	I	0V-1085		001	END USE: INDUSTRIAL/OEM
	I	0P-1914		001	DOMESTIC PACK FOR EXPORT
					SHIPPED LOOSE
NPR	S	2V-1713		001	TAG-NOTICE
NPR	S	3B-6768		001	BUSHING-REDUCER
NPR	S	5P-0640		001	WIRE-ELECTRICAL
NPR	S	5P-9074		001	WIRE-ELECTRICAL
NPR	S	7C-2644		001	CLIP
NPR	S	7E-8630		005	HOSE-AIR INLET
NPR	S	7N-0140		001	TUBE AS-COIL

<input type="checkbox"/>	NPR	S	7N-2059	001	CLAMP AS
<input type="checkbox"/>	NPR	S	8C-3334	002	RIVET-TUBULAR
<input type="checkbox"/>	NPR	S	8C-6354	001	CAP-RECEPTACLE
<input type="checkbox"/>	NPR	S	8N-3536	001	TUBE-STEEL
<input type="checkbox"/>	NPR	S	8T-8730	002	SOCKET-CONNECTOR
<input type="checkbox"/>	NPR	S	8T-8732	001	RECEPTACLE-CONNECTOR
<input type="checkbox"/>	NPR	S	8T-8736	001	RECEPTACLE-CONNECTOR
<input type="checkbox"/>	NPR	S	8T-8737	068	PLUG-SEAL
<input type="checkbox"/>	NPR	S	9W-0844	003	SOCKET-CONNECTOR
<input type="checkbox"/>	NPR	S	9W-0852	002	PIN-CONNECTOR
<input type="checkbox"/>	NPR	S	9X-2201	020	CLAMP-HOSE
<input type="checkbox"/>		S	REHS0753	001	WARRANTY DATE RESET140019D2(A)
<input type="checkbox"/>		S	SEBP3816	002	PTSBK 1400 (A)
<input type="checkbox"/>		S	SEBU6251	002	LUBE 140019B2(A)
<input type="checkbox"/>		S	SEBU7899	002	OMM 1400 (A)
<input type="checkbox"/>		S	SELF5457	001	WARRANTY
<input type="checkbox"/>		S	SELF9001	001	SUPP 1400 (A)
<input type="checkbox"/>		S	SERP3816	002	PTSCD 1400 (A)
<input type="checkbox"/>		S	SGBU7899	001	OMM 1400 (A)
<input type="checkbox"/>	NPR	S	127-7443	001	ATOMIZER AS
<input type="checkbox"/>	NPR	S	133-0967	001	PIN-CONNECTOR
<input type="checkbox"/>	NPR	S	133-0969	001	CONNECTOR-SOCKET
<input type="checkbox"/>	NPR	S	151-6320	002	TOOL-WIRE REMOVAL
<input type="checkbox"/>	NPR	S	155-2261	001	WEDGE-PLUG LOCK
<input type="checkbox"/>	NPR	S	155-2269	001	PLUG AS-CONNECTOR
<input type="checkbox"/>	NPR	S	160-7689	001	PLUG AS-CONNECTOR
<input type="checkbox"/>	NPR	S	180-9339	007	PIN-CONNECTOR
<input type="checkbox"/>	NPR	S	180-9340	069	SOCKET-CONNECTOR
<input type="checkbox"/>	NPR	S	230-1434	001	FITTING AS
<input type="checkbox"/>	NPR	SY	239-1134	001	VALVE GP-ETHER STARTING

Key:

I Installed

S Shipped Loose

Y Separate Illustration

R REMFG PART MAY BE AVAILABLE