

3456 GEN SET ENGINE

Engine Serial Number - 9BZ (Build Date - 10/2004, Test Date - 10/2004)

▼ ENGINE - ENTIRE GROUP (9BZ)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						PART NUMBERS
<input type="checkbox"/>	NPR	IY	235-1571	03	001	ENGINE AR
<input type="checkbox"/>	NPR	IY	167-8098	05	001	WIRING GP-ENGINE
<input type="checkbox"/>	NPR	IY	185-7209	00	001	FASTENER GP-COUPLING
<input type="checkbox"/>	NPR	IY	114-1906	02	001	LINES GP-AIR
<input type="checkbox"/>	NPR	IY	172-8660	01	001	SWITCH GP-LIQUID LEVEL
<input type="checkbox"/>	NPR	IY	165-6634	02	001	SENSOR GP-COOLANT LEVEL
<input type="checkbox"/>	NPR	IY	171-5281	02	001	COOLER GP-FUEL
<input type="checkbox"/>	NPR	IY	172-0066	03	001	PANEL GP-INSTRUMENT
<input type="checkbox"/>	NPR	IY	167-8099	01	001	MOUNTING GP-ENGINE & GENERATOR
<input type="checkbox"/>	NPR	IY	236-8836	00	002	HOSE-VENTING
<input type="checkbox"/>		I	0V-1065		001	0V1065 ENDUSE:GENERAL EPG
						SHIPPED LOOSE
<input type="checkbox"/>	NPR	S	0L-1352		004	BOLT
<input type="checkbox"/>	NPR	S	0S-1585		002	BOLT
<input type="checkbox"/>	NPR	S	0S-1594		002	BOLT
<input type="checkbox"/>	NPR	S	0T-0102		004	BOLT
<input type="checkbox"/>	NPR	S	1D-4585		006	BOLT
<input type="checkbox"/>	NPR	S	2J-3506		008	NUT-FULL
<input type="checkbox"/>	NPR	S	3J-7314		001	HOSE AS
<input type="checkbox"/>	NPR	S	3S-2093		017	STRAP-CABLE
<input type="checkbox"/>	NPR	S	3T-9693		002	HOSE AS
<input type="checkbox"/>	NPR	S	4F-3714		008	WASHER
<input type="checkbox"/>	NPR	S	4P-7582		002	CLIP
<input type="checkbox"/>	NPR	S	5H-7704		002	SEAL-O-RING
<input type="checkbox"/>	NPR	S	5M-2894		006	WASHER-HARD
<input type="checkbox"/>	NPR	S	5P-8245		016	WASHER-HARD
<input type="checkbox"/>	NPR	S	5P-8247		006	WASHER-HARD
<input type="checkbox"/>	NPR	S	5P-8248		008	WASHER-HARD
<input type="checkbox"/>	NPR	S	6F-7316		002	BOLT
<input type="checkbox"/>	NPR	S	6K-1330		004	BOLT
<input type="checkbox"/>	NPR	S	7W-3144		001	ELBOW
<input type="checkbox"/>	NPR	S	7W-3145		002	PLATE
<input type="checkbox"/>	NPR	S	8M-0547		001	ELBOW-FLARED

<input type="checkbox"/>	NPR	S	8N-9142	001	HOSE AS
<input type="checkbox"/>	NPR	S	8T-4122	002	WASHER-HARD
<input type="checkbox"/>	NPR	S	8T-6757	001	PLUG-PIPE
<input type="checkbox"/>	NPR	S	9S-1366	014	BOLT
<input type="checkbox"/>	NPR	S	9W-6582	004	SLEEVE
<input type="checkbox"/>	NPR	S	9W-6584	004	WASHER
<input type="checkbox"/>	NPR	S	9W-9930	004	MOUNT AS
<input type="checkbox"/>	NPR	S	122-0287	002	HOSE AS
<input type="checkbox"/>	NPR	S	129-5429	001	CORE AS-FUEL COOLER
<input type="checkbox"/>	NPR	S	141-1060	008	MOUNT-ISOLATION
<input type="checkbox"/>	NPR	S	141-2883	001	BRACKET AS
<input type="checkbox"/>	NPR	S	141-2884	001	BRACKET AS
<input type="checkbox"/>	NPR	S	151-1895	002	HOSE AS
<input type="checkbox"/>	NPR	SY	165-6634	001	SENSOR GP-COOLANT LEVEL
<input type="checkbox"/>	NPR	S	172-0956	001	HARNESS AS-WIRING
<input type="checkbox"/>	NPR	SY	172-8660	001	SWITCH GP-LIQUID LEVEL
<input type="checkbox"/>	NPR	S	185-1432	001	HARNESS AS-WIRING
<input type="checkbox"/>	NPR	SY	228-4223	001	PANEL GP-INSTRUMENT
<input type="checkbox"/>	NPR	S	235-8082	002	CONNECTOR
<input type="checkbox"/>	NPR	SY	236-8836	002	HOSE-VENTING