

3512B GEN SET ENGINE

Engine Serial Number Prefix - 6WN (Build Date - 06/01/2000, Test Date - 07/01/2000, Ship Date - 12/01/2000)

ENGINE - ENTIRE GROUP Prefix (6WN)

Qty.	NPR	Note	Part No.	Change
------	-----	------	----------	--------

Level	Req.
-------	------

Qty	Part Name
-----	-----------

FEATURE CODES

I	KW01500	F	001	1500 EKW W/FAN
I	512DE76	F	001	3512B 1500 EKW 60 HZ - LO BSFC
I	GENCON1	F	001	GENERATOR CONVERSION
I	CAACBX1	F	001	CABLE ACCESS BOX
I	RADDFL1	F	001	RADIATOR DUCT FLANGE
I	ACT0005	F	001	ANTIFREEZE
I	FPPRH02	F	001	FUEL PRIMING PUMP, RH MOUNTED
I	FLN0001	F	001	FLEXIBLE FUEL LINES
I	FULCOL2	F	001	FUEL COOLER
I	FUMDIS4	F	001	FUMES DISPOSAL
I	OPADRN4	F	001	OIL PAN DRAIN VALVE
I	LUBOIL1	F	001	LUBRICATING OIL
I	JWHD002	F	001	JACKET WATER HEATER - DUAL
I	LWS0001	F	001	LOW WATER TEMPERATURE SWITCH
I	BAT2417	F	001	24 VOLT BATTERY SET - DRY
I	BTRCBL1	F	002	BATTERY CABLES

I	ALT2442	F	001	CHARGING ALTERNATOR 24V 35 AMP
I	EMCENGU	F	001	ENGLISH DISPLAY UNITS
I	EMCAM06	F	001	ALARM MODULE - NFPA 99
I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
I	EMCCIM1	F	001	CUSTOMER INTERFACE MODULE-CIM
I	ALSLSM1	F	001	LOAD SHARE MODULE
I	WTLVLS3	F	001	WATER LEVEL SWITCH GAUGE
I	TSPCSA5	F	001	NEUTRAL GROUNDING CONNECTION
I	SHREL01	F	001	SPACE HEATER RELAY
I	60H-0480	F	001	60HZ 480 VOLTS
I	TRSGEN7	F	001	GEN SET TEST CHG AT 0.8 PF
I	MSEPGGN	F	001	GENERAL EPG
I	3512B F	001	001	3512B DIESEL ENGINE.
I	LOWBSFC	F	001	LO BSFC
I	60HERTZ	F	001	60 HERTZ
I	STANDBY	F	001	STANDBY POWER APPLICATION
I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL

PART NUMBERS

I	PP3562	07	001	2172 BHP 1545 GEN KW WOF 60 HZ
I	0P-8910		001	IX96-703_ POST SALE SPAR
I	LA2123 02	001	001	3512B 1500 EKW 60 HZ - LO BSFC
NPR	IY	128-2846	03	001 ENGINE AR
I	3L-0414		001	SINGLE BEARING GEN ALIGN-3500
I	3L-0432		001	TEST - PKG GEN SET (EMCP II
NPR	IY	4P-0558	00	001 AIR CLEANER GP

	I	5N-9582		001	LOW BSFC - 3500B SERIES.
	I	5P-2506	00	001	LITERATURE GP
NPR	IY	7C-0526	01	001	STARTING MOTOR GP-ELECTRIC
NPR	IY	7C-1664	07	001	DRIVE GP-FAN
NPR	I	7C-2459	02	001	GUARD GP-BELT
NPR	IY	7N-6782	08	001	INDICATOR GP-AIR FILTER CHANGE
NPR	IY	7W-5224	00	001	PULLEY GP-FAN DRIVE
NPR	IY	7W-5639	02	001	FAN GP-BLOWER
NPR	IY	7W-6669	01	001	GUARD GP-DAMPER
NPR	IY	8N-9639	04	001	GUARD GP-DAMPER
NPR	IY	9Y-6676	04	001	RADIATOR GP
NPR	I	104-4704	03	001	MOUNTING GP-CONTROL PANEL
NPR	IY	113-1592	03	001	MOUNTING GP-AIR CLEANER
NPR	I	115-7033	00	001	RAIL GP-ENGINE & GEN SUPPORT
NPR	IY	121-4450	10	001	PANEL GP-CONTROL
NPR	IY	121-8856	06	001	CONNECTION GP-ELECTRICAL
NPR	IY	126-9191	02	001	GROUND GP-ELECTRICAL
NPR	IY	134-0056	04	001	WIRING GP-ENGINE
NPR	I	141-1808	01	001	BOX GP-GENERATOR CONNECTION
NPR	I	144-1668	03	001	GENERATOR AR
NPR	I	153-0191	02	001	INSTALLATION AR-GENERATOR
	I	LA1969 03	001		GENERATOR CONVERSION
NPR	I	154-6022	00	001	CONVERSION GP-GENERATOR
	I	3L-0456		001	PROCEDURE - DVR PROG AND TEST
NPR	I	121-6202	06	001	REGULATOR GP-VOLTAGE

NPR	I	145-5138	00	001	WIRING GP-ELECTRONIC CONTROL
NPR	I	122-1194	01	001	BOX & MOUNTING GP
NPR	IY	9Y-7822	03	001	FLANGE GP-RADIATOR
	I	PA3948	04	001	ANTIFREEZE
NPR	I	2P-9868	04	001	ANTIFREEZE
	I	5N-3701		001	**FACTORY NOTE**
	I	LA3236 00	001		FUEL PRIMING PUMP AR-RH
NPR	IY	124-3187	04	001	LINES GP-FUEL PRIMING
NPR	IY	165-9154	02	001	PUMP GP-FUEL PRIMING
NPR	IY	5N-2438	05	001	LINES GP-FLEXIBLE FUEL
NPR	IY	7E-6681	03	001	COOLER GP-FUEL
	I	LA1060 05	001		FUMES DISPOSAL
NPR	IY	9Y-5563	00	001	FUMES DISPOSAL GP
NPR	IY	120-9818	04	001	FUMES DISPOSAL GP
NPR	IY	9Y-7876	01	001	DRAIN GP-ENGINE OIL
	I	PA5311	05	001	LUBRICATING OIL
NPR	I	5P-2586	03	001	OIL
	I	PA4391	08	001	JACKET WATER HEATER - DUAL
NPR	IY	6I-1041	04	001	MOUNTING GP-JACKET WTR HEATER
NPR	IY	6I-1042	06	001	MOUNTING GP-JACKET WTR HEATER
NPR	IY	7E-6248	06	001	HEATER GP-JACKET WATER
NPR	I	3E-0264	02	001	SWITCH GP-TEMPERATURE
	I	PA1787	09	001	24 VOLT BATTERY SET - DRY
NPR	I	7L-7872	08	001	BATTERY GP
NPR	IY	7W-0825	01	002	CABLE GP-BATTERY

	I	LA0427 08	001		CHARGING ALTERNATOR 24V 35AMP
NPR	IY	7C-4803	02	001	ALTERNATOR GP-CHARGING
NPR	IY	7E-4836	04	001	MOUNTING GP-ALTERNATOR
NPR	IY	7W-5780	04	001	GUARD GP-BELT
NPR	IY	107-7361	01	001	DRIVE GP-ACCESSORY
NPR	I	133-6468	01	001	WIRE AS-GROUND
	I	121-4713	00	001	INSTRUCTIONS
NPR	IY	121-4716	01	001	MODULE GP-ALARM
NPR	IY	121-4712	01	001	PANEL GP-ELECTRONIC
NPR	I	9Y-6496	02	001	MODULE GP-INTERFACE
	I	LA0498 06	001		LOAD SHARE MODULE
NPR	IY	149-6326	02	001	GOVERNOR GP-ELECTRONIC
NPR	IY	7E-9267	00	001	SWITCH GP-COOLANT LEVEL
NPR	I	121-9480	02	001	CONNECTION GP-TERMINAL STRIP
NPR	I	122-0335	02	001	RELAY GP
	I	5N-9597		001	VOLTAGE INDICATOR - 480 VOLT
	I	0P-1793		001	GEN SET TEST CHG AT 0.8 PF
	I	0V-1065		001	END USE: GENERAL EPG
	I	PP3562	07	001	2172 BHP 1545 GEN KW WOF 60 HZ
	I	2T-8373	00	001	1620 KW @ 1800 RPM (2172 BHP)

SHIPPED LOOSE

NPR	S	0S-1588		008	BOLT
NPR	S	2N-8928		008	CLIP
NPR	S	2V-7397		002	CABLE AS
NPR	S	3K-1715		002	CABLE AS

NPR	S	3N-6504	001	HOSE AS
NPR	S	3V-6785	002	CABLE AS
NPR	S	5F-5990	002	CLIP
NPR	S	5M-2894	016	WASHER-HARD
NPR	S	5P-0597	002	CLAMP-HOSE
NPR	S	5P-1472	580	HOSE
NPR	S	6V-2687	002	SCREW-PAN HEAD
NPR	S	7N-5274	002	COVER AS-TERMINAL
NPR	S	8L-8413	004	STRAP-CABLE
NPR	S	8N-0869	002	COVER-TERMINAL
NPR	S	8N-1186	001	HOSE AS
NPR	S	8N-1663	002	BOOT
NPR	S	8N-1725	002	COVER AS-TERMINAL
NPR	S	9G-0003	004	COVER AS-TERMINAL
NPR	S	9G-0004	004	COVER AS-TERMINAL
NPR	S	9G-8909	002	COVER-TERMINAL
NPR	S	9S-8752	008	NUT-FULL
NPR	S	9X-0203	001	MODULE GP-RELAY DRIVER
NPR	S	9X-9730	004	BATTERY GP
NPR	SY	9Y-6497	001	BOARD AS-RELAY
	S	9Y-9892	001	INSTRUCTIONS
NPR	S	171-6719	001	KIT-PARTS
NPR	SY	171-6721	001	KIT-PARTS
	S	SEBP2414	001	PTSBK
	S	SEBP2443	001	PTSBK

S	SEBU6251	001	LUBE 1632-16 (A)
S	SEBU6916	001	OMM
S	SEBU6918	001	OMM
S	SEBU6984	001	SUPP 140013B1(A)
S	SELF5260	001	NEW WARRANTY 1630-17 (A)
S	SELS0086	001	S.I.
S	ESO	001	(PRNT ESO COPY)
S	PML	001	*REQUIRED DECALS

Key:

I Installed

Y Separate Illustration

S Shipped Loose