

3516B GEN SET ENGINE

Engine Serial Number PREFIX- 7RN (Build Date - 12/03/2001, Test Date - 14/03/2001, Ship Date - 26/03/2001)

[View Latest Kit Information](#)

▼ ENGINE - ENTIRE GROUP PREFIX (7RN)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	KW01825	F	001	1825 EKW W/FAN
		I	516DE54	F	001	3516B 1825 EKW 60 HZ - LO BSFC
		I	RPA0063	F	001	825 FRAME GENERATOR REMOVAL
		I	HVGN048	F	001	GENERATOR 2470 FRAME 60 HZ
		I	SWRCN01	F	001	SWITCHGEAR CONVERSION
		I	ALSLSM1	F	001	LOAD SHARE MODULE
		I	GNDIFD0	F	001	DIODE FAULT DETECTOR
		I	SHKTHM0	F	001	THERMOSTAT FOR SPACE HEATER
		I	RAD6007	F	001	RADIATOR 60/CV, 0.357
		I	RRM0027	F	001	RADIATOR REMOVAL 46/CV, 0.428
		I	CLS0001	F	001	COOLANT LEVEL SENSOR
		I	LWS0001	F	001	LOW WATER TEMPERATURE SWITCH
		I	PFF0001	F	001	PRIMARY FUEL FILTER
		I	ALT2442	F	001	CHARGING ALTERNATOR 24V 35 AMP
		I	BAT2417	F	001	24 VOLT BATTERY SET - DRY
		I	ALTWH00	F	001	ALTERNATOR WIRING HARNESS
		I	OVRDG07	F	001	DIGITAL VOLTAGE REGULATOR
		I	JWHD001	F	001	JACKET WATER HEATER - DUAL
		I	OPADR4	F	001	OIL PAN DRAIN VALVE
		I	LUBOIL1	F	001	LUBRICATING OIL
		I	ELSDLH1	F	001	ELEC START MTR LH DUAL 24V
		I	RECTMO1	F	001	PROGRAM. RELAY CONTROL MODULE
		I	BTRCBL1	F	002	BATTERY CABLES
		I	BTR0001	F	002	BATTERY RACK
		I	BTC1005	F	001	BATTERY CHARGER 10 AMP

	I	VIBIS07	F	001	VIBRATION ISOLATORS - RADIATOR
	I	VIBIS09	F	001	VIBRATION ISOLATORS
	I	CCT1505	F	001	CCCT, 150:5 RATIO
	I	MSEPGGN	F	001	GENERAL EPG
	I	TVATRS1	F	001	STD G.S. TVA REPORT
	I	TRSGEN7	F	001	PGS TEST REPORT @ 0.8 PF
	I	LITENGE	F	002	EXTRA ENGLISH LITERATURE
	I	PRIPLUS	F	001	PRIME PLUS 10% POWER APPL.
	I	60H12K4	F	001	60HZ 12470 VOLTS
	I	3516B	F	001	3516B DIESEL ENGINE
	I	LOWBSFC	F	001	LO BSFC
	I	60HERTZ	F	001	60 HERTZ
	I	XLLENGL	F	001	EXTRA ENGLISH LITERATURE
					PART NUMBERS
	I	LL5068	00	001	2628 BHP 1880 GEN KW WOF 60 HZ
	I	LA3035	03	001	3516B 1825 EKW 60 HZ - LO BSFC
	NPR	IY 159-8836	02	001	ENGINE AR
	NPR	IY 5N-2438	05	001	LINES GP-FLEXIBLE FUEL
		I 5N-9582		001	LOW BSFC STRATEGY
		I 5P-2506	00	001	LITERATURE GP
	NPR	IY 8N-9639	04	001	GUARD GP-DAMPER
	NPR	IY 113-1581	00	001	AIR CLEANER GP
	NPR	IY 115-3613	03	001	MOUNTING GP-AIR CLEANER
	NPR	IY 126-9191	03	001	GROUND GP-ELECTRICAL
	NPR	IY 194-4903	00	001	MOUNTING GP-ENGINE OIL FILTER
		I LA3033	01	001	GENERATOR REMOVAL - 825 FRAME
		I LA2726	05	001	GENERATOR 2470 FRAME, 60 HZ
		I 3L-0467		001	TWO BEARING GEN ALIGNMENT-3500
	NPR	I 104-6203	06	001	INSTALLATION AR-GENERATOR
		I 160-1312	00	001	GENERATOR AR
	NPR	I 166-5168	00	001	BOX GP-EXTENSION TERMINAL
	NPR	I 166-5176	00	001	BOX GP-GENERATOR CONNECTION
	NPR	I 166-5183	00	001	CONNECTION GP-TERMINAL STRIP
	NPR	I 144-6656	01	001	PACKAGING AR
	NPR	IY 150-2536	02	001	RAIL GP-ENGINE & GEN SUPPORT
		I LA0392	12	001	SWITCHGEAR CONVERSION

	NPR	IY	119-0851	05	001	MOUNTING GP-INSTRUMENT PANEL
	NPR	IY	125-7089	08	001	BOX GP-INSTRUMENT PANEL
	NPR	IY	134-0062	04	001	WIRING GP-ENGINE
		I	LA0340	07	001	LOAD SHARE MODULE
	NPR	IY	161-0797	01	001	CONTROL AS-GOVERNOR
	NPR	I	135-3385	02	001	SENSOR GP-DETECTOR
		I	LA1701	02	001	THERMOSTAT FOR SPACE HEATER
	NPR	I	153-3275	01	001	THERMOSTAT AS
		I	LA2421	01	001	RADIATOR 60/CV, 0.357
	NPR	I	9Y-8563	00	001	COVER GP-SHIPPING
	NPR	I	120-9108	03	001	RADIATOR & FAN GP
		I	PA3069	08	001	RADIATOR REMOVAL 46/CV, 0.428
	NPR	IY	111-3794	01	001	SENSOR GP-COOLANT LEVEL
	NPR	IY	3E-0264	02	001	SWITCH GP-TEMPERATURE
	NPR	IY	8N-6435	02	001	FILTER GP-PRIMARY FUEL
		I	LA0427	08	001	CHARGING ALTERNATOR 24V 35AMP
	NPR	IY	7C-4803	02	001	ALTERNATOR GP-CHARGING
	NPR	IY	7E-4836	04	001	MOUNTING GP-ALTERNATOR
	NPR	IY	7W-5780	04	001	GUARD GP-BELT
	NPR	IY	107-7361	01	001	DRIVE GP-ACCESSORY
	NPR	I	133-6468	01	001	WIRE AS-GROUND
		I	PA1787	10	001	24 VOLT BATTERY SET - DRY
	NPR	IY	7L-7872	08	001	BATTERY GP
	NPR	IY	134-6317	00	001	WIRING GP-PANEL
		I	LA2503	00	001	DIG. VOLTAGE REG. DECS 125-15
	NPR	I	135-3393	05	001	REGULATOR AS-VOLTAGE
		I	PA4355	05	001	JACKET WATER HEATER - DUAL
	NPR	IY	7E-6247	03	001	HEATER GP-JACKET WATER
	NPR	IY	6I-1043	03	001	MOUNTING GP-JACKET WTR HEATER
	NPR	IY	6I-1044	07	001	MOUNTING GP-JACKET WTR HEATER
	NPR	IY	9Y-7876	01	001	DRAIN GP-ENGINE OIL
		I	PA5313	05	001	LUBRICATING OIL
	NPR	I	5P-2586	03	001	OIL
		I	PA1772	06	001	ELECTRIC STARTING MOTOR LH
	NPR	IY	8N-3896	13	001	STARTING MOTOR GP-ELECTRIC
	NPR	I	133-9300	01	001	CONTROL GP-ENGINE ELECTRONIC

	NPR	IY	7W-0825	01	002	CABLE GP-BATTERY
	NPR	IY	3N-7056	00	002	SUPPORT GP-BATTERY
	NPR	I	7W-0408	01	001	BATTERY CHARGER
	NPR	IY	9Y-8234	03	001	MOUNTING GP-RADIATOR
	NPR	IY	115-8491	02	001	MOUNTING GP-ENGINE & GENERATOR
		I	LA1728	01	001	CCCT, 150:5 RATIO
		I	0V-1065		001	0V1065 ENDUSE:GENERAL EPG
		I	0P-9799		001	STANDARD GEN SET TVA REPORT
		I	0P-1793		001	GEN SET TEST CHG AT 0.8 PF
		I	0P-9715		002	EXTRA LITERATURE - ENGLISH
		I	0P-1578		001	PRIME PLUS 10% RATING-3500
		I	5N-9607		001	VOLTAGE IDENTIFICATION EPG.
						SHIPPED LOOSE
		S			001	3406 -E324 - OEM ENG
	NPR	S	0S-1588		005	BOLT
	NPR	S	1D-4706		002	BOLT
	NPR	S	1L-3769		001	RING-RETAINING
	NPR	S	1W-0531		001	BASE-PRIMARY FUEL FILTER
	NPR	S	2A-1538		008	BOLT
	NPR	S	2H-3429		001	RING-RETAINING
	NPR	S	2J-0157		001	SEAL-O-RING
	NPR	S	2J-3506		014	NUT-FULL
	NPR	S	2V-7397		002	CABLE AS
	NPR	S	3B-2968		010	BOLT
	NPR	S	3B-7749		001	NIPPLE-PIPE
	NPR	S	3K-1715		002	CABLE AS
	NPR	S	3N-2451		004	JOINT AS-TUBE
	NPR	S	3N-6504		001	HOSE AS
	NPR	S	3N-7054		002	SUPPORT AS-BATTERY
	NPR	S	3N-7055		002	BOARD
	NPR	S	3V-6785		002	CABLE AS
	NPR	S	4P-3117		001	VALVE-BALL
	NPR	S	5F-5990		002	CLIP
	NPR	S	5P-7197		002	WASHER
	NPR	S	5P-8154		002	JOINT AS-TUBE
	NPR	S	5P-8248		032	WASHER-HARD

NPR	S	6V-3835	001	SEAL-O-RING
NPR	S	6V-6866	002	PLUG
NPR	S	7C-3879	002	BAR
NPR	S	7C-3892	002	BRACKET
NPR	S	7H-9678	001	RETAINER-ELEMENT
NPR	S	7N-1628	001	NUT
NPR	S	7N-5274	002	COVER AS-TERMINAL
NPR	S	7S-9323	001	SPRING
NPR	S	7W-0408	001	BATTERY CHARGER
NPR	S	8H-2778	001	SEAL-RING
NPR	S	8H-7202	001	CASE AS-FUEL FILTER
NPR	S	8L-8413	004	STRAP-CABLE
NPR	S	8N-0869	002	COVER-TERMINAL
NPR	S	8N-1186	001	HOSE AS
NPR	S	8N-1725	002	COVER AS-TERMINAL
NPR	S	8T-4994	008	WASHER-HARD
NPR	S	9G-0003	004	COVER AS-TERMINAL
NPR	S	9G-0004	004	COVER AS-TERMINAL
NPR	S	9G-8909	002	COVER-TERMINAL
NPR	S	9M-2342	001	FILTER ELEMENT-FUEL
NPR	SY	9X-9730	004	BATTERY GP
NPR	SY	111-3794	001	SENSOR GP-COOLANT LEVEL
NPR	S	120-9107	001	RADIATOR & FAN GP
NPR	S	126-5957	001	ELBOW
NPR	S	133-9300	001	CONTROL GP-ENGINE ELECTRONIC
NPR	S	135-3385	001	SENSOR GP-DETECTOR
NPR	S	135-3393	001	REGULATOR AS-VOLTAGE
NPR	S	153-3865	002	MOUNT AS
NPR	SY	161-0797	001	CONTROL AS-GOVERNOR
NPR	S	178-5048	008	ISOLATOR AS
	S	SEBP2414	003	PTSBK
	S	SEBP2416	003	PTSBK
	S	SEBP2931	003	PTSBK
	S	SEBU6042	003	SUPP
	S	SEBU6251	003	LUBE
	S	SEBU6916	003	OMM



S	SEBU6918	003	OMM
S	SEBU6984	003	SUPP
S	SELF5308	001	WARRANTY
S	SELS0086	003	S.I.
S	SENR4794	003	SCHEMATIC
S	SENR6588	002	SMGP
S	ESO	001	(PRNT ESO COPY)
S	PML	001	*REQUIRED DEC ALS

Key:

I Installed

Y Separate Illustration

S Shipped Loose