

3516C GENERATOR SET

Engine Serial Number Prefix - SBJ (Build Date - 07/12/2006, Test Date - 11/12/2006, Ship Date - unknown)

ENGINE - ENTIRE GROUP (SBJ)

Level	Qty.	NPR	Note	Part No.	Change
Req.					
Qty	Part Name				

FEATURE CODES

I	516DE5A	F	001	3516C, 60HZ, 1800RPM PGS 5A
S	VIBRM10	F	001	VIBRATION ISOLATOR REMOVAL 10
S	PFF0001	F	001	PRIMARY FUEL FILTER
S	ANNUNSL	F	001	REMOTE ANN NFPA99/CSA282 (1-3)
S	FWS0004	F	001	WATER SEPARATOR
I	NGRDCNB	F	001	NEUTRAL GND CONNECTION -REAR
S	BTC20A1	F	001	BATTERY CHG 20 AMP NFPA 99-110
I	ELSM246	F	001	HD ELEC STRTNG MOTOR DUAL 24V
I	JWHD004	F	001	JACKET WATER HEATER-DUAL
I	ALT2496	F	001	CHARGING ALTERNATOR-45AMP 96
I	BUSBL6R	F	001	5000A LV BB REMOVAL-RH (NEMA)
I	MEA1J1B	F	001	CBK UL 3P 5000A LSI-P EO
I	EMPTYPR	F	001	EMPTY ENCLOSURE RIGHT
I	CT35006	F	001	CURRENT TRANSF., 3500:5 RATIO
I	EMCP33B	F	001	EMCP 3.3 CONTROL PANEL - B

I	ANNNFPA	F	001	1ST LOCAL ANN NFPA 110/CSA282
I	BOTCBLB	F	001	BOTTOM CBL ENTRY NO SHROUD STD
I	EMCSDP1	F	001	DISCRETE I/O (DIO) PACKAGE
I	RTDDIOH	F	001	OPTIONAL MODULE HARNESS
I	PANLGTS	F	001	PANEL LIGHTS
I	CBCONN1	F	001	CIRCUIT BREAKER CONNECTION
I	AUXPNLL	F	001	AUXILIARY PLATE MOUNTING - LH
I	CERTIF2	F	001	EPA & CARB NON-ROAD EMIS. CERT
I	CUSTCNR	F	001	CUSTOMER CONNECTION MTG RH STD
I	NOENCPL	F	001	NO ENCLOSURE LEFT (STANDARD)
I	UIPBBHS	F	001	CONTROL PANEL MOUNT REAR (STD)
I	60H-0480	F	001	60HZ 480 VOLTS
I	MSEPGGN	F	001	GENERAL EPG
I	TRSGEN7	F	001	PGS TEST REPORT @ 0.8 PF
I	MSCEC72	F	001	COMMERCIAL BUSINESSES
I	MWCODEF	F	001	STANDBY POWER
I	LANENGO	F	001	ENGLISH LANGUAGE OPTION
I	3516C F	F	001	3516C DIESEL ENGINE
I	CERTSTA	F	001	STATIONARY APPLICATION USE
I	CERTUSA	F	001	END USER LOCATION DESCRIPTION
I	KW02000	F	001	2000 EKW W/FAN
I	NONULL	F	001	NON UL 2200 LISTED PKG GEN SET
I	STANDBY	F	001	STANDBY POWER APPLICATION

PART NUMBERS

I	GP0858	01	001	3516B TIER I PKG
---	--------	----	-----	------------------

	I	LA4570 06	001	3516C GLOBAL PKG-1800 RPM
NPR	IY	266-6137		001 ENGINE AR
NPR	IR	281-9204	01	001 ENGINE AR
NPR	IY	205-7860	08	001 FILM GP
	I	3L-0284		001 *****TEST - PKG GEN SET*****
NPR	IY	252-5590	02	001 FASTENER GP-GENERATOR COUPLING
	I	3L-0414		001 SINGLE BEARING GEN ALIGN-3500
	I	252-7405	00	001 ***** TEST - GEN ELE SYS LE *
NPR	SY	7W-0825	01	002 CABLE GP-BATTERY
NPR	SY	3N-7056	00	002 SUPPORT GP-BATTERY
NPR	SY	7L-7871	09	002 BATTERY GP
NPR	IY	240-0740	01	001 SWITCH GP-DISCONNECT
NPR	IY	245-0000	02	001 BOX GP-CONTROL PANEL
NPR	IY	245-0087	04	001 MOUNTING GP-CONTROL PANEL
NPR	IY	245-0095	01	001 WIRING GP-GENERATOR
NPR	IY	245-0082	01	001 CONTROL GP-GENERATOR SET
NPR	IY	252-7367	01	003 MOUNTING GP-PANEL
NPR	IY	252-7409	01	001 FASTENER GP-WIRING HARNESS
NPR	IY	245-0092	02	001 WIRING GP-GENERATOR
NPR	IY	269-3488	02	001 COVER GP-GENERATOR
NPR	IY	252-7438	03	002 PLUG GP-BOX
NPR	IY	252-7372	01	001 WIRING GP-GENERATOR
NPR	IY	252-7700	00	001 PLUG GP-BOX
NPR	IY	252-7418	03	001 WIRING GP-GENERATOR
NPR	IY	252-7556	00	001 COVER GP-CONTROL PANEL

NPR	IY	260-6666	04	001	CONNECTION GP-GENERATOR LEADS
NPR	IY	252-7411	08	001	GROUND GP-ELECTRICAL
NPR	IY	245-0001	00	001	COVER GP-CONTROL PANEL
NPR	IY	245-0013	01	001	COVER GP-GENERATOR
NPR	IY	245-0007	01	002	COVER GP-GENERATOR
NPR	IY	245-0023	01	001	COVER GP-CONTROL PANEL
NPR	IY	245-0027	03	001	COVER GP-ENCLOSURE
NPR	IY	245-0024	00	001	COVER GP-ENCLOSURE
NPR	IY	246-9375	04	001	WIRING GP-SENSOR
NPR	IY	241-0235	00	001	WIRING GP-ELECTRIC STARTING
NPR	IY	242-7068	00	001	WIRING GP-ELECTRIC STARTING
NPR	IY	259-2168	02	001	SENSOR GP-TEMPERATURE
NPR	IY	245-0031	02	001	WIRING GP-ENGINE
	I	252-7392	00	001	INSTRUCTIONS
	I	252-7394	00	001	INSTRUCTIONS
	I	252-7396	02	001	INSTRUCTIONS-GOV
NPR	I	249-0311	01	001	RADIATOR GP
NPR	IY	212-4694	02	001	DRIVE GP-FAN
NPR	I	269-7197	03	001	PULLEY GP-FAN DRIVE
NPR	IY	250-9694	04	001	CONVERSION AR-ENGINE
NPR	SY	256-3172	02	001	MOUNTING GP-RADIATOR
NPR	IY	121-3356	06	002	SENSOR & MTG GP-RADIATOR
NPR	IY	268-4442	02	001	DRAIN GP-ENGINE OIL
NPR	I	5P-2586	04	416	OIL
NPR	IY	147-3738	02	001	VALVE GP-FLUID SAMPLING

NPR	IY	7N-6782	08	001	INDICATOR GP-AIR FILTER CHANGE
NPR	IY	208-0820	03	001	MOUNTING GP-AIR CLEANER
NPR	I	208-0821	00	001	LINES GP-AIR
NPR	SY	5N-2438	05	001	LINES GP-FLEXIBLE FUEL
NPR	IY	115-1063	03	001	PUMP GP-FUEL PRIMING
NPR	IY	120-9818	06	002	FUMES DISPOSAL GP
NPR	SY	9Y-5563	03	002	FUMES DISPOSAL GP
NPR	IY	245-8742	00	001	RAIL GP-ENGINE & GEN SUPPORT
NPR	SY	256-3168	01	001	MOUNTING GP-ENGINE FLEXIBLE
NPR	IY	244-4064	02	001	MOUNTING GP-RAIL
NPR	IY	197-9052	00	001	GUARD GP-DAMPER
NPR	IY	3N-8594	06	001	COVER GP-ENGINE LIFTING EYE
	S	5P-2506	00	001	LITERATURE GP
	I	GC4950	00	001	GLOBAL-2000 GENERATOR 824/1
	I	GZ0292	01	001	VIBRATION ISOLATOR REMOVAL
NPR	IY	262-8148	00	001	GENERATOR AR
NPR	SY	252-7504	04	001	CONTROL GP-ELECTRONIC
	I	LE0196 01	001		FUEL WATER SEPARATOR
	I	LE0222 04	001		UL-2200 FOR ALL 3500
	I	3L-0028		001	NAMEPLATE
	I	3L-0043		001	GSC + SETPOINT INFORMATION-UL
	I	GC3383	00	001	NEUTRAL GND CONNECTION -REAR
	I	LE0195 01	001		PRIMARY FUEL FILTER
NPR	SY	8N-6435	02	001	FILTER GP-PRIMARY FUEL
	I	GC4968	01	001	2000S GENERATOR REMOVAL

NPR	SY	131-0832	01	001	BATTERY CHARGER GP
	I	LE0175 03	001		HEAVY DUTY ELECTRIC STARTING
	I	LE0214 02	001		HEATER AR - JACKET WATER
NPR	IY	273-7401	03	001	CABLE GP-GENERATOR GROUND
NPR	IY	8N-3896	16	001	STARTING MOTOR GP-ELECTRIC
	I	GC3236	03	001	CBK UL 3P 5000A LSI-P EO
NPR	IY	134-3160	08	001	MOUNTING GP-JACKET WTR HEATER
NPR	IY	166-6652	07	001	MOUNTING GP-JACKET WTR HEATER
NPR	IY	200-6504	01	002	HEATER GP-JACKET WATER
	I	GZ0290	01	001	ALTERNATOR-CHARGING
NPR	IY	107-7361	03	001	DRIVE GP-ACCESSORY
NPR	IRY	5N-5692	12	001	ALTERNATOR GP-CHARGING
NPR	IY	7E-4836	09	001	MOUNTING GP-ALTERNATOR
NPR	IY	271-9270	02	001	GUARD GP-BELT
NPR	IY	126-9191	05	001	GROUND GP-ELECTRICAL
NPR	IY	133-6468	01	001	WIRE AS-GROUND
NPR	IY	241-0243	00	001	WIRING GP-ALTERNATOR
NPR	IY	151-9228	02	001	GUARD GP-BELT
	I	GC2907	02	001	BUSS BAR POWER CONNECTIONS (NE
NPR	IY	245-0002	02	001	BOX GP-EXTENSION TERMINAL
NPR	IY	245-0093	02	001	BUS BAR GP-BOX
NPR	IY	245-0026	00	001	COVER GP-EXTENSION BOX
	I	252-7401	02	001	INSTRUCTIONS
NPR	IY	245-0097	00	001	COVER GP-EXTENSION BOX
NPR	IY	252-7350	00	001	MOUNTING GP-BOX

	I	GC2908	01	001	BUS BAR REMOVAL-RH LOW VOLTAGE
	I	GC3238	01	001	EMCP3.3
	I	GC2511	00	001	EMPTY ENCLOSURE LEFT
	I	GC2959	02	001	NFPA 99-110/CSA 282
NPR	IY	245-0003	04	002	BOX GP-EXTENSION TERMINAL
NPR	IY	245-0096	00	002	COVER GP-EXTENSION BOX
NPR	IY	245-0025	00	002	COVER GP-EXTENSION BOX
	I	252-7399	01	001	INSTRUCTIONS-BUS
	I	GC2510	00	001	EMPTY ENCLOSURE - RH
	I	252-7400	01	001	NOTE-BUSS BAR MOUNTING
	I	GC2903	00	001	MOUNTING GP-CT (3500:5)
	I	GC2961	00	001	SPARE DISCRETE I/O PKG
NPR	IY	252-7332	03	001	TRANSFORMER GP-CURRENT
	I	GC2963	00	001	OPTIONAL MODULE HARNESS
NPR	I	254-6368	04	001	ELECTRONICS GP-GENERATOR SET
NPR	IY	245-0030	07	001	PANEL GP-CONTROL
NPR	IY	245-0035	09	001	BOX GP-ELECTRONIC
	S	244-9655	01	001	INSTRUCTIONS
	I	GC2991	01	001	PANEL LIGHTS
	I	GC2995	00	001	RAISE/LOWER SWITCH
NPR	IY	267-8475	00	001	WIRING GP-GENERATOR
	I	GC2996	03	001	1ST. CUSTOM LOCAL ANNUCIATOR
	I	GC3256	02	001	CIRCUIT BREAKER CONNECTION
NPR	IY	271-2168	00	001	ALARM GP
	I	271-4524	00	001	INSTRUCTIONS

	SY	271-7376	00	001	FILM GP
NPR	IY	252-7480	00	001	WIRING GP-GENERATOR
	I	GC2508	01	001	BOTTOM CBL ENTRY NO SHROUD STD
	I	252-7502	04	001	INSTRUCTIONS
	I	5N-8982		002	STATIONARY EPA
	I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
	I	0V-1065		001	END USE: GENERAL EPG
	I	0P-1793		001	***GEN SET TEST CHG @ 0.8 PF**
	I	LL5723 00	001	2881	BHP 2000 GEN KW W/F 60 HZ
	I	0K-7364		001	2148 KW (2881 BHP) @ 1800 RPM
	I	CA0866	07	001	LANGUAGE MARKINGS-ENGLISH
	I	LL5712 01	001	2937	BHP 2000 GEN KW W/F 60 HZ

SHIPPED LOOSE

	S	ESO	001		(PRNT ESO COPY)
	S	PML	001		*REQUIRED DECALS
NPR	S	0S-1588		005	BOLT
NPR	S	0S-1594		008	BOLT
NPR	S	1K-6870		032	LOCKNUT
NPR	S	1L-3769		001	RING-RETAINING
NPR	S	1S-4305		008	WASHER
NPR	S	1S-5772		001	GASKET
NPR	S	1W-0531		001	BASE-PRIMARY FUEL FILTER
NPR	S	1W-2858		001	STRAP
NPR	S	1W-8129		001	SUPPORT
NPR	S	2H-3429		001	RING-RETAINING

NPR	S	2J-0157	001	SEAL-O-RING
NPR	S	2N-2107	003	CLIP
NPR	S	2N-8928	010	CLIP
NPR	S	2P-1293	002	LOCKNUT
NPR	S	2V-7397	002	CABLE AS
NPR	S	2W-1745	002	SPACER
NPR	S	3B-7744	001	FITTING
NPR	S	3K-1715	002	CABLE AS
NPR	S	3N-2451	004	JOINT AS-TUBE
NPR	S	3N-7054	002	SUPPORT AS-BATTERY
NPR	S	3N-7055	002	BOARD
NPR	SY	3N-7056	001	SUPPORT GP-BATTERY
NPR	S	3P-0648	016	SEAL-O-RING
NPR	S	3V-6785	002	CABLE AS
NPR	S	4D-7794	002	CLIP
NPR	S	4F-0411	002	BOLT
NPR	S	4L-6454	001	BOLT
NPR	S	4P-0692	002	CLAMP AS
NPR	S	4R-8658	001	VALVE AS-MANUAL
NPR	S	5P-0597	002	CLAMP-HOSE
NPR	S	5P-1075	020	WASHER-HARD
NPR	S	5P-1076	008	WASHER-HARD
NPR	S	5P-1472	760	HOSE
NPR	S	5P-2566	016	BOLT
NPR	S	5P-5894	001	COATING

NPR	S	5P-6652	060	WASHER
NPR	S	5S-7383	008	BOLT
	SY	6L-4502	001	CHART-PLATE & FILM
NPR	S	6V-3835	001	SEAL-O-RING
NPR	S	6V-6866	002	PLUG
NPR	S	6V-8182	030	NUT
NPR	S	6V-8188	030	NUT
NPR	S	6V-8801	020	NUT
NPR	S	6V-8997	002	UNION
NPR	S	6V-9746	005	SEAL-O-RING
NPR	S	6V-9853	001	ELBOW
NPR	S	7H-9678	001	RETAINER-ELEMENT
NPR	S	7K-1181	007	STRAP-CABLE
NPR	SY	7L-7871	001	BATTERY GP
NPR	S	7N-1628	001	NUT
NPR	S	7N-5274	002	COVER AS-TERMINAL
NPR	S	7N-6986	002	SUPPORT
NPR	S	7S-9323	001	SPRING
NPR	SY	7W-0825	001	CABLE GP-BATTERY
NPR	S	7X-0297	002	BOLT
NPR	S	7X-0311	004	BOLT
NPR	S	7X-0368	032	BOLT
NPR	S	7X-0369	012	BOLT
NPR	S	7X-0371	006	BOLT
NPR	S	7X-0447	004	NUT

NPR	S	7X-0448	012	NUT
NPR	S	8C-4436	008	BOLT
NPR	S	8H-2778	001	SEAL-RING
NPR	S	8H-7202	001	CASE AS-FUEL FILTER
NPR	S	8L-8413	004	STRAP-CABLE
NPR	S	8N-0869	002	COVER-TERMINAL
NPR	S	8N-1663	002	BOOT
NPR	S	8N-1725	002	COVER AS-TERMINAL
NPR	S	8N-6432	001	ADAPTER
NPR	SY	8N-6435	001	FILTER GP-PRIMARY FUEL
NPR	S	8T-2501	010	BOLT
NPR	S	8T-2502	006	BOLT
NPR	S	8T-4122	024	WASHER-HARD
NPR	S	8T-4223	056	WASHER-HARD
NPR	S	8T-4896	022	WASHER-HARD
NPR	S	8T-4994	064	WASHER-HARD
NPR	S	8T-5360	008	WASHER
NPR	S	8T-8916	004	BOLT
NPR	S	8T-8917	010	BOLT
NPR	S	8T-8919	004	BOLT
NPR	S	8T-9101	002	BOLT
NPR	S	8T-9379	004	BOLT
NPR	S	8T-9393	012	BOLT
NPR	S	9B-7237	004	BOLT
NPR	S	9G-0003	004	COVER AS-TERMINAL

NPR	S	9G-0004	004	COVER AS-TERMINAL
NPR	S	9G-8140	001	SPACER
NPR	S	9G-8909	002	COVER-TERMINAL
NPR	S	9M-2342	001	FILTER ELEMENT-FUEL
NPR	S	9X-9720	004	BATTERY
NPR	S	092-7385	001	CLIP
NPR	SY	121-3356	001	SENSOR & MTG GP-RADIATOR
NPR	S	121-3369	001	HARNESS AS-SENSOR
NPR	S	124-6267	014	CLAMP-HOSE
NPR	S	126-5957	001	ELBOW
NPR	SY	131-0832	001	BATTERY CHARGER GP
NPR	S	135-6261	024	CLAMP
NPR	S	136-4190	006	CLIP-2 PIECE
NPR	S	136-4191	006	CLIP-2 PIECE
NPR	S	161-1528	003	BRACKET
NPR	S	176-0028	001	BRACKET
NPR	S	198-4782	060	WASHER-HARD
NPR	S	216-2783	002	JOINT AS-TUBE
NPR	SY	233-7973	001	SEPARATOR GP-WATER
NPR	S	239-9957	001	SENSOR GP-LIQUID LEVEL
NPR	S	251-5715	006	BOLT
NPR	SY	252-7504	001	CONTROL GP-ELECTRONIC
NPR	SY	252-7564	001	TRANSFORMER AS-CURRENT
NPR	S	266-5360	004	WASHER
NPR	SY	270-3504	001	RADIATOR GP

NPR	SY	270-3505	001	RADIATOR GP
NPR	S	272-6462	001	GASKET
NPR	S	273-3538	006	HOSE
NPR	S	273-3540	002	TUBE
NPR	S	274-1732	002	TUBE
NPR	S	274-1737	006	BRACKET
NPR	S	274-1742	001	TUBE
NPR	SY	276-2449	001	LINES GP-AIR
NPR	S	276-2450	001	TUBE AS
NPR	S	276-3033	002	SUPPORT AS
NPR	S	276-3039	001	SUPPORT
NPR	S	276-3040	002	SUPPORT AS
NPR	S	276-3041	001	TUBE
NPR	S	276-3042	001	TUBE
NPR	S	282-2602	001	BRACKET
NPR	S	282-6664	002	BELLOWS
NPR	S	282-6678	001	BRACKET
NPR	S	282-6679	016	CLAMP
NPR	S	282-6680	008	STRAP
NPR	S	282-6684	001	BRACKET
NPR	S	282-8532	001	BRACKET
NPR	S	282-8535	002	U-BOLT
NPR	S	282-9919	001	ADAPTER AS
NPR	SY	283-2548	001	FUMES DISPOSAL GP
NPR	S	284-4913	001	GUARD AS

NPR	S	284-4914	001	GUARD AS
NPR	S	284-4915	002	GUARD AS
NPR	SY	284-4916	001	GUARD GP-LINES
NPR	S	285-8515	001	BRACKET
NPR	S	286-2182	001	HOSE AS
NPR	S	286-2185	001	HOSE AS
NPR	S	286-2445	002	PLATE
NPR	SY	286-3573	001	LINES GP-FUEL
NPR	S	289-0222	002	PLATE
NPR	S	289-0223	002	PLATE
NPR	S	289-0272	006	BOLT
NPR	S	293-9809	004	CLIP-2 PIECE
NPR	S	293-9810	004	CLIP-2 PIECE
NPR	S	294-0517	004	STRAP
NPR	S	294-0521	002	CLAMP
NPR	S	294-0522	002	CLAMP
NPR	S	294-5249	002	BRACKET
NPR	S	294-5250	002	BRACKET
NPR	S	295-2847	001	BRACKET
NPR	S	295-2848	001	BRACKET
	S	SEBU6251	001	LUBE 140019B2(A)
	S	SEBU8111	001	OMM
	S	SELF5397	001	WARRANTY
	S	SERP4369	001	PTSCD

Key:

I Installed

S Shipped Loose

Y Separate Illustration

R REMFG PART MAY BE AVAILABLE

Copyright 1993 - 2015 Caterpillar Inc.

All Rights Reserved.