

3508 GEN SET ENGINE

Engine Serial Number Prefix - 23Z (Build Date - 12/10/1998, Test Date - 13/10/1998, Ship Date - 04/12/1998)

ENGINE - ENTIRE GROUP PREFIX (23Z)

| Qty. | NPR | Note | Part No. | Change | Qty | Part Name |
|--------------|-----|------|-----------|--------|------|--------------------------------|
| | | | | Level | Req. | |
| PART NUMBERS | | | | | | |
| | | I | LA1383 11 | 001 | | 3508 DITA/XQ 900 RENTAL PKG |
| NPR | IRY | | 2W-8406 | 30 | 001 | ENGINE AR |
| NPR | I | | 2P-9868 | 04 | 001 | ANTIFREEZE |
| | | I | 3L-0467 | | 001 | TWO BEARING GEN ALIGNMENT-3500 |
| NPR | IY | | 3N-4905 | 03 | 001 | HOSE AS |
| NPR | I | | 149-2477 | 00 | 001 | SUPPORT AS |
| NPR | IY | | 4P-7610 | 02 | 001 | SENSOR GP-SPEED |
| NPR | IY | | 4W-4753 | 02 | 001 | SWITCH GP-MAGNETIC |
| | | I | 5N-9597 | | 001 | VOLTAGE INDICATOR 480V, 60HZ |
| | | I | 5N-9623 | | 001 | NOTE GOVERNOR WIRING |
| | | I | 5P-2506 | 00 | 001 | LITERATURE GP |
| NPR | I | | 5P-2586 | 03 | 001 | OIL |
| NPR | IY | | 6I-3139 | 01 | 001 | COOLER GP-FUEL |
| NPR | IY | | 7C-0526 | 01 | 001 | STARTING MOTOR GP-ELECTRIC |
| NPR | IY | | 7C-6207 | 03 | 001 | RADIATOR GP |
| NPR | IY | | 7E-2858 | 00 | 001 | ALTERNATOR GP-CHARGING |

| | | | | | |
|-----|----|----------|----|-----|--------------------------------|
| NPR | IY | 7E-4836 | 03 | 001 | MOUNTING GP-ALTERNATOR |
| NPR | IY | 7E-6247 | 02 | 001 | HEATER GP-JACKET WATER |
| NPR | IY | 7N-6782 | 07 | 001 | INDICATOR GP-AIR FILTER CHANGE |
| NPR | IY | 7W-3953 | 08 | 001 | DRIVE GP-FAN |
| NPR | IY | 7W-5223 | 00 | 001 | PULLEY GP-FAN DRIVE |
| NPR | IY | 7W-5780 | 04 | 001 | GUARD GP-BELT |
| NPR | IY | 7W-6669 | 01 | 001 | GUARD GP-DAMPER |
| NPR | IY | 7W-6906 | 01 | 001 | FAN GP-BLOWER |
| NPR | IY | 7W-7214 | 04 | 001 | GUARD GP-BELT |
| NPR | IY | 7W-9032 | 04 | 001 | ENCLOSURE GP-WIRING |
| NPR | IY | 7W-9465 | 04 | 001 | PUMP GP-FUEL PRIMING |
| NPR | IY | 7W-9704 | 05 | 001 | PUMP GP-SUMP |
| NPR | IY | 8N-9639 | 04 | 001 | GUARD GP-DAMPER |
| NPR | IY | 104-6203 | 04 | 001 | INSTALLATION AR-GENERATOR |
| NPR | IY | 104-9727 | 03 | 001 | MOUNTING GP-CONTACTOR |
| NPR | IY | 105-3255 | 00 | 001 | MOUNTING GP-CIRCUIT BREAKER |
| NPR | IY | 105-7182 | 02 | 001 | FASTENER GP-WIRING HARNESS |
| NPR | I | 121-6200 | 01 | 001 | REGULATOR GP-VOLTAGE |
| NPR | IY | 121-8855 | 02 | 001 | CONNECTION GP-ELECTRICAL |
| NPR | IY | 121-9294 | 02 | 001 | RAIL GP-ENGINE SUPPORT |
| NPR | IY | 129-2238 | 01 | 001 | HARNESS AS-ENGINE |
| NPR | I | 129-2244 | 00 | 001 | SENSOR & MTG GP-RADIATOR |
| NPR | IY | 134-3241 | 01 | 001 | SENSOR GP-TEMP & PRESS |
| NPR | IY | 136-9728 | 03 | 001 | MOUNTING GP-JACKET WTR HEATER |
| NPR | IY | 136-9729 | 02 | 001 | MOUNTING GP-JACKET WTR HEATER |

| | | | | | |
|-----|----|----------|----|-----|--------------------------------|
| NPR | IY | 141-1808 | 01 | 001 | BOX GP-GENERATOR CONNECTION |
| | I | 5N-9955 | | 001 | VOLTAGE IDENTIFICATION EPG/GAS |
| | IY | 103-1034 | 01 | 001 | MUFFLER GP |
| NPR | IY | 140-2674 | 00 | 001 | VALVE GP-RADIATOR DRAIN |
| NPR | IY | 141-1598 | 00 | 001 | SWITCH GP-DISCONNECT |
| NPR | IY | 141-3229 | 00 | 001 | RAIL GP-SLIDE |
| | I | 142-2386 | 01 | 001 | PLATE & FILM GP |
| NPR | IY | 144-5213 | 02 | 001 | ENCLOSURE GP-GENERATOR |
| NPR | I | 144-6656 | 01 | 001 | PACKAGING AR |
| NPR | IY | 149-5237 | 00 | 001 | ENCLOSURE GP-GENERATOR |
| NPR | IY | 149-7755 | 00 | 001 | ENCLOSURE GP-GENERATOR |
| NPR | IY | 125-9326 | 00 | 001 | TRANSFORMER GP-POTENTIAL |
| NPR | IY | 153-0180 | 00 | 001 | VENT GP-FUEL TANK |
| NPR | I | 129-4337 | 04 | 001 | CONTROL GP-EMCP ELECTRONIC |
| NPR | IY | 141-7883 | 00 | 001 | BOX AS-STORAGE |
| NPR | I | 144-1748 | 02 | 001 | GENERATOR AR |
| NPR | IY | 146-0806 | 01 | 001 | DOOR AS-ACCESS |
| NPR | IY | 146-9838 | 03 | 001 | PANEL GP-CONTROL |
| NPR | IY | 149-6401 | 00 | 001 | BATTERY GP |
| NPR | IY | 152-2876 | 01 | 001 | HARNESS AS-WIRING |
| NPR | IY | 130-5652 | 00 | 001 | PANEL GP-CONTROL |
| NPR | IY | 131-2837 | 02 | 001 | PANEL GP-CONTROL |
| NPR | IY | 131-7253 | 03 | 001 | CONTROL GP-GOVERNOR |
| NPR | IY | 135-3319 | 03 | 001 | BATTERY CHARGER GP |
| NPR | IY | 136-2054 | 02 | 001 | MODULE GP-ALARM |

| | | | | | |
|-----|-----|-----------|-----|-----|------------------------------|
| NPR | IY | 147-1165 | 04 | 001 | SWITCHGEAR AR |
| | I | LA1233 05 | 001 | | SEMI AUTOMATIC PARALLELING |
| NPR | IY | 126-0033 | 01 | 001 | PANEL GP-CIRCUIT BREAKER |
| NPR | IY | 130-5380 | 01 | 001 | PARALLELING GP-SEMIAUTOMATIC |
| NPR | IY | 147-1186 | 00 | 001 | CONTROL GP-CIRCUIT BREAKER |
| NPR | IY | 150-7151 | 00 | 001 | BUS BAR GP |
| NPR | IY | 122-6587 | 00 | 001 | TRANSFORMER AS-CURRENT |
| | I | LA1264 01 | 001 | | REMOTE COMMUNICATIONS OPTION |
| NPR | IY | 131-0487 | 03 | 001 | CONTROL GP-EMCP ELECTRONIC |
| | I | 9Y-1386 | 02 | 001 | UNDERCARRIAGE AR |
| NPR | IY | 133-6295 | 02 | 001 | BOX GP-CABLE STORAGE |
| | I | 165-5375 | 00 | 001 | INSTRUCTION-SWGR |
| NPR | IY | 151-5675 | 01 | 001 | CONNECTION GP-ELECTRICAL |
| NPR | I | 152-8793 | 00 | 001 | INSULATION GP-GENERATOR |
| | IY | 153-9797 | 01 | 001 | SUPPRESSION GP-SOUND |
| NPR | IY | 154-8289 | 00 | 001 | FUMES DISPOSAL GP |
| NPR | I | 155-2606 | 00 | 001 | AIR CLEANER GP |
| NPR | IY | 155-7444 | 01 | 001 | SHIELD AS |
| | I | 164-6539 | 00 | 001 | TANK GP - F 1250 |
| NPR | IY | 162-8684 | 00 | 001 | MOUNTING GP-ENGINE |
| | IY | 162-1395 | 00 | 001 | BAFFLE GP-RADIATOR |
| NPR | ILY | 5N-9527 | 01 | 001 | FITTING GP-EXHAUST |
| NPR | ILY | 7N-6967 | 05 | 001 | FITTING GP-EXHAUST |
| NPR | ILY | 8N-9302 | 08 | 001 | AIR CLEANER GP |
| NPR | ILY | 9Y-5563 | 00 | 002 | FUMES DISPOSAL GP |

| | | | | | |
|-----|-----|----------|----|-----|-------------------------------|
| | IL | 102-6838 | 01 | 001 | AIR CLEANER |
| | IL | 102-6854 | 00 | 001 | INSULATION AR |
| | IL | 103-1037 | 00 | 001 | 30 DBA MUFFLER INSULATION |
| NPR | ILY | 141-7896 | 02 | 001 | TANK GP-FUEL |
| NPR | ILY | 151-5673 | 01 | 001 | CONNECTION GP-ELECTRICAL |
| | IL | 102-6831 | 00 | 001 | NEOPRENE VIBRATION PADS |
| | I | OP-8707 | | 001 | QUOTE NO. |
| | I | OP-9583 | | 001 | ENGINE RENTAL INVENTORY PLAN |
| | I | OP-1578 | | 001 | PRIME PLUS 10% RATING-3500 |
| | I | PP3949 | 00 | 001 | 1220 BHP 840 GEN KW WOF 60 HZ |
| | I | 2T-9164 | 00 | 001 | 910 KW @ 1800 RPM (1220 BHP) |

SHIPPED LOOSE

| | | | | | |
|-----|---|----------|--|-----|-----------------------------|
| NPR | S | 3E-3361 | | 001 | PLUG AS-CONNECTOR |
| NPR | S | 3E-3362 | | 001 | WEDGE-PLUG LOCK |
| NPR | S | 8N-2555 | | 002 | FILTER-SOOT |
| NPR | S | 8T-8730 | | 002 | SOCKET-CONNECTOR |
| NPR | S | 131-4254 | | 001 | KIT-PARTS |
| NPR | S | 131-4724 | | 001 | KIT-PARTS |
| | S | SEBP2208 | | 001 | PTSBK |
| | S | SEBP2414 | | 001 | PTSBK |
| | S | SEBU6042 | | 001 | SUPP (GEN ONLY) 1632-05 (A) |
| | S | SEBU6251 | | 001 | LUBE |
| | S | SEBU6701 | | 001 | OMM |
| | S | SEBU6918 | | 001 | OMM(GEN ONLY) FL CC06E(A) |
| | S | SEBU6984 | | 001 | SUPP |

| | | | |
|---|----------|-----|----------------------|
| S | SELF5260 | 001 | WARRANTY 140013C2(A) |
| S | SELS0086 | 001 | S.I. |
| S | SELS0117 | 001 | S.I. |
| S | SENR4794 | 001 | DIAGRAM 1634-04 (A) |
| S | ESO | 001 | (PRNT ESO COPY) |
| S | PML | 001 | *REQUIRED DECALS |

Key:

I Installed

Y Separate Illustration

R REMFG PART MAY BE AVAILABLE

L Less Indicator

S Shipped Loose

Copyright 1993 - 2015 Caterpillar Inc.

All Rights Reserved.