

3508B GEN SET ENGINE

Engine Serial Prefix - 4GM (Build Date - 04/2000, Test Date - 04/2000, Ship Date - 04/2000)

▼ ENGINE - ENTIRE GROUP (4GM)

Qty.	NPR	Note	Part No.	Change Level	Req. Qty	Part Name
						<b>FEATURE CODES</b>
		I	KW01000	F	001	1000 EKW W/FAN
		I	508DE04	F	001	3508B 1000 EKW 60 HZ - LO BSFC
		I	OGNP033	F	001	GENERATOR 693 FRAME PM
		I	RPA0033	F	001	692 FRAME GENERATOR REMOVAL
		I	EMCENGU	F	001	ENGLISH DISPLAY UNITS
		I	EMCAM06	F	001	ALARM MODULE - NFPA 99
		I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
		I	CLSSTND	F	001	COOLANT LOSS SENSING
		I	EMCEFR1	F	001	RELAY GP
		I	EMCRMP1	F	001	REM. ANNUNCIATOR PANEL-8 LIGHT
		I	CLS0008	F	001	COOLANT LEVEL SENSOR
		I	SHREL01	F	001	SPACE HEATER RELAY
		I	VIBIS05	F	001	VIBRATION ISOLATORS
		I	VIBIS07	F	001	VIBRATION ISOLATORS - RADIATOR
		I	ACT0003	F	001	ANTIFREEZE
		I	OPADRN4	F	001	OIL PAN DRAIN VALVE
		I	LUBOIL1	F	001	LUBRICATING OIL
		I	FPPRH02	F	001	FUEL PRIMING PUMP, RH MOUNTED
		I	FLN0001	F	001	FLEXIBLE FUEL LINES
		I	FULCOL5	F	001	FUEL COOLER
		I	JWHD001	F	001	JACKET WATER HEATER - DUAL
		I	LWS0001	F	001	LOW WATER TEMPERATURE SWITCH
		I	ELSDLH1	F	001	ELEC START MTR LH DUAL 24V
		I	ALT2442	F	001	CHARGING ALTERNATOR 24V 35 AMP
		I	EXRVAL2	F	001	EXPLOSION RELIEF VALVE
		I	60H-0480	F	001	60HZ 480 VOLTS
		I	MSEPGGN	F	001	GENERAL EPG
		I	TRSGEN4	F	001	GEN SET TEST CHARGE
		I	3508B	F	001	3508B PACKAGE GEN SET
		I	LOWBSFC	F	001	LO BSFC

	I	60HERTZ	F	001	60 HERTZ
	I	STANDBY	F	001	STANDBY POWER APPLICATION 02
	I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL
					<b>PART NUMBERS</b>
	I	PP3571	07	001	1489 BHP 1035 GEN KW WOF 60 HZ
	I	0P-8709		001	STANDBY ALLOW PGM - PGM 344
	I	0P-9889		001	0P9889 STANDBY PLUS PGM 344
	I	LA1294	10	001	3508B 1000 EKW 60 HZ - LO BSFC
	<u>NPR</u>	IY <u>128-2845</u>	06	001	ENGINE AR
	I	3L-0414		001	SINGLE BEARING GEN ALIGN-3500
	I	3L-0432		001	TEST - PKG GEN SET (EMCP II
	I	5N-9582		001	LOW BSFC - 3500B SERIES.
	I	5P-2506	00	001	LITERATURE GP
	<u>NPR</u>	IY <u>7C-1665</u>	07	001	DRIVE GP-FAN
	<u>NPR</u>	I 7C-2459	02	001	GUARD GP-BELT
	<u>NPR</u>	IY <u>7C-7827</u>	04	001	MOUNTING GP-RADIATOR
	<u>NPR</u>	IY <u>7C-7831</u>	06	001	LINES GP-WATER
	<u>NPR</u>	IY <u>7C-8124</u>	04	001	HOUSING & REGULATOR GP
	<u>NPR</u>	IY <u>7E-7528</u>	04	001	RADIATOR GP
	<u>NPR</u>	IY <u>7N-6782</u>	08	001	INDICATOR GP-AIR FILTER CHANGE
	<u>NPR</u>	IY <u>7W-5224</u>	00	001	PULLEY GP-FAN DRIVE
	<u>NPR</u>	IY <u>7W-5639</u>	02	001	FAN GP-BLOWER
	<u>NPR</u>	IY <u>7W-6669</u>	01	001	GUARD GP-DAMPER
	<u>NPR</u>	IY <u>8N-3378</u>	06	001	AIR CLEANER GP
	<u>NPR</u>	IY <u>8N-9639</u>	04	001	GUARD GP-DAMPER
	<u>NPR</u>	IRY <u>9X-9591</u>	01	001	CONVERTER GP-ELECTRICAL
	<u>NPR</u>	IY <u>9Y-4859</u>	00	001	FASTENER GP-RADIATOR
	<u>NPR</u>	I 104-4704	03	001	MOUNTING GP-CONTROL PANEL
	<u>NPR</u>	IY <u>115-3620</u>	03	001	MOUNTING GP-AIR CLEANER
	<u>NPR</u>	I 115-7030	00	001	RAIL GP-ENGINE SUPPORT
	<u>NPR</u>	IY <u>121-4450</u>	10	001	PANEL GP-CONTROL
	<u>NPR</u>	IY <u>121-8856</u>	06	001	CONNECTION GP-ELECTRICAL
	<u>NPR</u>	IY <u>126-9191</u>	02	001	GROUND GP-ELECTRICAL
	<u>NPR</u>	IY <u>134-0058</u>	04	001	WIRING GP-ENGINE
	<u>NPR</u>	I 141-1808	01	001	BOX GP-GENERATOR CONNECTION
	<u>NPR</u>	I 153-0191	02	001	INSTALLATION AR-GENERATOR

	<u>NPR</u>	IY	<u>8N-0339</u>	10	001	DAMPER GP
		I	LA2306	01	001	GENERATOR 693 FRAME PM
	<u>NPR</u>	I	144-1772	01	001	GENERATOR AR
		I	3L-0456		001	PROCEDURE - DVR PROG AND TEST
	<u>NPR</u>	I	121-6202	06	001	REGULATOR GP-VOLTAGE
	<u>NPR</u>	I	145-5138	00	001	WIRING GP-ELECTRONIC CONTROL
		I	LA1951	03	001	GENERATOR REMOVAL - 692 FRAME
		I	121-4713	00	001	INSTRUCTIONS
	<u>NPR</u>	IY	<u>121-4716</u>	01	001	MODULE GP-ALARM
	<u>NPR</u>	IY	<u>121-4712</u>	01	001	PANEL GP-ELECTRONIC
		I	139-1129	00	001	COOLANT SENSING PROGRAM
	<u>NPR</u>	I	134-1157	00	001	RELAY GP
	<u>NPR</u>	I	7C-5296	01	001	PANEL GP-INSTRUMENT
	<u>NPR</u>	IY	<u>121-3362</u>	00	001	SENSOR & MTG GP-RADIATOR
	<u>NPR</u>	I	122-0335	02	001	RELAY GP
	<u>NPR</u>	IY	<u>8N-9567</u>	04	001	MOUNTING GP-ENGINE FLEXIBLE
	<u>NPR</u>	IY	<u>9Y-8234</u>	03	001	MOUNTING GP-RADIATOR
		I	PA3946	05	001	ANTIFREEZE
	<u>NPR</u>	I	2P-9868	04	001	ANTIFREEZE
	<u>NPR</u>	IY	<u>9Y-7876</u>	01	001	DRAIN GP-ENGINE OIL
		I	PA5309	05	001	LUBRICATING OIL
	<u>NPR</u>	I	5P-2586	03	001	OIL
		I	LA3236	00	001	FUEL PRIMING PUMP AR-RH
	<u>NPR</u>	IY	<u>124-3187</u>	04	001	LINES GP-FUEL PRIMING
	<u>NPR</u>	IY	<u>165-9154</u>	02	001	PUMP GP-FUEL PRIMING
	<u>NPR</u>	IY	<u>5N-2438</u>	05	001	LINES GP-FLEXIBLE FUEL
	<u>NPR</u>	IY	<u>7E-6634</u>	04	001	COOLER GP-FUEL
		I	PA4361	06	001	JACKET WATER HEATER - DUAL
	<u>NPR</u>	IY	<u>7E-6247</u>	03	001	HEATER GP-JACKET WATER
	<u>NPR</u>	IY	<u>6I-1039</u>	04	001	MOUNTING GP-JACKET WTR HEATER
	<u>NPR</u>	IY	<u>6I-1040</u>	06	001	MOUNTING GP-JACKET WTR HEATER
	<u>NPR</u>	I	3E-0264	02	001	SWITCH GP-TEMPERATURE
		I	PA2479	05	001	ELECTRIC STARTING MOTOR LH
	<u>NPR</u>	IY	<u>7C-0527</u>	02	001	STARTING MOTOR GP-ELECTRIC
		I	LA0427	08	001	CHARGING ALTERNATOR 24V 35AMP
	<u>NPR</u>	IY	<u>7C-4803</u>	02	001	ALTERNATOR GP-CHARGING

	<u>NPR</u>	IY	<u>7E-4836</u>	04	001	MOUNTING GP-ALTERNATOR
	<u>NPR</u>	IY	<u>7W-5780</u>	04	001	GUARD GP-BELT
	<u>NPR</u>	IY	<u>107-7361</u>	01	001	DRIVE GP-ACCESSORY
	<u>NPR</u>	I	133-6468	01	001	WIRE AS-GROUND
	<u>NPR</u>	IY	<u>5N-4830</u>	07	001	VALVE GP-EXPLOSION RELIEF
		I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
		I	0V-1065		001	END USE: GENERAL EPG
		I	0P-1853		001	GEN SET TEST CHARGE
		I	PP3571	07	001	1489 BHP 1035 GEN KW WOF 60 HZ
		I	2T-8404	00	001	1110 KW @ 1800 RPM(1489 BHP)
						<b>SHIPPED LOOSE</b>
	<u>NPR</u>	S	3N-6504		001	HOSE AS
	<u>NPR</u>	S	5F-5990		002	CLIP
	<u>NPR</u>	S	5P-7197		006	WASHER
	<u>NPR</u>	S	7C-5296		001	PANEL GP-INSTRUMENT
	<u>NPR</u>	S	8N-1186		001	HOSE AS
	<u>NPR</u>	S	153-3865		006	MOUNT AS
	<u>NPR</u>	S	171-6719		001	KIT-PARTS
	<u>NPR</u>	SY	<u>171-6721</u>		001	KIT-PARTS
		S	SEBP2414		001	PTSBK
		S	SEBP2449		001	PTSBK
		S	SEBU6042		001	SUPP
		S	SEBU6251		001	LUBE RECOMMENDATION 1632-16(A)
		S	SEBU6916		001	OMM
		S	SEBU6918		001	OMM
		S	SEBU6984		001	SUPP 1632-07 (A)
		S	SELF5308		001	WARRANTY
		S	SELS0086		001	S.I.
		S	SENR4794		001	SCHEMATIC
		S	ESO		001	(PRNT ESO COPY)
		S	PML		001	*REQUIRED DECALS