

C175-16 GENERATOR SET

Engine Serial Prefix - WYB (Build Date - 01/2010, Test Date - 01/2010)

▼ ENGINE - ENTIRE GROUP (WYB)

Qty.	NPR	Note	Part No.	Change Level	Req. Qty	Part Name
		I	LF0072	11	001	ENGINE AR - 60 HZ, LOW BSFC -
	<u>NPR</u>	IY	<u>239-2330</u>	12	001	ENGINE AR
	<u>NPR</u>	IY	<u>286-4579</u>	02	001	PUMP GP-FUEL TRANSFER
	<u>NPR</u>	IY	<u>304-9602</u>	07	001	LINES GP-FUEL INJECTION
	<u>NPR</u>	IY	<u>328-2001</u>	00	001	RAIL GP-FUEL
	<u>NPR</u>	IY	<u>249-6368</u>	05	001	FILLER GP-ENGINE OIL
	<u>NPR</u>	IY	<u>267-2195</u>	02	001	PUMP GP-ENGINE OIL
	<u>NPR</u>	IY	<u>267-2216</u>	03	001	LINES GP-TURBOCHARGER OIL
	<u>NPR</u>	IY	<u>243-6449</u>	07	001	MOUNTING GP-TURBOCHARGER
	<u>NPR</u>	IY	<u>325-2656</u>	01	003	MANIFOLD GP-INLET
	<u>NPR</u>	IY	<u>325-2655</u>	01	001	MANIFOLD GP-INLET
	<u>NPR</u>	IY	<u>293-5007</u>	03	001	LINES GP-AFTERCOOLER AIR
	<u>NPR</u>	IY	<u>293-6557</u>	03	001	LINES GP-AIR
	<u>NPR</u>	IY	<u>293-6558</u>	03	001	LINES GP-AIR
	<u>NPR</u>	IY	<u>249-3999</u>	12	001	COVER GP-FLYWHEEL HOUSING
	<u>NPR</u>	IY	<u>254-5899</u>	10	001	COVER GP-FRONT HOUSING
	<u>NPR</u>	IY	<u>283-9331</u>	01	001	LIFTING GP-ENGINE
	<u>NPR</u>	SY	<u>284-8332</u>	00	001	LIFTING GP-ENGINE
	<u>NPR</u>	IY	<u>325-2666</u>	03	016	VALVE MECHANISM GP
	<u>NPR</u>	IY	<u>330-4461</u>	01	001	HOUSING GP-FRONT
	<u>NPR</u>	IY	<u>247-1880</u>	04	016	WIRING GP-UNIT INJECTOR
	<u>NPR</u>	IY	<u>247-1893</u>	06	001	SENSOR GP-SPEED
	<u>NPR</u>	IY	<u>334-5951</u>	02	001	SENSOR GP-ENGINE
	<u>NPR</u>	IY	<u>250-0864</u>	09	001	SENSOR GP-TEMP & PRESS
	<u>NPR</u>	IY	<u>250-0865</u>	05	001	SENSOR GP-TEMP & PRESS
	<u>NPR</u>	IY	<u>330-5197</u>	00	001	SENSOR GP-ENGINE
	<u>NPR</u>	IY	<u>250-0867</u>	08	001	SENSOR GP-TEMP & PRESS
	<u>NPR</u>	IY	<u>307-8716</u>	00	001	SENSOR GP-ENGINE
	<u>NPR</u>	IY	<u>330-5185</u>	01	001	SENSOR GP-SPEED
	<u>NPR</u>	IY	<u>250-1792</u>	02	001	PLUG GP-CYLINDER BLOCK

PART NUMBERS

	NPR	IY	250-9989	02	001	PLUG GP-CYLINDER BLOCK
	NPR	IY	278-7303	02	001	SENSOR GP-SPEED
	NPR	IY	278-7340	01	001	MOUNTING GP-CIRCUIT BREAKER
	NPR	IY	334-5935	01	001	WIRING GP-ENGINE
	NPR	IY	250-6720	06	001	PUMP GP-AUXILIARY WATER
	NPR	IY	254-5910	09	001	LINES GP-WATER
	NPR	IY	255-4435	05	001	DRAIN GP-COOLANT
	NPR	IY	256-5980	04	001	CONNECTION GP-WATER
	NPR	IY	262-9227	00	001	VALVE GP-FLUID SAMPLING
	NPR	IY	274-7711	03	001	MOUNTING GP-AFTERCOOLER
	NPR	IY	286-4571	03	001	VALVE GP-THERMOSTATIC
	NPR	IY	334-6157	00	001	DAMPER GP
	NPR	IY	348-8249	01	001	COOLER GP-ENGINE OIL
	NPR	IY	339-0322	00	001	FLYWHEEL GP
	NPR	I	344-2930	00	001	HOUSING GP-FLYWHEEL
	NPR	IY	347-8859	00	001	MOUNTING GP-CONTROL
	NPR	IY	347-8864	00	001	SENSOR GP-ENGINE
	NPR	IY	348-8245	00	001	LINES GP-OIL SUPPLY
	NPR	IY	347-9093	00	001	SHIELD GP-MANIFOLD
	NPR	IY	333-9201	01	001	LINES GP-WATER
	NPR	IY	287-7028	01	001	ELBOW GP-WATER
	NPR	IY	287-7040	00	001	FASTENER GP-REGULATOR HOUSING
	NPR	IY	302-5913	01	001	LINES GP-VENT
	NPR	IY	328-7085	02	001	MOUNTING GP-PUMP
	NPR	IY	311-6036	03	001	GEAR GP-FRONT
	NPR	IY	313-7600	01	001	PUMP GP-WATER
	NPR	IY	302-5915	00	001	PLUG GP-WATER LINES
	NPR	IY	289-6083	01	001	MANIFOLD GP-EXHAUST
	NPR	IY	289-6087	01	006	MANIFOLD GP-EXHAUST
	NPR	IY	296-8500	03	001	MANIFOLD GP-EXHAUST
	NPR	IY	327-0844	01	001	LINES GP-FUEL INJECTION
	NPR	IY	345-8469	00	001	LINES GP-WATER
	NPR	IY	345-8467	00	001	LINES GP-WATER
	NPR	IY	345-8468	00	001	LINES GP-WATER
	NPR	IY	263-6779	07	001	SENSOR GP-TEMPERATURE
	NPR	IY	302-5910	00	001	PLUG GP-WATER LINES

	<u>NPR</u>	IY	<u>326-1426</u>	02	001	MANIFOLD GP-FUEL
	<u>NPR</u>	IY	<u>326-1427</u>	01	001	LINES GP-FUEL INJECTION
	<u>NPR</u>	IY	<u>326-1456</u>	02	001	REGULATOR GP-OIL PRESSURE
	<u>NPR</u>	IY	<u>325-7849</u>	01	001	WIRING GP-ENGINE
	<u>NPR</u>	IY	<u>270-6860</u>	02	001	PLUG GP-ENGINE
	<u>NPR</u>	IL	331-3675	00	016	LINES GP-FUEL INJECTION
	<u>NPR</u>	IY	<u>284-8351</u>	00	016	LINES GP-FUEL INJECTION
	<u>NPR</u>	ILY	<u>331-3652</u>	00	014	COVER GP-VALVE MECHANISM
	<u>NPR</u>	IY	<u>284-8334</u>	02	014	COVER GP-VALVE MECHANISM
	<u>NPR</u>	IL	331-3651	01	002	COVER GP-VALVE MECHANISM
	<u>NPR</u>	IY	<u>284-8333</u>	03	002	COVER GP-VALVE MECHANISM
		I	0V-2329		001	PRODUCTION CORRECTION
	<u>NPR</u>	ILY	<u>205-7860</u>	10	001	FILM GP
		I	LF0070	05	001	REF 175DE01, LF0015, LF0100
	<u>NPR</u>	IY	<u>283-9369</u>	01	002	COVER GP-ENGINE LIFTING EYE
	<u>NPR</u>	IY	<u>254-2064</u>	04	001	DRAIN GP-ENGINE OIL
		I	3L-0284		001	*****TEST - PKG GEN SET*****
		I	3L-0467		001	TWO BEARING GEN ALIGNMENT-3500
	<u>NPR</u>	IY	<u>328-7087</u>	01	001	LINES GP-FUEL COLLECTOR
	<u>NPR</u>	IY	<u>226-7563</u>	05	001	PUMP GP-FUEL PRIMING
	<u>NPR</u>	IY	<u>262-1136</u>	03	001	VALVE GP-FLUID SAMPLING
	<u>NPR</u>	IY	<u>327-0853</u>	02	001	FILTER GP-FUEL
	<u>NPR</u>	IY	<u>336-3623</u>	04	001	LINES GP-FUEL FILTER
	<u>NPR</u>	IY	<u>328-1999</u>	00	001	LINES GP-FUEL
	<u>NPR</u>	SY	<u>323-3913</u>	00	001	SENSOR GP-COOLANT LEVEL
	<u>NPR</u>	IY	<u>338-0683</u>	01	001	GUARD GP-DAMPER
	<u>NPR</u>	IY	<u>348-2177</u>	00	001	COVER GP-ENGINE
	<u>NPR</u>	IY	<u>283-1676</u>	02	001	FASTENER GP-DAMPER
		I	LF0082	02	001	PRIMARY FUEL FILTER W/O PKG MT
	<u>NPR</u>	SY	<u>323-3914</u>	01	001	LINES GP-FUEL FILTER
	<u>NPR</u>	SY	<u>247-4908</u>	01	001	LINES GP-FUEL
	<u>NPR</u>	SY	<u>331-3524</u>	04	001	FILTER GP-PRIMARY FUEL
	<u>NPR</u>	SY	<u>334-5894</u>	01	001	SENSOR GP-ENGINE
	<u>NPR</u>	IY	<u>307-8694</u>	03	001	MOUNTING GP-CIRCUIT BREAKER
		I	LF0091	01	001	COVER GP (W/O PRELUBE)
	<u>NPR</u>	IY	<u>322-8260</u>	00	001	COVER GP-ENGINE

	<u>NPR</u>	IY	<u>285-3958</u>	00	001	PLUG GP-CONNECTOR
		I	LF0092	00	001	PAN & GAGE GP-OIL
	<u>NPR</u>	IY	<u>256-5982</u>	02	001	GAUGE GP-OIL LEVEL (DIPSTICK)
	<u>NPR</u>	IY	<u>311-6020</u>	01	001	PAN GP-OIL
		I	LF0099	05	001	FILTER GP - PRIMARY OIL
	<u>NPR</u>	IY	<u>327-0850</u>	02	001	LINES GP-ENGINE OIL
	<u>NPR</u>	IY	<u>327-0851</u>	01	001	LINES GP-ENGINE OIL
	<u>NPR</u>	IY	<u>345-8473</u>	00	001	MOUNTING GP-OIL FILTER
	<u>NPR</u>	I	347-8857	00	001	FILTER GP-ENGINE OIL
		I	LF0208	04	001	THERMOCOUPLE GP
	<u>NPR</u>	IY	<u>325-7847</u>	02	001	THERMOCOUPLE GP
	<u>NPR</u>	IY	<u>334-5947</u>	01	001	WIRING GP-ENGINE
	<u>NPR</u>	IY	<u>334-5891</u>	02	001	WIRING GP-ENGINE
	<u>NPR</u>	IY	<u>334-5942</u>	00	001	BOX GP-CONTROL
		I	LF0094	00	001	COVER GP - CRANKCASE
	<u>NPR</u>	IY	<u>249-4015</u>	04	014	COVER GP-CYLINDER BLOCK
		I	LF0095	00	001	PLUG GP (ETHER)
	<u>NPR</u>	IY	<u>285-3938</u>	00	001	PLUG GP-ENGINE
	<u>NPR</u>	IY	<u>285-3953</u>	00	001	PLUG GP-CONNECTOR
	<u>NPR</u>	IY	<u>285-3954</u>	00	001	PLUG GP-CONNECTOR
	<u>NPR</u>	IY	<u>285-3955</u>	00	001	PLUG GP-CONNECTOR
	<u>NPR</u>	IY	<u>309-6470</u>	00	001	PLUG GP-ENGINE
		I	LF0245	01	001	SINGLE STAGE ACL W/ SERV IND
	<u>NPR</u>	IY	<u>288-8379</u>	04	001	AIR CLEANER GP
	<u>NPR</u>	IY	<u>322-5760</u>	02	001	INDICATOR GP-AIR FILTER CHANGE
	<u>NPR</u>	IY	<u>335-3205</u>	00	001	CAP GP-AIR CLEANER
		I	LF0161	00	001	MOTOR GP - DUAL ELECTRIC START
	<u>NPR</u>	IY	<u>276-8882</u>	02	001	STARTING MOTOR GP-ELECTRIC
	<u>NPR</u>	IY	<u>285-3957</u>	00	001	RECEPTACLE GP-ELECTRICAL
		I	LF0057	02	001	COVER GP (2)- STARTER LOCATION
	<u>NPR</u>	IY	<u>250-6830</u>	03	002	COVER GP-FLYWHEEL HOUSING
		I	252-7394	00	001	INSTRUCTIONS
		I	LF0089	02	001	OIL - BULK
	<u>NPR</u>	I	8T-9548	05	606	OIL
		I	LF0243	01	001	FUMES DISPOSAL
	<u>NPR</u>	IY	<u>276-2723</u>	07	001	BREATHING GP

	<u>NPR</u>	SY	<u>259-9105</u>	02	001	FUMES DISPOSAL GP
		I	LF0223	02	001	CHARGING ALTERNATOR
	<u>NPR</u>	IY	<u>276-8890</u>	00	001	ALTERNATOR GP-CHARGING
	<u>NPR</u>	IY	<u>276-8885</u>	07	001	BELT TENSIONER GP
	<u>NPR</u>	IY	<u>263-6751</u>	04	001	WIRING GP-ALTERNATOR
	<u>NPR</u>	IY	<u>307-8727</u>	02	001	GUARD GP-BELT
	<u>NPR</u>	IY	<u>341-4065</u>	00	001	MOUNTING GP-ALTERNATOR
	<u>NPR</u>	IY	<u>278-7393</u>	03	001	WIRING GP-ENGINE
	<u>NPR</u>	IY	<u>346-0052</u>	00	001	WIRING GP-JACKET WATER HEATER
	<u>NPR</u>	SY	<u>284-8366</u>	01	001	LIFTING GP-ENGINE
		I	LF0231	00	001	LANGUAGE MARKINGS - ENGLISH
		S	5P-2506	00	001	LITERATURE GP
	<u>NPR</u>	IY	<u>269-2551</u>	02	001	FITTING GP-EXHAUST
		I	289-6091	00	001	PRESERVATION GP
		I	LL6019	00	001	3688 BHP 2500 GEN KW W/F 60 HZ
		I	0K-8533		001	2750 BKW (3688 BHP) @ 1800 RPM
		I	0V-3466		001	LOW BSFC NON-CERTIFIED
		I	0V-1065		001	END USE: GENERAL EPG
						SHIPPED LOOSE
		S			002	PACK IN CARTON ONLY INFO(A)
		S	ESO		001	(PRNT ESO COPY)
		S	PML		001	*REQUIRED DECALS
	<u>NPR</u>	S	2P-1293		001	LOCKNUT
	<u>NPR</u>	S	2Y-5829		012	NUT
	<u>NPR</u>	S	5P-8245		006	WASHER-HARD
	<u>NPR</u>	S	6B-5072		002	BUSHING-REDUCING
		SY	<u>6L-4502</u>		001	CHART-PLATE & FILM
	<u>NPR</u>	S	6V-1820		009	BOLT
	<u>NPR</u>	S	6V-3582		004	CLAMP-HOSE
	<u>NPR</u>	S	6V-5696		006	BOLT
	<u>NPR</u>	S	6V-5839		009	WASHER
	<u>NPR</u>	S	6V-5843		008	BOLT
	<u>NPR</u>	S	6V-5844		002	BOLT
	<u>NPR</u>	S	6V-7981		004	BOLT
	<u>NPR</u>	S	6V-8635		001	CONNECTOR
	<u>NPR</u>	S	6V-8997		001	UNION

	NPR	S	6V-8998	001	UNION
	NPR	S	6V-9005	001	ELBOW
	NPR	S	6V-9172	001	NUT
	NPR	S	6V-9832	001	CAP AS
	NPR	S	6V-9833	001	CAP AS
	NPR	S	6V-9854	001	ELBOW
	NPR	S	7X-7729	004	WASHER
	NPR	S	8T-4121	004	WASHER-HARD
	NPR	S	8T-4133	002	NUT
	NPR	S	8T-4182	002	BOLT
	NPR	S	8T-4189	002	BOLT
	NPR	S	8T-4196	002	BOLT
	NPR	S	8T-4224	002	WASHER-HARD
	NPR	S	9X-2327	024	WASHER
	NPR	S	9X-8268	002	WASHER
	NPR	S	107-9610	001	HOSE AS
	NPR	S	120-5867	002	CLIP
	NPR	SY	204-2518	002	SENSOR GP-LIQUID LEVEL
	NPR	S	217-3307	001	HOSE AS
	NPR	S	225-6948	006	SEAL-O-RING
	NPR	S	228-7092	003	SEAL-O-RING
	NPR	S	228-7093	007	SEAL-O-RING
	NPR	S	228-7100	001	SEAL-O-RING
	NPR	S	228-7101	001	SEAL-O-RING
	NPR	S	238-5084	002	SEAL-O-RING
	NPR	S	241-6157	001	PLUG
	NPR	SY	247-4908	001	LINES GP-FUEL
	NPR	SY	259-9105	001	FUMES DISPOSAL GP
	NPR	S	266-0136	001	SENSOR GP-PRESSURE
	NPR	S	274-6720	001	SENSOR GP-PRESSURE
	NPR	S	279-0786	002	CLEVIS
	NPR	S	281-8197	002	TUBE
	NPR	S	283-1132	002	HOSE AS
	NPR	S	283-9337	002	EYE-LIFTING
	NPR	S	283-9355	002	PIN AS
	NPR	SY	284-8332	001	LIFTING GP-ENGINE

	NPR	SY	284-8366	001	LIFTING GP-ENGINE
	NPR	S	298-7175	001	BRACKET
	NPR	S	298-7177	001	HOSE AS
	NPR	S	302-5905	002	BRACKET
	NPR	S	316-9954	003	FILTER AS-WATER SEP & FUEL
	NPR	SY	323-3913	001	SENSOR GP-COOLANT LEVEL
	NPR	SY	323-3914	001	LINES GP-FUEL FILTER
	NPR	SY	331-3524	001	FILTER GP-PRIMARY FUEL
	NPR	SY	334-5894	001	SENSOR GP-ENGINE
	NPR	S	334-8397	001	ELBOW
	NPR	S	335-0721	001	MANIFOLD
	NPR	S	335-1647	001	SUPPORT AS
	NPR	S	352-4668	003	BASE AS-FILTER
		S	SEBU8100	001	OMM
		S	SELF5440	001	WARRANTY
		S	SERP4467	001	PTSCD