

Engine Serial Number - FFH (Build Date - 04/2009, Test Date - 04/2009)

[View Latest Kit Information](#)

▼ ENGINE - ENTIRE GROUP (FFH)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	C15DE9A	F	001	C15 480/227V 60 HZ PKG GEN 9A
		I	OGNPRB9	F	001	GENERATOR 6134F FRAME PREM B9
		I	EMCP33	F	001	EMCP 3.3 CONTROL PANEL INST
		I	EMCTDM1	F	001	*OLD* RTD MODULE
		I	RELEBT1	F	001	RELEBT1
		I	EMCCAS2	F	001	COMMON ALARM/SHUTDOWN RELAY
		I	EMCGRR2	F	001	GENERATOR RUNNING RELAY
		I	CCM0005	F	001	CAN 2
		I	EMCOC01	F	001	OPTION CHASSIS 01
		I	EMCOC02	F	001	OPTION CHASSIS 02
		S	EXCFF25	F	001	FLEXIBLE FITTING
		S	MUFCR37	F	001	MUFFLER-8" CRITICAL 35 DBA
		I	SHK0013	F	001	SPACE HEATER - 230V 13
		I	OVRDG20	F	001	DIGITAL VOLTAGE REGULATOR 20
		I	LUBTMPS	F	001	TEMPERATURE SENSOR GROUP
		I	CNTHTR1	F	001	CONTROL GP-HEATER 240V L-L
		I	JWH0058	F	001	JACKET WATER HEATER 240VAC 3KW
		I	RPA0230	F	001	6114D FRAME GENERATOR REMOVAL
		I	PTSR080	F	001	POWER TERMNL STRIP REMOVAL 080
		I	CBK3P78	F	001	800 AMP 3P CIRCUIT BREAKER 78
		I	CBKAC06	F	001	CIR BRKR AUX CONTACTS 06
		I	SHUNT04	F	001	SHUNT TRIP 24 VDC 04
		I	EMCSDP2	F	001	SPARE DISCRETE I/O PKG (1-2)
		I	NGRDCNB	F	001	NEUTRAL GND CONNECTION -REAR
		I	LOWBSFC	F	001	LO BSFC
		I	EMCCPRR	F	001	CONTROL PANEL MOUNTING - REAR
		I	60H-0480	F	001	60HZ 480 VOLTS

	I	STANDBY	F	001	STANDBY POWER APPLICATION	
	I	MSEPGGN	F	001	GENERAL EPG	
	I	TRSGEN7	F	001	PGS TEST REPORT @ 0.8 PF	
	I	TRSGEN1	F	001	GENERATOR TEST REPORT	
	I	DPX0001	F	001	DOMESTIC PACK-EXPORT CONTAINER	
	S	LITENGE	F	004	EXTRA ENGLISH LITERATURE (1-6)	
	I	MWCODEF	F	001	STANDBY POWER	
	I	MSCEC70	F	001	ENERGY UTILITIES	
	I	KW00450	F	001	450 EKW W/FAN	
	I	LANENGO	F	001	ENGLISH LANGUAGE OPTION	
	I	800AMP	F	001	800 AMPS	
	I	ESCNONE	F	001	NO EXTENDED SERVICE COVERAGE	
	I	NONULL	F	001	NON UL 2200 LISTED PKG GEN SET	
	I	NOENCLO	F	001	NO ENCLOSURE REQUIRED	
	NPR	IL	287-4915	F	001	GUARD GP-PULLEY
	NPR	IY	260-4784	F	001	RADIATOR GP
	NPR	ILY	287-4914	F	001	RADIATOR GP
		IL	272-9969	F	001	MODIFICATION AR-ENGINE
	NPR	I	272-6169	F	001	MODIFICATION AR-ENGINE
	NPR	IL	270-0096	F	001	HARNESS AS-MOTOR
		N	0V-8707	F	001	DTO QUOTE DESIGN FEE
						PART NUMBERS
		I	DK4520	04	001	ENGINE AR-C15 DITA PGS
		IY	287-3367		001	GENERAL AR-GENSET
	NPR	IY	286-4920	07	001	ENGINE AR-COMplete
		S	3L-0284		001	TEST - PKG GEN SET
		S	252-7405	00	001	***** TEST - GEN ELE SYS LE *
	NPR	IY	265-0740		001	FILM GP
		IY	278-7096	01	001	FILM GP
		S	5P-2506	00	001	LITERATURE GP
	NPR	IY	268-0889		001	BASE GP-ENGINE & GENERATOR
	NPR	IY	260-0556		001	MOUNTING GP-BEAM
	NPR	IY	233-9391		001	AIR CLEANER GP
	NPR	IY	233-9351		001	COUPLING GP-GENERATOR
	NPR	IY	274-1340		001	SUPPORT GP-BATTERY
	NPR	IY	270-3125		001	BATTERY GP

	NPR	IY	144-7184	02	004	COVER GP-ENGINE LIFTING EYE
	NPR	IY	264-0256		001	DRAIN GP-OIL
	NPR	IY	263-5120		001	FUMES DISPOSAL GP
	NPR	IY	244-9579		001	COVER GP-BASE
	NPR	IY	261-5613		001	HARNESS AS-POWER
	NPR	IY	261-0001		001	COVER GP-CONTROL PANEL
	NPR	IY	258-6763		001	ENCLOSURE AS
	NPR	I	236-4395		001	COVER GP-INSTRUMENT PANEL
	NPR	IY	258-6791		001	PANEL GP-ELECTRONIC
	NPR	IY	258-6790		001	MOUNTING GP-BUS BAR
	NPR	IY	258-6782		001	DOOR GP
	NPR	IY	258-6776		001	MOUNTING GP-DIVIDER PLATE
	NPR	IY	258-6773		001	MOUNTING GP-BRACKET
	NPR	IY	240-0170		001	BOX GP-CONNECTION
	NPR	IY	266-7116		001	HARNESS AS-ENGINE
		S	239-5745		001	DIAGRAM-WIRING
		S	239-8007		001	DIAGRAM-WIRING
	NPR	IY	240-1622		001	CABLE GP
	NPR	IY	241-6078		001	SEAL GP-ENCLOSURE
	NPR	IY	262-9635		001	MOUNTING GP-WIRING
	NPR	IY	266-2701		001	COVER GP-CONTROL PANEL
	NPR	IY	268-8667		001	PLUG GP-BOX
		S	261-5834		001	DIAGRAM-WIRING
	NPR	I	205-7860	10	001	FILM GP
	NPR	IY	253-3023		001	FASTENER GP-INSTRUMENT PANEL
	NPR	IY	239-6758		001	MOUNTING GP-CONTROL PANEL
	NPR	IY	246-1428		001	HARNESS AS-WIRING
	NPR	IY	239-0410		001	TRANSFORMER GP-CURRENT
	NPR	IY	240-1621		002	WIRING GP-GENERATOR
	NPR	IY	286-8875		001	FASTENER GP-WIRING HARNESS
		I	DK2794	00	001	GENERATOR AR-6100 FRAME, PM, O
	NPR	IY	235-1213	00	001	GENERATOR AR
		I	DK1593	03	001	CONTROL PANEL EMCP III
	NPR	IY	261-5133		001	CONTROL GP-GENERATOR SET
		I	265-7866		001	DIAGRAM-WIRING
		I	DK2127	01	001	RTD MODULE

	NPR	IY	261-8427		001	CONTROL GP-ENGINE MONITORING
		I	DK1608	01	001	ANNUNCIATOR MODULE-LOCAL
	NPR	IY	258-6799		001	MOUNTING GP-CONTROL PANEL
		I	DK9120	00	001	RELAY END BLOCK TERMINALS
	NPR	IY	292-5967		001	PANEL GP-ELECTRICAL
		I	DK1615	01	001	RELAY GP-COMMON ALARM/SHUTDOWN
	NPR	IY	261-5828		001	RELAY GP
		I	DK1616	01	001	RELAY GP-RUNNING
	NPR	IY	261-6623		001	PANEL GP-ELECTRICAL
		I	DK2129	00	001	CAN2 CONTROL GP
	NPR	IY	261-8479		001	WIRING GP-GENERATOR
		I	DK1612	00	001	CHASSIS OPTION 1
	NPR	IY	258-6778		001	PANEL GP-ELECTRONIC
		I	DK1613	00	001	CHASSIS OPTION 2
	NPR	IY	258-6795		001	MOUNTING GP-TERMINAL STRIP
		I	DK2779	01	001	STAINLESS STEEL FLEX EXH FITTI
	NPR	SY	243-2907		001	FITTING GP-EXHAUST
		I	DK2782	02	001	MUFFLER - 35 DBA ATTENUATION
	NPR	S	244-3709		001	MUFFLER GP
		I	DK1620	03	001	SPACE HEATER
	NPR	I	327-0286		001	HEATER GP-SPACE
		I	DK1819	00	001	DIGITAL VOLTAGE REGULATOR
	NPR	IY	259-0983		001	MOUNTING GP-VOLTAGE REGULATOR
	NPR	IY	261-8430		001	SWITCH AS
		I	254-1260		001	DIAGRAM-WIRING
		I	DK4942	00	001	SENSOR GP-TEMPERATURE
	NPR	IY	269-8078		001	SENSOR GP-TEMPERATURE
		I	DK2586	00	001	CONTROL GP-HEATERS
	NPR	IY	261-7137		001	CONTACTOR GP
		I	DK4621	04	001	JACKET WATER COOLANT HEATER
	NPR	IY	196-2236	03	001	HEATER GP-JACKET WATER
	NPR	IY	183-2899		001	HARNESS AS-WIRING
		I	275-7659		001	NOTE-HEATER
	NPR	IY	295-2249		001	MOUNTING GP-JACKET WTR HEATER
	NPR	IY	282-9957		001	CIRCUIT BREAKER GP
		I	DK0576	00	001	REMOVAL AR-GENERATOR, 6100 FRA

	I	DK6972	00	001	PWR TERMINAL STRIP REMOVL-800A
	I	DK7044	03	001	800 AMP 3P CIRCUIT BREAKER 78
	NPR	IY 243-3540		001	CIRCUIT BREAKER GP
	NPR	IY 258-6812		001	COVER GP-ENCLOSURE
	NPR	IY 243-5599		001	COVER GP-ACCESS
	NPR	IY 260-0568		001	BRACKET GP-MOUNTING
	NPR	IY 277-3571		001	SEAL GP-ENCLOSURE
	NPR	IY 284-9190		001	TERMINAL GP-CIRCUIT BREAKER
	NPR	IY 295-2373		001	CONNECTION GP-TERMINAL STRIP
	I	DK1869	01	001	CIR BRKR AUX CONTACTS 06
	NPR	IY 143-7886	00	001	SWITCH AS
	NPR	IY 237-8962		002	HARNESS AS-WIRING
	I	DK0634	02	001	SHUNT TRIP (24 VDC)
	NPR	IY 243-4797		001	SHUNT-TRIP
	NPR	IY 259-0240		001	TRANSFORMER GP-CURRENT
	I	DK1606	01	001	SPARE DISCRETE I/O PKG
	NPR	IY 261-8428		001	CONTROL GP-ENGINE MONITORING
	NPR	I 253-3028		001	CONNECTION GP-GENERATOR LEADS
	I	5N-9582		001	LOW BSFC STRATEGY
	I	DK7424	00	001	C15 BRAID CONN 800A BREAKER
	NPR	IY 239-3812		001	DUCT GP-CABLE
	NPR	IY 330-0995	00	001	CONNECTION GP-GENERATOR LEADS
	NPR	IY 281-4494		001	MOUNTING GP-CONTROL PANEL
	NPR	IY 272-2205		001	SUPPORT GP-CABLE
	I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
	I	9Y-8156		001	NOTE - STAMP FOR STANDBY POWER
	I	0V-1065		001	END USE: GENERAL EPG
	I	0P-1803		001	GEN SET TEST CHG AT 0.8 PF
	I	0P-1530		001	GENERATOR TEST REPORT
	I	3L-0334		001	NAMEPLATE INFORMATION
	NPR	I 274-2195	01	001	FILM-WARNING
	I	0P-7824		001	DOMESTIC PACK-EXPORT CONTAINER
	S	0P-9715		004	EXTRA ENGLISH LITERATURE (1-6)
	I	PP5619	00	001	450 EKW W/FAN
	I	0K-7100	00	001	527 KW (707 BHP) @ 1800 RPM
	I	DK3872	00	001	ENGLISH LANGUAGE OPTION

	NPR	I	254-6368	06	001	ELECTRONICS GP-GENERATOR SET
		I	0V-2329		002	PRODUCTION CORRECTION
	NPR	IY	254-1490		001	GUARD GP-ENGINE
		I	0V-2330		003	DTO QUOTE CORRECTION
		I	DK4633	02	001	RADIATOR REMOVAL
		I	0P-9799		001	STANDARD GEN SET TVA REPORT SHIPPED LOOSE
		S			006	
		S	ESO		001	(PRNT ESO COPY)
		S	PML		001	*REQUIRED DECALS
	NPR	S	5H-8331		001	GASKET
		SY	6L-4502		001	CHART-PLATE & FILM
	NPR	S	6V-3532		008	BOLT
	NPR	S	6V-5686		004	BOLT
	NPR	S	6V-7742		008	NUT-FULL
	NPR	S	8T-1757		004	NUT
	NPR	S	8T-3282		016	WASHER-HARD
	NPR	S	9X-8268		008	WASHER
	NPR	S	113-9848		001	GASKET
	NPR	S	145-4933		001	FLANGE
	NPR	S	220-5619		002	CLAMP-EXHAUST
	NPR	S	227-3019		001	TUBE
	NPR	S	235-3330		001	TUBE AS
	NPR	SY	243-2907		001	FITTING GP-EXHAUST
	NPR	S	243-6277		001	MUFFLER AS
	NPR	S	243-6278		001	MUFFLER AS
	NPR	S	244-1878		001	ADAPTER AS
	NPR	S	244-3709		001	MUFFLER GP
		S	SEBP4325		005	PTSBK
		S	SEBU6251		005	LUBE 140019B2(A)
		S	SEBU7909		005	OMM
		S	SELF5419		005	WARRANTY
		S	SERP4325		005	PTSCD

Key:

I Installed

S Shipped Loose

L Less Indicator

Y Separate Illustration

N Not Installed