

3512 GEN SET ENGINE

Engine Serial Number - 24Z (Build Date - 01/1998, Test Date - 01/1998)

ENGINE - ENTIRE GROUP (24Z)

Qty.	NPR	Note	Part No.	ChangeReq. Level	Qty	Part Name
		I	LA1382	07	001	3512 DITA/XQ 1250 RENTAL PKG
	<u>NPR</u>	IRY	<u>2W-8405</u>	26	001	ENGINE AR
	<u>NPR</u>	I	2P-9868	04	001	ANTIFREEZE
		I	3L-0414		001	SINGLE BEARING GEN ALIGN-3500
	<u>NPR</u>	IY	<u>3N-4905</u>	03	001	HOSE AS
	<u>NPR</u>	IY	<u>4P-7610</u>	02	001	SENSOR GP-SPEED
	<u>NPR</u>	IY	<u>4W-4753</u>	02	001	SWITCH GP-MAGNETIC
		I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
		I	5N-9623		001	NOTE GOVERNOR WIRING
		I	5P-2506	00	001	LITERATURE GP
	<u>NPR</u>	I	5P-2586	03	001	OIL
	<u>NPR</u>	IY	<u>7C-0526</u>	01	001	STARTING MOTOR GP-ELECTRIC
	<u>NPR</u>	IY	<u>7E-2858</u>	00	001	ALTERNATOR GP-CHARGING
	<u>NPR</u>	IY	<u>7E-4836</u>	03	001	MOUNTING GP-ALTERNATOR
	<u>NPR</u>	IY	<u>7E-6247</u>	02	001	HEATER GP-JACKET WATER
	<u>NPR</u>	IY	<u>7E-6681</u>	03	001	COOLER GP-FUEL
	<u>NPR</u>	IY	<u>7N-6782</u>	07	001	INDICATOR GP-AIR FILTER CHANGE
	<u>NPR</u>	IY	<u>7W-3953</u>	08	001	DRIVE GP-FAN
	<u>NPR</u>	IY	<u>7W-5224</u>	00	001	PULLEY GP-FAN DRIVE
	<u>NPR</u>	IY	<u>7W-5639</u>	02	001	FAN GP-BLOWER
	<u>NPR</u>	IY	<u>7W-5780</u>	03	001	GUARD GP-BELT
	<u>NPR</u>	IY	<u>7W-6669</u>	01	001	GUARD GP-DAMPER
	<u>NPR</u>	IY	<u>7W-7214</u>	04	001	GUARD GP-BELT
	<u>NPR</u>	I	7W-8708	00	001	INSTALLATION AR-GENERATOR
	<u>NPR</u>	IY	<u>7W-9032</u>	04	001	ENCLOSURE GP-WIRING
	<u>NPR</u>	IY	<u>7W-9465</u>	04	001	PUMP GP-FUEL PRIMING
	<u>NPR</u>	IY	<u>7W-9704</u>	05	001	PUMP GP-SUMP
	<u>NPR</u>	IY	<u>8N-9302</u>	08	001	AIR CLEANER GP
	<u>NPR</u>	IY	<u>8N-9639</u>	04	001	GUARD GP-DAMPER
	<u>NPR</u>	I	9Y-0166	00	001	GENERATOR AR
	<u>NPR</u>	IY	<u>9Y-6676</u>	03	001	RADIATOR GP
		I	103-0020	00	001	PACKAGING AR
	<u>NPR</u>	IY	<u>104-9727</u>	03	001	MOUNTING GP-CONTACTOR
	<u>NPR</u>	IY	<u>105-2048</u>	02	001	SENSOR & MTG GP-RADIATOR

PART NUMBERS

	<u>NPR</u>	IY	<u>105-3255</u>	00	001	MOUNTING GP-CIRCUIT BREAKER
	<u>NPR</u>	IY	<u>105-7183</u>	02	001	FASTENER GP-WIRING HARNESS
	<u>NPR</u>	I	115-3056	02	001	CONNECTION GP-TERMINAL STRIP
	<u>NPR</u>	IY	<u>115-7033</u>	00	001	RAIL GP-ENGINE & GEN SUPPORT
	<u>NPR</u>	I	121-6200	01	001	REGULATOR GP-VOLTAGE
	<u>NPR</u>	IY	<u>121-8855</u>	02	001	CONNECTION GP-ELECTRICAL
	<u>NPR</u>	IY	<u>129-2237</u>	01	001	HARNESS AS-WIRING
	<u>NPR</u>	IY	<u>134-3241</u>	01	001	SENSOR GP-TEMP & PRESS
	<u>NPR</u>	IY	<u>136-9369</u>	03	001	MOUNTING GP-JACKET WTR HEATER
	<u>NPR</u>	IY	<u>136-9370</u>	02	001	MOUNTING GP-JACKET WTR HEATER
	<u>NPR</u>	I	141-1808	01	001	BOX GP-GENERATOR CONNECTION
	<u>NPR</u>	IY	<u>141-4987</u>	01	001	COVER GP-GENERATOR
	<u>NPR</u>	I	144-9059	00	001	TRANSFORMER GP-CURRENT
		I	102-6832	00	001	MOUNTING AR-GENERATOR SET
	<u>NPR</u>	IY	<u>103-1033</u>	01	001	MUFFLER GP
		IY	<u>103-1036</u>	01	001	INSULATION AR
	<u>NPR</u>	IY	<u>141-1598</u>	00	001	SWITCH GP-DISCONNECT
	<u>NPR</u>	IY	<u>141-4950</u>	00	001	RAIL GP-SLIDE
	<u>NPR</u>	IY	<u>142-1415</u>	04	001	ENCLOSURE GP-GENERATOR
		I	142-2386	01	001	PLATE & FILM GP
	<u>NPR</u>	I	144-6656	01	001	PACKAGING AR
	<u>NPR</u>	IY	<u>125-9326</u>	00	001	TRANSFORMER GP-POTENTIAL
	<u>NPR</u>	I	129-4337	02	001	CONTROL GP-EMCP ELECTRONIC
	<u>NPR</u>	IY	<u>130-5379</u>	01	001	PARALLELING GP-MANUAL
	<u>NPR</u>	IY	<u>130-5652</u>	00	001	PANEL GP-CONTROL
	<u>NPR</u>	IY	<u>131-2837</u>	02	001	PANEL GP-CONTROL
	<u>NPR</u>	IY	<u>131-7253</u>	03	001	CONTROL GP-GOVERNOR
	<u>NPR</u>	IY	<u>149-6401</u>	00	001	BATTERY GP
	<u>NPR</u>	IY	<u>152-2876</u>	01	001	HARNESS AS-WIRING
	<u>NPR</u>	IY	<u>134-0958</u>	03	001	BUS BAR GP
		I	5N-9955		001	VOLTAGE IDENTIFICATION EPG/GAS
	<u>NPR</u>	IY	<u>9Y-5563</u>	00	001	FUMES DISPOSAL GP
	<u>NPR</u>	IY	<u>140-2674</u>	00	001	VALVE GP-RADIATOR DRAIN
	<u>NPR</u>	IY	<u>141-7883</u>	00	001	BOX AS-STORAGE
	<u>NPR</u>	IY	<u>141-7896</u>	01	001	TANK GP-FUEL
	<u>NPR</u>	IY	<u>146-0806</u>	01	001	DOOR AS-ACCESS
	<u>NPR</u>	IY	<u>146-9838</u>	02	001	PANEL GP-CONTROL
	<u>NPR</u>	IY	<u>149-5237</u>	00	001	ENCLOSURE GP-GENERATOR
	<u>NPR</u>	IY	<u>135-3319</u>	03	001	BATTERY CHARGER GP
	<u>NPR</u>	I	136-2054	01	001	MODULE GP-ALARM

	<u>NPR</u>	IY	<u>147-1165</u>	00	001	SWITCHGEAR AR
	<u>NPR</u>	IY	<u>147-1168</u>	00	001	PANEL GP-SWITCHGEAR
	<u>NPR</u>	IY	<u>147-1947</u>	00	001	TRANSFORMER GP-CURRENT
	<u>NPR</u>	IY	<u>153-0180</u>	00	001	VENT GP-FUEL TANK
		I	9Y-1386	01	001	UNDERCARRIAGE AR
	<u>NPR</u>	IY	<u>149-8779</u>	00	001	HEATER GP-SPACE
		I	157-1861	00	001	INSTRUCTION-SWITCHGEAR
	<u>NPR</u>	I	152-8793	00	001	INSULATION GP-GENERATOR
	<u>NPR</u>	IY	<u>151-5674</u>	00	001	CONNECTION GP-ELECTRICAL
	<u>NPR</u>	IY	<u>130-6481</u>	01	001	INSTALLATION GP-RADIATOR
	<u>NPR</u>	I	149-2477	00	001	SUPPORT AS
		I	131-4406	00	001	TANK-RECOVERY
	<u>NPR</u>	I	150-1959	01	002	LOUVER AS
		IL	102-6854	00	001	INSULATION AR
	<u>NPR</u>	ILY	<u>151-5673</u>	00	001	CONNECTION GP-ELECTRICAL
	<u>NPR</u>	ILY	<u>5N-9527</u>	01	001	FITTING GP-EXHAUST
	<u>NPR</u>	ILY	<u>7N-6967</u>	05	001	FITTING GP-EXHAUST
	<u>NPR</u>	ILY	<u>149-7755</u>	00	001	ENCLOSURE GP-GENERATOR
		I	0P-1578		001	PRIME PLUS 10% RATING-3500
		I	0P-9583		001	ENGINE RENTAL INVENTORY PLAN
		I	0P-9270		001	PRE 01JAN98 PRC PRO PGM641-5
		I	PP2239	01	001	1662 BHP 1150 GEN KW WOF 60 HZ
		I	0T-6412	02	001	1220 KW @ 1800 RPM (1636 BHP)
						<b>SHIPPED LOOSE</b>
	<u>NPR</u>	S	3E-3361		001	PLUG AS-CONNECTOR
	<u>NPR</u>	S	3E-3362		001	WEDGE-PLUG LOCK
	<u>NPR</u>	S	8T-8730		002	SOCKET-CONNECTOR
	<u>NPR</u>	S	131-4724		001	KIT-PARTS
		S	SEBP2414		001	PTSBK
		S	SEBP2573		001	PTSBK
		S	SEBU6042		001	SUPP (GEN ONLY) 1632-05 (A)
		S	SEBU6251		001	LUBE
		S	SEBU6701		001	OMM
		S	SEBU6918		001	OMM(GEN ONLY) FL CC06E(A)
		S	SEBU6984		001	SUPP
		S	SELF5260		001	WARRANTY 140013C2(A)
		S	SELS0086		001	S.I.
		S	SELS0117		001	S.I.
		S	SENR4794		001	DIAGRAM 1634-04 (A)
		S	ESO		001	(PRNT ESO COPY)



S PML

001

\*REQUIRED DECALS