

C-9 INDUSTRIAL ENGINE

Engine Serial Prefix - CLJ (Build Date - 03/2004, Test Date - 03/2004)

▼ ENGINE - ENTIRE GROUP (CLJ)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	HP00300	F	001	300 BHP (224 BKW) W/O FAN
		I	C09DI00	F	001	C-9 ATAAC INDUSTRIAL ENGINE
		I	CGTPS07	F	001	REMOTE SPEED CONTROL
		I	AIH2402	F	001	AIR INLET HEATER - 24 VOLT
		I	RAD0016	F	001	RADIATOR
		I	ALT2485	F	001	CHARGING ALTERNATOR 24V 70 AMP
		I	ALTGD00	F	001	ALTERNATOR GUARD
		I	ALTPL00	F	001	ALT PULLEY 3.69 DIA 2 GROOVE
		I	FANB018	F	001	BLOWER FAN 33 IN
		I	FANPL28	F	001	FAN PULLEY 1:1 RATIO
		I	ELSMLH2	F	001	ELEC START MTR LH 24V
		I	FLN0003	F	001	FLEXIBLE FUEL LINES
		I	FULFLT1	F	001	FUEL FILTER
		I	FULCOL1	F	001	FUEL COOLER
		I	ACL9000	F	001	AIR CLEANER
		I	PCL0004	F	001	PRECLEANER
		I	ENGSP02	F	001	FRONT ENGINE SUPPORT
		I	EXCEL15	F	001	ELBOW - 90 DEGREE
		I	GIPCNT0	F	001	CONTROL 24V
		I	EMSMU02	F	001	EMS MAIN UNIT
		I	OLGAG05	F	001	OIL LEVEL GAGE
		I	LUBOIL1	F	001	LUBRICATING OIL
		I	OSAMVL1	F	001	OIL SAMPLING VALVE
		I	OFLH02	F	001	LH OIL FILLER 02
		I	BAT2402	F	001	24V BATTERY SET-DRY 1000 CCA
		I	BTRCBL1	F	001	BATTERY CABLES
		I	JWH0001	F	001	JACKET WATER HEATER
		I	BTR0001	F	001	BATTERY RACK
		I	MSLOCEP	F	001	LOCOMOTIVE EPG
		I	PBKCD01	F	001	PARTS BOOK-ELECTRONIC
		I	INDUSTR	F	001	APPLICATION
		I	CERTIF2	F	001	EPA & CARB TIER II
		I	INDUSTB	F	001	INDUSTRIAL B RATING

	I	2200RPM	F	001	2200 RPM
	I	EXHFRNT	F	001	FRONT FACING EXHAUST
	I	FWSPFF0	F	001	CUST FWS/PRIMARY FUEL FILTER
	I	PCKNONE	F	001	NO PACKING REQUIRED
					PART NUMBERS
	I	PP4804	01	001	300 BHP WOF 2200 RPM IND "C"
	I	0V-2030		001	DEALER INVENTORY UNIT
	I	PA7722	14	001	C-9 ATAAC INDUSTRIAL ENGINE
	NPR	IY 202-0333	05	001	ENGINE AR-CORE
	I	5P-2506	00	001	LITERATURE GP
	NPR	IY 118-1727	02	001	COVER GP-FRONT HOUSING
	NPR	IY 155-4313	00	001	FASTENER GP-FLYWHEEL
	NPR	IY 155-6615	00	001	FLYWHEEL GP
	NPR	IY 165-4461	07	001	HOUSING & REGULATOR GP
	NPR	IY 165-4462	07	001	PUMP GP-WATER
	NPR	IY 165-4469	13	001	SENSOR GP-ENGINE
	NPR	IY 166-1788	01	001	FASTENER GP-FRONT HOUSING
	NPR	IY 169-3105	05	001	PLUG GP-ENGINE
	NPR	IY 169-3107	03	001	PULLEY GP-CRANKSHAFT
	NPR	IY 175-4131	05	001	COVER GP-VALVE MECHANISM
	NPR	IY 187-3077	05	001	FUMES DISPOSAL GP
	NPR	IY 187-6508	03	001	SEAL GP-CRANKSHAFT
	NPR	IY 192-2832	07	001	LINES GP-ENGINE OIL
	NPR	IY 194-1091	04	001	WIRING GP-ELECTRONIC CONTROL
	NPR	IY 197-2672	03	001	LINES GP-TURBOCHARGER OIL
	NPR	IY 198-1723	02	001	CONTROL & MTG GP-ENGINE ELEK
	NPR	IY 198-6368	01	001	PAN GP-OIL
	NPR	IY 198-6475	02	001	DRAIN GP-ENGINE OIL
	NPR	IY 200-2310	01	001	CONNECTION GP-ELECTRICAL
	NPR	IY 197-6859	02	001	DRIVE GP-WATER PUMP
	NPR	IY 201-9778	05	001	FILTER GP-ENGINE OIL
	NPR	I 9Y-9238	03	001	COVER GP-SHIPPING
	NPR	IY 183-3649	06	001	COVER GP-CYLINDER BLOCK
	NPR	IY 209-2106	04	001	WIRING GP-ELECTRONIC CONTROL
	NPR	IY 165-6934	01	001	DAMPER GP
	I	208-2845	00	001	INSTRUCTIONS
	NPR	IY 222-3991	03	001	HOUSING GP-FLYWHEEL
	NPR	IY 230-2548	00	001	FASTENER GP-WIRING HARNESS
	NPR	IY 169-3113	01	001	LIFTING GP-ENGINE
	NPR	IY 140-2175	00	001	CONTROL GP-REMOTE SPEED

	I	PA7777	03	001	WIRING - CONTROL (24V)
NPR	IY	118-7284	02	001	STARTING AID GP
NPR	IY	209-2108	04	001	STARTING AID GP
	I	PQ0014	04	001	C-9 RADIATOR SIDE-BY-SIDE ATAA
NPR	IY	228-4301	02	001	RADIATOR GP
NPR	IY	228-4320	01	001	LINES GP-AIR
NPR	IY	194-1093	00	001	MOUNTING GP-FAN DRIVE
NPR	IY	194-9463	01	001	DRIVE GP-FAN
NPR	IY	198-7629	00	001	FASTENER GP-FAN DRIVE
NPR	IY	233-0079	00	001	ELBOW GP-AIR INLET
	I	230-2546	00	001	INSTRUCTIONS
NPR	IY	236-2540	00	001	LINES GP-WATER
NPR	IY	204-1528	01	001	CONNECTION GP-WATER
NPR	IR	107-7977	02	001	ALTERNATOR GP-CHARGING
NPR	IY	212-8693	01	001	GUARD GP-ALTERNATOR
NPR	ICLY	2W-8494	00	001	PULLEY-ALTERNATOR
NPR	IY	228-4311	01	001	FAN GP-BLOWER
	I	PQ0025	02	001	C-9 DRIVE GP-FAN PULLEY (1:1)
NPR	IY	233-0075	02	001	FASTENER GP-DAMPER & PULLEY
NPR	IY	230-2554	00	001	PULLEY GP
NPR	IY	198-7627	00	001	PULLEY GP-FAN
NPR	IY	7M-0981	04	001	V-BELT SET
NPR	IY	111-2675	01	001	STARTING MOTOR GP-ELECTRIC
NPR	IY	203-3154	01	001	LINES GP-FLEXIBLE FUEL
	I	PQ0021	01	001	C-9 SIDE-BY-SIDE FUEL FILTER G
NPR	IY	229-2028	01	001	LINES GP-FUEL FILTER
NPR	IY	229-2027	00	001	FILTER GP-WATER SEP & FUEL
	I	PQ0029	01	001	C-9 / 3126B FUEL COOLER GPS
NPR	IY	228-4336	01	001	COOLER GP-FUEL
NPR	IY	230-2561	00	001	LINES GP-FUEL
NPR	IY	192-2072	01	001	AIR CLEANER GP
NPR	IY	150-1714	03	001	PRECLEANER GP
	I	PQ0019	01	001	C-9/3126B SUPPORT GP-FRONT(WID
NPR	IY	230-2540	00	001	SUPPORT GP-ENGINE
	I	PL0034	00	001	ELBOW GP-EXHAUST
NPR	IY	212-6029	00	001	MANIFOLD GP-EXHAUST
NPR	IY	212-6032	00	001	ELBOW GP-EXHAUST
	I	PA7677	00	001	CONTROL 24V
	I	195-0126	01	001	DIAGRAM-WIRING
NPR	IY	195-0131	00	001	WIRING GP-ENGINE

	NPR	IY	195-1345	00	001	CONTROL GP-AUTO START/STOP
	NPR	IY	133-4850	03	001	CONTROL GP-ENGINE MONITORING
		I	PA7791	00	001	GAUGE - OIL LEVEL
	NPR	IY	204-1553	00	001	GAUGE GP-OIL LEVEL (DIPSTICK)
		I	PL4088	00	001	LUBRICANT GP
		I	165-4458	03	001	PLATE & FILM GP
		I	PA7796	00	001	OIL SAMPLE VALVE
	NPR	IY	204-1543	00	001	VALVE GP-FLUID SAMPLING
		I	PQ0060	00	001	FILLER GP - OIL
	NPR	IY	240-6062	01	001	COVER GP-FRONT HOUSING
	NPR	IY	7L-7871	09	001	BATTERY GP
	NPR	IY	7W-0825	01	001	CABLE GP-BATTERY
		I	PA7801	01	001	JACKET WATER HEATER
	NPR	IY	205-6289	01	001	HEATER GP-JACKET WATER
	NPR	IY	3N-7056	00	001	SUPPORT GP-BATTERY
		I	0V-1075		001	END USE: LOCOMOTIVE EPG
		I	0V-1767		001	PARTS BOOK - ELECTRONIC
		I	PP4804	01	001	300 BHP WOF 2200 RPM IND "C"
		I	0K-2860	00	001	224 KW @ 2200 RPM (300 BHP)
						SHIPPED LOOSE
	NPR	S	2V-7397		001	CABLE AS
	NPR	S	3K-1715		001	CABLE AS
	NPR	S	3N-7054		001	SUPPORT AS-BATTERY
	NPR	S	3N-7055		001	BOARD
	NPR	S	3V-6785		001	CABLE AS
	NPR	S	7N-5274		001	COVER AS-TERMINAL
	NPR	S	8L-8413		002	STRAP-CABLE
	NPR	S	8N-0869		001	COVER-TERMINAL
	NPR	S	8N-1725		001	COVER AS-TERMINAL
	NPR	S	8T-8732		001	RECEPTACLE-CONNECTOR
	NPR	S	8T-8737		036	PLUG-SEAL
	NPR	S	8T-9834		001	PLUG AS-CONNECTOR
	NPR	S	9G-0003		002	COVER AS-TERMINAL
	NPR	S	9G-0004		002	COVER AS-TERMINAL
	NPR	S	9G-8909		001	COVER-TERMINAL
	NPR	S	9W-0844		003	SOCKET-CONNECTOR
	NPR	S	9X-3401		003	PIN-CONNECTOR
	NPR	S	9X-3402		039	SOCKET-CONNECTOR
	NPR	S	9X-9720		002	BATTERY
	NPR	S	133-0969		001	CONNECTOR-SOCKET

<input type="checkbox"/>	NPR	SY	133-4850	001	CONTROL GP-ENGINE MONITORING
<input type="checkbox"/>	NPR	SY	140-2175	001	CONTROL GP-REMOTE SPEED
<input type="checkbox"/>	NPR	SY	150-1714	001	PRECLEANER GP
<input type="checkbox"/>	NPR	S	151-6320	002	TOOL-WIRE REMOVAL
<input type="checkbox"/>	NPR	S+Y	192-2072	001	AIR CLEANER GP
<input type="checkbox"/>		S+	195-0126	001	DIAGRAM-WIRING
<input type="checkbox"/>	NPR	SY	195-0131	001	WIRING GP-ENGINE
<input type="checkbox"/>	NPR	SY	195-1345	001	CONTROL GP-AUTO START/STOP
<input type="checkbox"/>	NPR	S+Y	203-3154	001	LINES GP-FLEXIBLE FUEL