

3412 GEN SET ENGINE

Engine Serial Prefix - 2WJ (Build Date - 12/2000, Test Date - 16/12/2000, Ship Date - 12/2000)

▼ ENGINE - ENTIRE GROUP (2WJ)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						<b>FEATURE CODES</b>
		I	KW00635	F	001	635 EKW W/FAN
		I	412DE13	F	001	3412 635 EKW 60 HZ PGS-PRIME
		I	EMCPLUS	F	001	EMCP TWO PLUS
		I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
		I	RADE003	F	001	RADIATOR E 0.485 DRIVE
		I	CLS0001	F	001	COOLANT LEVEL SENSOR
		I	ACT0007	F	001	EXTENDED LIFE COOLANT
		I	BAT2401	F	001	24 VOLT BATTERY SET - DRY 01
		I	BTRCBL1	F	001	BATTERY CABLES
		I	BTR0001	F	001	BATTERY RACK
		I	JWH0005	F	001	JACKET WATER HEATER
		I	ACLDE05	F	001	AIR CLEANER - DUAL ELEMENT
		I	ACLRM04	F	001	REG. DUTY AIR CLEANER REMOVAL
		I	ALT2422	F	001	CHARGING ALTERNATOR 24V 35 AMP
		I	PCL0005	F	001	PRECLEANER
		I	CBK0011	F	001	CIRCUIT BKR W/ST 1200 A
		I	PFF0004	F	001	PRIMARY FUEL FILTER
		I	60H-0480	F	001	60HZ 480 VOLTS
		I	MSEPGGN	F	001	GENERAL EPG (NON-ENCLOSED)
		I	NONCERT	F	001	NON-CERTIFIED
		I	PRIMEPA	F	001	PRIME POWER
		I	ELECGOV	F	001	ELECTRONIC GOVERNOR
		I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL
						<b>PART NUMBERS</b>
		I	PP2205	00	001	947 BHP 671 GEN KW WOF 60 HZ P
		I	0P-8910		001	POST SALE SPAR
		I	0V-1317		001	01JAN01 PRC PROTECT PGM641-11
		I	PA5356	02	001	3412 635 EKW 60 HZ PGS-PRIME
	<u>NPR</u>	IY	<u>7E-0161</u>	15	001	ENGINE AR
		I	3L-0432		001	TEST - PKG GEN SET (EMCP II)
	<u>NPR</u>	IY	<u>3N-6668</u>	05	001	LINES GP-FLEXIBLE FUEL
	<u>NPR</u>	IY	<u>4N-1061</u>	13	001	STARTING MOTOR GP-ELECTRIC
	<u>NPR</u>	IY	<u>4P-7610</u>	03	001	SENSOR GP-SPEED
		I	5N-7562	00	001	CHART

	I	5P-2506	00	001	LITERATURE GP
	<a href="#">NPR</a>	IY <a href="#">6I-2026</a>	04	001	CONNECTION GP-ELECTRICAL
	<a href="#">NPR</a>	IY <a href="#">6N-8878</a>	02	001	GAUGE GP-FUEL PRESSURE
	<a href="#">NPR</a>	IY <a href="#">7E-9053</a>	01	001	GUARD GP-BELT
	<a href="#">NPR</a>	IY <a href="#">9Y-0450</a>	01	001	GENERATOR AR
	<a href="#">NPR</a>	IY <a href="#">9Y-6397</a>	05	001	RAIL GP-ENGINE SUPPORT
	<a href="#">NPR</a>	IY <a href="#">102-9942</a>	00	001	MOUNTING GP-CONTACTOR
	<a href="#">NPR</a>	IY <a href="#">103-1966</a>	05	001	WIRING GP-ENGINE
	<a href="#">NPR</a>	IY <a href="#">104-4704</a>	03	001	MOUNTING GP-CONTROL PANEL
	<a href="#">NPR</a>	IY <a href="#">108-1467</a>	01	001	COUPLING GP-GENERATOR
	I	5N-9677		001	NOTE-PANEL CHART 1369048
	I	CA0597	01	001	ELECT. MODULAR CONT. PANEL II+
	<a href="#">NPR</a>	IY <a href="#">141-2858</a>	01	001	CONTROL AR-EMCP ELECTRONIC
	<a href="#">NPR</a>	IY <a href="#">145-5219</a>	01	001	CONTROL GP-ENG RATINGS ELEK
	I	121-4713	00	001	INSTRUCTIONS
	<a href="#">NPR</a>	IY <a href="#">121-4712</a>	01	001	PANEL GP-ELECTRONIC
	I	PA5371	03	001	RADIATOR E 0.485 DRIVE
	<a href="#">NPR</a>	IY <a href="#">6N-4371</a>	02	001	FAN GP-BLOWER
	<a href="#">NPR</a>	IY <a href="#">6N-4874</a>	03	001	LINES GP-WATER
	<a href="#">NPR</a>	IY <a href="#">7E-4257</a>	02	001	RADIATOR GP
	<a href="#">NPR</a>	IY <a href="#">7N-8847</a>	02	001	DRIVE GP-FAN
	<a href="#">NPR</a>	IY <a href="#">7E-4259</a>	00	001	LINES GP-WATER
	<a href="#">NPR</a>	IY <a href="#">111-3794</a>	01	001	SENSOR GP-COOLANT LEVEL
	I	CA0888	01	001	EXTENDED LIFE COOLANT
	<a href="#">NPR</a>	I 119-5148	01	001	COOLANT-EXTENDED LIFE
	<a href="#">NPR</a>	IY <a href="#">7L-7872</a>	08	001	BATTERY GP
	<a href="#">NPR</a>	IY <a href="#">7W-0825</a>	01	001	CABLE GP-BATTERY
	<a href="#">NPR</a>	IY <a href="#">3N-7056</a>	00	001	SUPPORT GP-BATTERY
	I	PA5399	01	001	JACKET WATER HEATER
	<a href="#">NPR</a>	IY <a href="#">7E-4244</a>	01	001	MOUNTING GP-JACKET WTR HEATER
	<a href="#">NPR</a>	IY <a href="#">7E-6248</a>	06	001	HEATER GP-JACKET WATER
	<a href="#">NPR</a>	IY <a href="#">142-9999</a>	01	001	AIR CLEANER GP
	I	PA6014	01	001	REG. DUTY AIR CLEANER REMOVAL
	I	PA5344	02	001	CHARGING ALTERNATOR 24V 35 AMP
	<a href="#">NPR</a>	IY <a href="#">4P-4063</a>	01	001	MOUNTING GP-ALTERNATOR
	<a href="#">NPR</a>	IRY <a href="#">6T-1395</a>	06	001	ALTERNATOR GP-CHARGING
	<a href="#">NPR</a>	IY <a href="#">7E-9054</a>	03	001	GUARD GP-BELT
	<a href="#">NPR</a>	IY <a href="#">103-7286</a>	01	001	MOUNTING GP-CIRCUIT BREAKER
	I	PA6022	02	001	PRECLEANER
	<a href="#">NPR</a>	IY <a href="#">150-1714</a>	03	001	PRECLEANER GP

	I	PA5370	03	001	CIRCUIT BKR W/ST 1200 A
	<a href="#">NPR</a>	IY <a href="#">4P-4968</a>	01	001	MOUNTING GP-CIRCUIT BREAKER
	<a href="#">NPR</a>	IY <a href="#">4P-4969</a>	01	001	BOX GP-EXTENSION TERMINAL
	<a href="#">NPR</a>	IY <a href="#">105-7185</a>	01	001	HARNESS AS-PANEL
	<a href="#">NPR</a>	IY <a href="#">106-9697</a>	00	001	NEUTRAL BUS BAR AS
	<a href="#">NPR</a>	IY <a href="#">108-1055</a>	00	001	FASTENER GP-EXTENSION BOX
	<a href="#">NPR</a>	IY <a href="#">108-1056</a>	00	001	COVER GP-EXTENSION BOX
	<a href="#">NPR</a>	IY <a href="#">108-1057</a>	01	001	CABLE GP-GENERATOR GROUND
	<a href="#">NPR</a>	IY <a href="#">108-1060</a>	00	001	CABLE GP-GENERATOR GROUND
	<a href="#">NPR</a>	IY <a href="#">108-1061</a>	00	001	CIRCUIT BREAKER GP
	I	PL1697	06	001	PRIMARY FUEL FILTER
	<a href="#">NPR</a>	IY <a href="#">6N-3212</a>	04	001	MOUNTING GP-PRIMARY FUEL FLTR
	<a href="#">NPR</a>	IY <a href="#">8H-7204</a>	09	001	FILTER GP-FUEL
	I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
	I	0V-1065		001	END USE: GENERAL EPG
	I	PP2205	00	001	947 BHP 671 GEN KW WOF 60 HZ P
	I	2T-5770	00	001	706 KW @ 1800 RPM (947 BHP)
					<b>SHIPPED LOOSE</b>
	<a href="#">NPR</a>	S 0S-1566		008	BOLT
	<a href="#">NPR</a>	S 0S-1585		008	BOLT
	<a href="#">NPR</a>	S 0S-1594		002	BOLT
	<a href="#">NPR</a>	S 0T-0065		001	BOLT
	<a href="#">NPR</a>	S 1F-7958		008	NUT-FULL
	<a href="#">NPR</a>	S 1W-1325		001	BRACKET AS-AIR CLEANER
	<a href="#">NPR</a>	S 2F-4967		002	SPACER
	<a href="#">NPR</a>	S 2L-3331		002	CONNECTOR-PIPE
	<a href="#">NPR</a>	S 2V-7397		001	CABLE AS
	<a href="#">NPR</a>	S 3B-1915		001	BOLT
	<a href="#">NPR</a>	S 3B-6552		002	ELBOW-PIPE
	<a href="#">NPR</a>	S 3K-1715		001	CABLE AS
	<a href="#">NPR</a>	S 3N-6667		002	HOSE AS
	<a href="#">NPR</a>	S 3N-7054		001	SUPPORT AS-BATTERY
	<a href="#">NPR</a>	S 3N-7055		001	BOARD
	<a href="#">NPR</a>	S 3V-6785		001	CABLE AS
	<a href="#">NPR</a>	S 4B-4043		004	BOLT
	<a href="#">NPR</a>	S 4D-3704		016	WASHER-HARD
	<a href="#">NPR</a>	S 4K-0367		004	NUT-FULL
	<a href="#">NPR</a>	SY <a href="#">4W-5828</a>		002	CAP AS-AIR CLEANER
	<a href="#">NPR</a>	S 5L-3233		002	FITTING-CONNECTOR
	<a href="#">NPR</a>	S 5M-2894		006	WASHER-HARD

	<a href="#">NPR</a>	S	5P-3860	004	CLAMP-HOSE
	<a href="#">NPR</a>	S	5P-8245	016	WASHER-HARD
	<a href="#">NPR</a>	S	6V-4611	001	FILM-WARNING
	<a href="#">NPR</a>	S	7N-5274	001	COVER AS-TERMINAL
	<a href="#">NPR</a>	S	8B-8679	002	SPACER
	<a href="#">NPR</a>	S	8L-8413	002	STRAP-CABLE
	<a href="#">NPR</a>	S	8N-0869	001	COVER-TERMINAL
	<a href="#">NPR</a>	S	8N-1725	001	COVER AS-TERMINAL
	<a href="#">NPR</a>	S	8N-2694	002	INDICATOR-AIR FILTER CHANGE
	<a href="#">NPR</a>	S	8T-4896	022	WASHER-HARD
	<a href="#">NPR</a>	S	8T-6763	001	PLUG-PIPE
	<a href="#">NPR</a>	S	9B-7237	002	BOLT
	<a href="#">NPR</a>	S	9G-0003	002	COVER AS-TERMINAL
	<a href="#">NPR</a>	S	9G-0004	002	COVER AS-TERMINAL
	<a href="#">NPR</a>	S	9G-8909	001	COVER-TERMINAL
	<a href="#">NPR</a>	S	9S-8752	002	NUT-FULL
	<a href="#">NPR</a>	SY	<a href="#">9X-9730</a>	002	BATTERY GP
		S	REHS0753	001	WARR REGISTRATION 140010D2(A)
		S	SEBP2268	002	PT BK 1690 4-7(A)
		S	SEBP2534	001	PT BK(EMCP 11) 140015B1(A)
		S	SEBP2678	002	PT BK(EMCP 2) 1688 6-9(A)
		S	SEBU6042	002	SUPP (GEN ONLY) 1632-05 (A)
		S	SEBU6251	002	LUBE
		S	SEBU6767	002	OMM 1690 3-1(A)
		S	SEBU6918	003	OMM(GEN ONLY) FL CC06E(A)
		S	SEBU6984	002	SUPP
		S	SEHS9213	002	S.I. 1632-02 (A)
		S	SEHS9866	001	S.I. 16881-11(A)
		S	SEHS9970	002	S.I. FORM 1632-01 (A)
		S	SELF5308	002	WARRANTY 140013C2(A)
		S	SENR4794	001	DIAGRAM 1634-04 (A)
		S	SMBU6981	001	SUPP
	<a href="#">NPR</a>	S	003-2143	001	ELBOW
	<a href="#">NPR</a>	S	138-3230	001	BRACE
	<a href="#">NPR</a>	S	138-3231	001	BRACE
	<a href="#">NPR</a>	S	138-4173	001	SUPPORT AS-AIR CLEANER
	<a href="#">NPR</a>	S	138-4174	001	SUPPORT AS-AIR CLEANER
	<a href="#">NPR</a>	S	138-4551	001	HOSE
	<a href="#">NPR</a>	S	145-6673	001	HOSE
	<a href="#">NPR</a>	SY	<a href="#">150-1714</a>	001	PRECLEANER GP



[NPR](#) SY [159-8566](#)

[NPR](#) SY [159-8567](#)

001 AIR CLEANER GP

001 AIR CLEANER GP