

▼ ENGINE - ENTIRE GROUP (3FZ)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	KW00550	F	001	550 EKW W/FAN
		I	412DE6K	F	001	3412 208/120V 60 HZ
		I	OGNPM00	F	001	GENERATOR 593 FRAME PM
		I	RPA0110	F	001	592 FRAME GENERATOR REMOVAL
		I	ULLIST	F	001	UL LISTING
		I	EMCPLUS	F	001	EMCP TWO PLUS
		I	GOVEL11	F	001	ELECTRONIC LOAD SHARE GOVERNOR
		I	OVRDG05	F	001	VOLTAGE REG - DIGITAL
		I	EMCCAS1	F	001	COMMON ALARM/SHUTDOWN
		I	EMCGRR1	F	001	GENERATOR RUNNING RELAY
		I	CIM0001	F	001	CUSTOMER INTERFACE MODULE
		I	EMCAM06	F	001	ALARM MODULE - NFPA 99
		I	EMCRMP2	F	001	REM. ANNUNCIATOR PANEL-8 LIGHT
		I	RADREM1	F	001	RADIATOR - REMOVAL
		I	COLHTR2	F	001	JACKETWATER COOLANT HEATER
		I	BTC1015	F	001	BATTERY CHARGER-10AMP DUALRATE
		I	BATRM01	F	001	STANDARD BATTERY REMOVAL
		I	CNTCT01	F	001	CONTACTOR GP
		I	PTSRH00	F	001	RH POWER TERMINAL STRIP
		I	EXHMTG1	F	001	MAN AND TURBO GUARDS
		I	MUFRS11	F	001	RESIDENTIAL SILENCER - 25 DBA
		I	EXHEL02	F	001	MUFFLER ELBOW KIT
		I	60H-0208	F	001	60HZ 208 VOLTS
		I	MSEPGGN	F	001	GENERAL EPG (NON-ENCLOSED)
		I	STANDBY	F	001	STANDBY POWER
		I	NONCERT	F	001	NON-CERTIFIED
		I	2301GOV	F	001	2301 GOVERNOR
		I	TOPCBLE	F	001	TOP CABLE ENTRY CIRCUIT BKR
						PART NUMBERS
		I	PP4248	01	001	823 BHP 574 GEN KW WOF 60 HZ S
		I	0V-2019		001	0V2019 EPG SB PRICEMPGM20-00
		I	CA1319	09	001	3412 DITTA PKG 208VOLT 60HZ
	<u>NPR</u>	IY	<u>167-6897</u>	00	001	GENERAL AR
	<u>NPR</u>	IY	<u>166-8590</u>	02	001	ENGINE AR

	I	3L-0284		001	*****TEST - PKG GEN SET*****
	I	3L-0303		001	ADJUSTING-WW 2301 CONTROL SYS
	NPR	IY 3N-8594	03	001	COVER GP-ENGINE LIFTING EYE
	I	5P-2506	00	001	LITERATURE GP
	NPR	IY 6N-8878	02	001	GAUGE GP-FUEL PRESSURE
	NPR	IY 148-5232	02	001	FITTING GP-EXHAUST
	NPR	IY 149-7876	03	001	FASTENER GP-GENERATOR COUPLING
	NPR	IY 151-7794	04	001	MOUNTING GP-ENGINE FLEXIBLE
	NPR	IY 166-5029	02	001	LINES GP-ENGINE OIL DRAIN
	NPR	IY 166-5034	02	001	FUMES DISPOSAL GP
	I	3L-0432		001	TEST - PKG GEN SET (EMCP II)
	NPR	IY 168-3237	04	001	SUPPORT GP-BATTERY
	NPR	IY 168-3241	05	001	ENCLOSURE GP-GENERATOR
	NPR	IY 168-3293	02	001	AIR CLEANER GP
	NPR	IY 169-0226	03	001	BOX GP-JUNCTION
	NPR	IY 169-0240	03	001	COVER GP-GENERATOR
	NPR	IY 169-0247	07	001	BOX GP-EXTENSION TERMINAL
	NPR	IY 169-0257	05	001	MOUNTING GP-BUS BAR
	NPR	IY 169-0295	03	001	CONNECTION GP-GENERATOR LEADS
	NPR	IY 169-2055	02	001	LINES GP-FLEXIBLE FUEL
	NPR	IY 169-2065	00	001	BASE GP-ENGINE & GENERATOR
	NPR	IY 169-4439	04	001	HARNESS AS-WIRING
	NPR	IY 169-4441	05	001	HARNESS AS-WIRING
	NPR	IY 169-4444	04	001	HARNESS AS-WIRING
	NPR	IY 169-4450	03	001	HARNESS AS-WIRING
	NPR	IY 180-3986	02	001	MOUNTING GP-JUNCTION BOX
	NPR	IY 183-4729	03	001	COVER GP-ACCESS
		IY 156-2882	00	001	TRANSFORMER GP-CURRENT
	NPR	IY 170-8400	03	001	COVER GP-CONTROL PANEL
	NPR	IY 196-8775	01	001	SWITCH GP-DISCONNECT
	I	CA1644	01	001	GENERATOR AR-OPTIONAL-PM-SR4B
	IY	136-6628	00	001	GENERATOR AR
	I	CA1637	00	001	REMOVAL AR-GENERATOR-SR4B
	I	CA2464	07	001	UL 2200 LISTED PACKAGED GENSET
	I	3L-0027		001	NAMEPLATE
	I	3L-0028		001	NAMEPLATE
	I	3L-0043		001	GSC + SETPOINT INFORMATION-UL
	I	3L-0059		001	INFORMATION-CONTROL PANEL (UL)
	I	210-2630	00	001	INSTRUCTIONS
	I	CA1371	02	001	CONTROL PANEL-EMCP II+

	NPR	IY	153-3441	03	001	SENSOR GP-ENGINE
	NPR	IY	169-0200	08	001	PANEL GP-ELECTRONIC
	NPR	IY	171-6833	03	001	RELAY GP
	NPR	IY	193-3247	02	001	HARNESS AS-WIRING
		I	CA1443	02	001	GOVERNOR GP-2301A W/EG3P-LOAD
	NPR	IY	172-0323	01	001	CONTROL GP-GOVERNOR
		I	CA1624	06	001	REGULATOR GP-VOLTAGE-DIGITAL
	NPR	IY	143-9519	04	001	REGULATOR GP-VOLTAGE
	NPR	IY	155-8893	01	001	WIRING GP-GENERATOR
	NPR	IY	193-3262	01	001	HARNESS AS-WIRING
		I	121-4713	00	001	INSTRUCTIONS
		I	CA1430	04	001	RELAY GP-COMMON ALARM/SHUTDOWN
	NPR	IY	190-2565	02	001	HARNESS AS-WIRING
	NPR	IY	200-0844	01	001	RELAY GP
		I	CA1619	04	001	RELAY GP-RUNNING
	NPR	IY	190-2566	02	001	HARNESS AS-WIRING
	NPR	IY	200-0842	01	001	RELAY GP
		I	CA1432	03	001	CONTROL GP-CUSTOMER INTERFACE
	NPR	IY	171-6828	02	001	MODULE GP-INTERFACE
		I	CA1436	03	001	CONTROL GP-ALARM MODULE-NFPA99
	NPR	IY	171-6827	03	001	PANEL GP-INSTRUMENT
	NPR	IY	131-1962	02	001	PANEL GP-INSTRUMENT
		I	CA1386	06	001	REMOVAL AR-RADIATOR
	NPR	IY	188-8220	01	001	GUARD GP-BELT
		I	199-4971	00	001	DRIVE GP-FAN
		I	CA1388	02	001	HEATER GP-JACKET WATER-6000 WA
	NPR	IY	169-2058	02	001	HEATER GP-JACKET WATER
	NPR	IY	171-6841	03	001	CONNECTION GP-ELECTRICAL
		I	CA1947	02	001	BATTERY CHARGER - 10 AMP UL W/
	NPR	IY	111-6138	02	001	BATTERY CHARGER
	NPR	IY	184-7029	01	001	MOUNTING GP-BATTERY CHARGER
	NPR	IY	203-4316	00	001	CONNECTION GP-ELECTRICAL
		I	CA1072	03	001	BATTERY REMOVAL
	NPR	IY	184-7031	02	001	CONTACTOR GP
		I	CA2332	02	001	POWER TERMINAL STRIP-RH-TCE
		I	5N-9697		001	NOTE - TOP CABLE ENTRY
		I	5N-9703		001	NOTE-POWER TERM STRIPS-RIGHT
	NPR	IY	169-4522	03	001	BOX GP-EXTENSION TERMINAL
	NPR	IY	179-9087	01	001	COVER GP-GENERATOR
	NPR	IY	189-8887	01	001	CABLE GP-GENERATOR GROUND

	NPR	IY	184-7028	00	001	WIRING GP-PANEL
	NPR	IY	202-7403	00	001	MOUNTING GP-ENGINE
		I	CA1830	01	001	GUARD GP-EXHAUST
	NPR	IY	201-2675	00	001	GUARD GP-ENGINE
		I	CA1485	01	001	MUFFLER GP-RESIDENTIAL
	NPR	IY	183-7643	01	001	MUFFLER
		I	CA1608	02	001	ELBOW GP-MUFFLER
	NPR	IY	184-0840	01	001	ELBOW GP-EXHAUST
		I	5N-9593		001	BASIC TRANSFER SWITCH-5N6800
		I	0V-1065		001	END USE: GENERAL EPG
		I	9Y-8156		001	STANDBY POWER APPLICATION
		I	PP4248	01	001	823 BHP 574 GEN KW WOF 60 HZ S
		I	0K-0510	00	001	614 KW @ 1800 RPM (823 BHP)