

3406C GEN SET ENGINE

Engine Serial Prefix - 4ZR (Build Date - 05/2000, Test Date - 05/2000, Ship Date - 05/2000)

▼ ENGINE - ENTIRE GROUP (4ZR)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	KW00400	F	001	400 EKW W/FAN
		I	406DE30	F	001	3406 480 VOLT 60 HZ PGS
		I	EMCPLUS	F	001	EMCP TWO PLUS
		I	GOVEL01	F	001	1724 ELECTRONIC GOVERNOR
		I	EMCENGU	F	001	ENGLISH DISPLAY UNITS
		I	EMCRH01	F	001	RH MTG OF CONTROL PANEL
		I	EMCAM07	F	001	ALARM MODULE - NFPA 110
		I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
		I	EMCEFR1	F	001	RELAY GP
		I	CCM0001	F	001	CUST COMMUNICATIONS MODULE-CCM
		I	EMCRMP2	F	001	REM. ANNUNCIATOR PANEL-8 LIGHT
		I	FDV0001	F	001	FAN DRIVE RATIO 0.800
		I	ACTC001	F	001	ANTIFREEZE
		I	CLS0001	F	001	COOLANT LEVEL SENSOR
		I	FTBDW05	F	001	DW FUEL TANK BS-2271L(600GAL)
		I	BAT2401	F	001	24 VOLT BATTERY SET - DRY
		I	BTR0003	F	001	BATTERY RACK + CABLES
		I	JWH0001	F	001	JACKET WATER HEATER
		I	BTC1001	F	001	BATTERY CHARGER 10 AMP 01
		I	FPG0001	F	001	FUEL PRESSURE GAUGE, LH
		I	CBK3P14	F	001	700 AMP 3 POLE CIRCUIT BREAKER
		I	60H-0480	F	001	60HZ 480 VOLTS
		I	MSEPGGN	F	001	GENERAL EPG
		I	STANDBY	F	001	STANDBY POWER APPLICATION 02
		I	CBKRH01	F	001	RH MOUNT CIRCUIT BREAKER
		I	NONCERT	F	001	NOT EPA&CARB NONROAD EMIS CERT
		I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL
						PART NUMBERS
		I	PP3432	02	001	587 BHP 411 GEN KW WOF 60 HZ S
		I	0P-9177		001	0P9177 PWR PRICING PGM769-00
		I	CA0331	06	001	3406 480 VOLT 60 HZ PGS
	<u>NPR</u>	IY	<u>128-7032</u>	06	001	ENGINE AR
	<u>NPR</u>	IY	<u>2W-8198</u>	09	001	SHUTOFF GP-ELECTRICAL
	<u>NPR</u>	IY	<u>2W-9666</u>	07	001	GUARD GP-BELT

	I	3L-0432		001	TEST - PKG GEN SET (EMCP II
	NPR	IY 4N-1062	09	001	STARTING MOTOR GP-ELECTRIC
	NPR	IY 4N-3093	09	001	FAN GP-BLOWER
	NPR	IY 4P-7610	03	001	SENSOR GP-SPEED
	NPR	IY 4W-1727	00	001	COVER GP-FUEL TRANSFER
	I	5N-7601		001	NOTE-CONTROL & POWER PANEL
	I	5P-2506	00	001	LITERATURE GP
	NPR	I 5P-2586	03	001	OIL
	NPR	IY 6L-2927	07	001	ELBOW GP-EXHAUST
	NPR	IY 8N-6115	03	001	AIR CLEANER GP
	NPR	IY 103-1736	01	001	WIRING GP-PANEL
	NPR	IY 103-1956	00	001	MOUNTING GP-CONTACTOR
	NPR	IY 104-4704	03	001	MOUNTING GP-CONTROL PANEL
	NPR	IY 109-1532	02	001	FUMES DISPOSAL GP
	NPR	IY 128-5881	01	001	BASE GP-ENGINE & GENERATOR
	NPR	IY 129-1479	01	001	GENERATOR AR
	NPR	IY 129-6803	03	001	CONNECTION GP-ELECTRICAL
	NPR	IY 129-7502	01	001	LINES GP-COOLANT DRAIN
	NPR	IY 129-7504	01	001	LINES GP-ENGINE OIL DRAIN
	NPR	IY 130-3459	01	001	REGULATOR GP-VOLTAGE
	NPR	IY 130-3480	02	001	MOUNTING GP-VOLTAGE REGULATOR
	NPR	IY 4N-9778	04	001	LINES GP-WATER
	NPR	IY 133-9878	01	001	COUPLING GP-GENERATOR
	NPR	IY 7N-9946	14	001	RADIATOR GP
	I	3L-0284		001	*****TEST - PKG GEN SET*****
	I	CA0597	01	001	ELECT. MODULAR CONT. PANEL II+
	NPR	IY 141-2858	01	001	CONTROL AR-EMCP ELECTRONIC
	NPR	IY 145-5219	01	001	CONTROL GP-ENG RATINGS ELEK
	I	PA5018	03	001	1724 ELECTRONIC GOVERNOR
	NPR	IY 7E-0123	00	001	MOUNTING GP-GOVERNOR ACTUATOR
	NPR	IY 7E-0598	00	001	ACTUATOR AS-GOVERNOR
	NPR	IY 131-5455	02	001	CONTROL AS-GOVERNOR
	I	121-4713	00	001	INSTRUCTIONS
	I	PL4838	04	001	RH MTG OF CONTROL PANEL
	I	5N-7563		001	NOTE- CONTROL PANEL MTG (RH)
	NPR	IY 121-4717	01	001	MODULE GP-ALARM
	NPR	IY 121-4712	01	001	PANEL GP-ELECTRONIC
	NPR	IY 134-1157	00	001	RELAY GP
	NPR	IY 102-8627	01	001	MODULE GP-SYSTEM COMMUNICATION
	NPR	IY 131-1962	01	001	PANEL GP-INSTRUMENT

	I	PA4042	03	001	FAN DRIVE RATIO 0.800
NPR	IY	7N-8840	04	001	DRIVE GP-FAN
	I	CA0563	00	001	LONG LIFE COOLANT/ANTIFREEZE
NPR	I	119-5148	01	001	COOLANT-EXTENDED LIFE
NPR	IY	111-3794	00	001	SENSOR GP-COOLANT LEVEL
	I	CA0299	03	001	FUEL TANK BASE-2271 L(600 GAL)
NPR	IY	110-9697	02	001	LINES GP-FLEXIBLE FUEL
NPR	IY	130-1270	02	001	TANK AS-FUEL
	I	150-9039	01	001	INSTRUCTIONS - WIRING
NPR	IY	7L-7872	08	001	BATTERY GP
NPR	IY	128-5214	00	001	SUPPORT GP-BATTERY
	I	CA0470	01	001	JACKET WATER HEATER
NPR	IY	7E-6247	03	001	HEATER GP-JACKET WATER
NPR	IY	129-4439	03	001	MOUNTING GP-JACKET WTR HEATER
	I	CA0441	01	001	BATTERY CHARGER 10 AMP
NPR	IY	114-6486	00	001	BATTERY CHARGER
NPR	IY	130-1983	01	001	FASTENER GP-BATTERY CHARGER
NPR	IY	6N-8878	02	001	GAUGE GP-FUEL PRESSURE
	I	CA0416	02	001	CIRCUIT BREAKER W/ST 700 AMP
NPR	IY	6I-3340	00	001	NEUTRAL BUS BAR AS
NPR	IY	105-7185	01	001	HARNESS AS-PANEL
NPR	IY	111-9706	01	001	CIRCUIT BREAKER GP
NPR	IY	129-5841	00	001	COVER GP-GENERATOR
NPR	IY	130-1968	02	001	MOUNTING GP-CIRCUIT BREAKER
NPR	IY	130-2572	00	001	BOX GP-EXTENSION TERMINAL
NPR	IY	130-2569	00	001	FASTENER GP-EXTENSION BOX
	I	5N-9597		001	VOLTAGE INDICATOR 480V, 60HZ
	I	0V-1065		001	END USE: GENERAL EPG
	I	9Y-8156		001	STANDBY POWER APPLICATION
	I	5N-7595		001	NOTE - MOUNT CIRCUIT BKR RH
	I	PP3432	02	001	587 BHP 411 GEN KW WOF 60 HZ S
	I	2T-8212	00	001	438 KW @ 1800 RPM (587 BHP)
	I	5N-7545		001	NOTE-REMOVE STD GOV SPRING
NPR	I	7L-8056	03	001	SPRING
					SHIPPED LOOSE
NPR	S	2G-5836		001	CABLE AS
NPR	S	2V-7397		001	CABLE AS
NPR	S	4L-6454		004	BOLT
NPR	S	5N-2042		003	BOLT
NPR	S	5N-2145		001	ANGLE

	NPR	S	5P-1075	004	WASHER-HARD
	NPR	S	6V-4611	001	FILM-WARNING
	NPR	S	7N-5274	001	COVER AS-TERMINAL
	NPR	S	8C-0620	003	PROTECTOR-THREAD
	NPR	S	8L-8413	004	STRAP-CABLE
	NPR	S	8N-0869	001	COVER-TERMINAL
	NPR	S	8N-1725	001	COVER AS-TERMINAL
	NPR	S	8T-4205	003	WASHER-HARD
	NPR	S	9G-0003	002	COVER AS-TERMINAL
	NPR	S	9G-0004	002	COVER AS-TERMINAL
	NPR	S	9G-8909	001	COVER-TERMINAL
	NPR	SY	9X-9730	002	BATTERY GP
		S	JERC2162	001	SOFT
		S	REHS0753	001	WARR. REGISTRATION 140010D2(A)
		S	SEBP2534	001	PT BK(EMCP 11) 140015B1(A)
		S	SEBP2547	001	PTSBK FL CC06E(A)
		S	SEBU6042	001	SUPP
		S	SEBU6251	001	LUBE RECOMMENDATION 1632-16(A)
		S	SEBU6874	001	S.I.
		S	SEBU6918	001	OMM
		S	SEBU6999	001	OMM 16904-11(A)
		S	SENR4794	001	SCHEMATIC
		S	SMBU6981	001	SUPP 140015C2(A)
	NPR	S	035-0499	003	NUT-WING
	NPR	S	053-0103	001	CABLE AS
	NPR	S	128-5212	002	MAT-BATTERY
	NPR	S	128-5213	001	SUPPORT AS
	NPR	SY	131-1962	001	PANEL GP-INSTRUMENT
	NPR	SRY	164-8940	001	MODULE GP-SYSTEM COMMUNICATION