

3512B MARINE AUXILIARY

Engine Serial Prefix - 1PW (Build Date - 09/2003, Test Date - 09/2003)

▼ ENGINE - ENTIRE GROUP (1PW)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
<input type="checkbox"/>		I	512DY08	F	001	3512B OFFSHORE ELEC PWR MOD 08
<input type="checkbox"/>		I	ENMTPL5	F	001	ENGINE MOUNT PREMIUM PANEL LH
<input type="checkbox"/>		I	RECTMO1	F	001	PROGRAM. RELAY CONTROL MODULE
<input type="checkbox"/>		I	AIARM05	F	001	AIR INLET ADAPTER-ROUND
<input type="checkbox"/>		I	GOVPG08	F	001	GOVERNOR CONVERSION
<input type="checkbox"/>		I	CENTOF0	F	001	CENTRIFUGAL OIL FILTER
<input type="checkbox"/>		I	COUHUB1	F	001	COUPLING HUB - 127 MM DIA MAX
<input type="checkbox"/>		I	APRRH01	F	001	AIR PRESSURE REGULATOR RH
<input type="checkbox"/>		I	EXRVAL1	F	001	EXPLOSION RELIEF VALVE
<input type="checkbox"/>		I	BARGP01	F	001	ENGINE BARRING GROUP
<input type="checkbox"/>		I	1200RPM	F	001	1200 RPM
<input type="checkbox"/>		I	HP01476	F	001	1476 BHP (1101 BKW) W/O FAN
<input type="checkbox"/>		I	MSPETEP	F	001	PETROLEUM
<input type="checkbox"/>		I	GRACHRG	F	001	GRA MATERIAL HANDLING CHARGE
<input type="checkbox"/>		I	SWP0023	F	001	SHRINK WRAP PRO - 3512
<input type="checkbox"/>		I	TVATRS2	F	001	TORSIONAL ANALYSIS OPTIONS
<input type="checkbox"/>		I	TRSENG1	F	001	STD ENGINE TEST CHARGE 3L0436
<input type="checkbox"/>		I	MSCP12	F	001	DRILLING
<input type="checkbox"/>		I	MWCODEE	F	001	PRIME POWER
<input type="checkbox"/>		I	SET6006	F	001	SET6006
<input type="checkbox"/>		I	3512B	F	001	3512B NON EPA FOR EXPORT ONLY
<input type="checkbox"/>		I	CSTRADC	F	001	RADIATOR COOLED
<input type="checkbox"/>		I	NOMREQD	F	001	MCS CERTIFICATION NOT REQUIRED
<input type="checkbox"/>		I	OELEPMD	F	001	OFFSHORE ELEC DRILLING MODULE
<input type="checkbox"/>	NPR	IY	229-9379	F	001	LINES GP-ENGINE OIL DRAIN
<input type="checkbox"/>	NPR	ILY	7E-4271	F	001	HUB-FLEXIBLE COUPLING
<input type="checkbox"/>	NPR	IL	3N-8572	F	002	MOUNTING GP-VIBRATION ISOLATOR
<input type="checkbox"/>		I	0V-8707	F	001	DTO QUOTE DESIGN FEE

PART NUMBERS

	I	LA3718	04	001	3512B DITA SCAC OIL FIELD OFFS
	NPR	IY 174-4951	04	001	ENGINE AR
	NPR	IY 2W-7871	03	001	FLANGE GP-EXHAUST
	NPR	IY 2W-8532	02	001	MOUNTING GP-ENGINE
	NPR	IY 3N-5765	06	001	GUARD GP-COUPLING
	NPR	IY 3N-8594	05	001	COVER GP-ENGINE LIFTING EYE
	NPR	IY 3N-8647	05	001	FASTENER GP-COUPLING
	NPR	IY 4P-9064	00	001	GUARD GP-EXTENSION
	NPR	IY 4W-2767	00	001	CONTACTOR GP
	NPR	IY 4W-3651	05	001	MOUNTING GP-ENGINE
	NPR	IY 5N-2438	05	001	LINES GP-FLEXIBLE FUEL
	NPR	IY 5N-2457	03	001	FITTING GP-EXHAUST
	NPR	IY 5N-3765	10	001	COUPLING GP-FLEXIBLE
	I	5N-7531		001	NOTE - ASSEMBLY INSTRUCTIONS
	I	5N-7558		001	ASSEMBLY INST. LH SERVICE
	I	5N-9581		001	LOW EMISSIONS STRATEGY
	I	5N-9949		001	CONVENIENCE NUMB
	I	5P-2506	00	001	LITERATURE GP
	NPR	I 5P-2586	03	001	OIL
	NPR	IY 7C-0330	05	001	CONTROL GP-AIR STARTING
	NPR	IY 7C-3371	00	001	STARTING MOTOR GP-AIR
	NPR	IY 7C-4135	04	001	HOUSING & REGULATOR GP
	NPR	IY 7E-6469	05	001	MOUNTING GP-CONTACTOR
	NPR	IY 7N-6782	08	001	INDICATOR GP-AIR FILTER CHANGE
	NPR	IY 7N-6967	05	001	FITTING GP-EXHAUST
	NPR	IY 7W-6372	03	001	CONNECTION GP-WATER
	NPR	IY 8N-7719	09	001	LINES GP-WATER
	NPR	IY 8N-9303	08	001	AIR CLEANER GP
	NPR	IY 8N-9639	04	001	GUARD GP-DAMPER
	NPR	IY 107-2855	04	001	MOUNTING GP-INSTRUMENT PANEL
	NPR	IY 112-6597	02	001	SILENCER GP-AIR STARTING
	NPR	IY 115-1064	03	001	PUMP GP-FUEL PRIMING
	NPR	IY 115-5164	02	001	BOX & MOUNTING GP
	NPR	IY 115-7841	16	001	FILTER GP-ENGINE OIL
	NPR	IY 115-7842	09	001	FILTER GP-FUEL
	NPR	IY 126-9191	04	001	GROUND GP-ELECTRICAL

	NPR	IY	132-6467	07	001	WIRING GP-ENGINE
	NPR	IY	134-6315	02	001	WIRING GP-PANEL
	NPR	IY	153-7220	02	001	LINES GP-WATER
	NPR	IY	163-1462	00	001	SENSOR & MTG GP-ELECTRIC
	NPR	IY	210-6112	02	001	DRAIN GP-ENGINE OIL
	NPR	IY	214-5543	03	001	SHUTOFF GP-AIR
	NPR	IY	7W-9269	06	001	LINES GP-AIR STARTING
		I	LA2087	00	001	ENGINE MOUNT PREMIUM PANEL LH
	NPR	IY	120-4493	01	001	WIRING GP-PYROMETER
	NPR	IY	120-4498	02	001	THERMOCOUPLE GP
	NPR	IY	120-4504	02	001	PYROMETER GP
	NPR	IY	126-7156	10	001	BOX GP-INSTRUMENT PANEL
	NPR	IY	128-2858	05	001	WIRING GP-ENGINE
	NPR	IY	133-9300	01	001	CONTROL GP-ENGINE ELECTRONIC
	NPR	IY	7W-9828	01	001	ADAPTER GP-AIR CLEANER
		I	LA3242	01	001	ENGINE GOVERNOR CONVERSION
	NPR	I	7W-3355	04	001	SENSOR GP-SPEED
		I	176-1690	00	001	TEST-DIRECT FUEL *****
	NPR	IY	180-7385	01	001	CONTROL GP-CONVERTER
		I	LA2095	00	001	CENTRIFUGAL OIL FILTER
	NPR	IY	133-6461	08	001	FILTER GP-CENTRIFUGAL
	NPR	IY	148-8007	02	001	LINES GP-CENTRIFUGAL FILTER
	NPR	IY	8N-8483	05	001	VALVE GP-AIR CONTROL
	NPR	IY	8N-8510	16	001	VALVE GP-EXPLOSION RELIEF
	NPR	IY	5R-7425	04	001	BARRING GP
		I	0V-1055		001	END USE: PETROLEUM EPG
		I	0P-9613		001	CHARGE FOR HANDLING GRA MAT
		I	0P-7578		001	SHRINK WRAP PROTECTION - 3512
		I	0P-1502		001	CUSTOM GENSET TVA REPORT
		I	0P-1852		001	STD ENGINE TEST CHARGE 3L0436
		I	0V-1672		003	EXTRA ENG LIT - PAPER (1 - 6)
		I	LL5376	01	001	1476 BHP 980 GEN KW W/F 60 HZ
		I	0K-3603		001	1101 BKW (1476 BHP) @ 1200 RPM
	NPR	ILY	210-6113	01	001	LINES GP-ENGINE OIL DRAIN
		I	0V-2319		001	DTO MATERIAL FOR QUOTES
	NPR	ILY	7W-7915	05	001	BASE AS

<input type="checkbox"/>	NPR	ILY	2W-8160	04	001	BASE AS
<input type="checkbox"/>	NPR	I	213-9797	00	001	BASE AS
<input type="checkbox"/>	NPR	ILY	7C-7123	04	001	MOUNTING GP-GENERATOR
<input type="checkbox"/>		I	243-1155	00	001	BASE AS.
<input type="checkbox"/>		I	228-4126	00	001	MOUNTING GP-GENERATOR
<input type="checkbox"/>	NPR	I	3N-8573	04	003	MOUNTING GP-VIBRATION ISOLATOR
<input type="checkbox"/>		I	8Q-9795	00	001	PACKAGING AR
						SHIPPED LOOSE
<input type="checkbox"/>	NPR	S	0S-1571		012	BOLT
<input type="checkbox"/>	NPR	S	0S-1588		008	BOLT
<input type="checkbox"/>	NPR	S	0S-1591		008	BOLT
<input type="checkbox"/>	NPR	S	1B-5355		012	NUT-FULL
<input type="checkbox"/>	NPR	S	1B-5357		012	NUT-FULL
<input type="checkbox"/>	NPR	SY	1L-2073		001	VALVE GP-PRESSURE REDUCING
<input type="checkbox"/>	NPR	S	2W-7872		001	FLANGE-EXHAUST
<input type="checkbox"/>	NPR	S	2W-7873		001	GASKET-EXHAUST
<input type="checkbox"/>	NPR	S	3L-8993		001	FITTING
<input type="checkbox"/>	NPR	S	3N-6504		001	HOSE AS
<input type="checkbox"/>	NPR	S	3V-3308		008	WASHER-HARD
<input type="checkbox"/>	NPR	S	5B-7666		001	ELBOW
<input type="checkbox"/>	NPR	S	5F-5990		002	CLIP
<input type="checkbox"/>	NPR	S	5L-3773		001	GASKET-EXHAUST ELBOW
<input type="checkbox"/>	NPR	S	5L-4398		012	BOLT
<input type="checkbox"/>	NPR	S	5L-6297		001	ADAPTER AS-FLEXIBLE
<input type="checkbox"/>	NPR	S	5N-7830		002	GASKET
<input type="checkbox"/>	NPR	S	5P-8245		024	WASHER-HARD
<input type="checkbox"/>	NPR	SY	6F-5985		001	HOSE AS
<input type="checkbox"/>	NPR	SY	7E-4271		001	HUB-FLEXIBLE COUPLING
<input type="checkbox"/>	NPR	S	7N-6959		001	ADAPTER
<input type="checkbox"/>	NPR	S	7W-9829		002	ADAPTER AS
<input type="checkbox"/>	NPR	S	8N-1186		001	HOSE AS
<input type="checkbox"/>	NPR	SY	8N-2555		002	FILTER-SOOT
<input type="checkbox"/>	NPR	S	8T-4224		096	WASHER-HARD
<input type="checkbox"/>	NPR	S	8T-6762		001	PLUG-PIPE
<input type="checkbox"/>	NPR	S	8T-9043		048	BOLT
<input type="checkbox"/>	NPR	S	9L-9132		024	WASHER

<input type="checkbox"/>	NPR	S	9S-8752	008	NUT-FULL
<input type="checkbox"/>	NPR	S	031-4155	048	LOCKNUT
<input type="checkbox"/>	NPR	SY	133-9300	001	CONTROL GP-ENGINE ELECTRONIC
<input type="checkbox"/>		S	LEXM0051	001	IMO TECH DOC
<input type="checkbox"/>		S	SEBP2712	003	PTSBK
<input type="checkbox"/>		S	SEBU6251	001	LUBE 140019B2(A)
<input type="checkbox"/>		S	SEBU6916	004	OMM
<input type="checkbox"/>		S	SEBU6984	004	SUPP
<input type="checkbox"/>		S	SELF5345	001	WARRANTY
<input type="checkbox"/>		S	SELS0086	004	S.I.
<input type="checkbox"/>		S	SENR6588	001	SMGP
<input type="checkbox"/>		S	SERP2712	004	PTSCD
<input type="checkbox"/>		S	SMBU6981	004	SUPP
<input type="checkbox"/>		S	ESO	001	(PRNT ESO COPY)
<input type="checkbox"/>		S	PML	001	*REQUIRED DECALS

Key:

I Installed

Y Separate Illustration

L Less Indicator

S Shipped Loose