

3516B GEN SET ENGINE

Engine Serial Number - 7RN (Build Date - 11/1999, Test Date - 11/1999, Ship Date - 11/1999)

▼ ENGINE - ENTIRE GROUP (7RN)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						<b>FEATURE CODES</b>
		I	KW01825	F	001	1825 EKW W/FAN
		I	516DE53	F	001	3516B 1825 EKW 60 HZ EMISSIONS
		I	OGNPM97	F	001	GENERATOR 825 FRAME PM
		I	RPA0063	F	001	825 FRAME GENERATOR REMOVAL
		I	EMCRMP5	F	001	REM. ANNUNCIATOR MODULE
		I	VIBIS05	F	001	VIBRATION ISOLATORS
		I	RRM0007	F	001	RADIATOR REMOVAL 72/25, 0.428
		I	RAD8500	F	001	RADIATOR 85/CVD, 0.357
		I	SHREL01	F	001	SPACE HEATER RELAY
		I	CAACBX1	F	001	CABLE ACCESS BOX
		I	OVRDG02	F	001	DIGITAL VOLTAGE REGULATOR
		I	EXCYA04	F	001	Y ADAPTER
		I	ALSLSM1	F	001	LOAD SHARE MODULE
		I	JWHD002	F	001	JACKET WATER HEATER - DUAL
		I	EMCEFR1	F	001	RELAY GP
		I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
		I	EMCAM06	F	001	ALARM MODULE - NFPA 99
		I	LUBOIL1	F	001	LUBRICATING OIL
		I	PFF0001	F	001	PRIMARY FUEL FILTER
		I	LWS0001	F	001	LOW WATER TEMPERATURE SWITCH
		I	VIBIS07	F	001	VIBRATION ISOLATORS - RADIATOR
		I	BARGP01	F	001	ENGINE BARRING GROUP
		I	ALT2442	F	001	CHARGING ALTERNATOR 24V 35 AMP
		I	BTC1006	F	001	BATTERY CHARGER 10 AMP
		I	BAT2417	F	001	24 VOLT BATTERY SET - DRY
		I	OLVLRG1	F	001	OIL LEVEL REGULATOR
		I	FUMDIS4	F	001	FUMES DISPOSAL
		I	FPPRH01	F	001	FUEL PRIMING PUMP, RH MOUNTED
		I	CLSSTND	F	001	COOLANT LOSS SENSING
		I	CLS0001	F	001	COOLANT LEVEL SENSOR
		I	BTRCBL1	F	002	BATTERY CABLES
		I	BTR0001	F	002	BATTERY RACK
		I	TRSGEN1	F	001	GENERATOR TEST REPORT
		I	PRIPLUS	F	001	PRIME PLUS 10% POWER APPL.

	I	TRSGEN7	F	001	PGS TEST REPORT @ 0.8 PF	
	I	60H-2400	F	001	60HZ 2400 VOLTS	
	I	3516B	F	001	3516B DIESEL ENGINE	
	I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL	
	I	EMISSNS	F	001	EMISSIONS	
	I	60HERTZ	F	001	60 HERTZ	
					<b>PART NUMBERS</b>	
	I	PP3111	09	001	2628 BHP 1880 GEN KW WOF 60 HZ	
	<a href="#">NPR</a>	I	165-8514	01	001	GENERATOR AR
	<a href="#">NPR</a>	IL	144-2000	03	001	GENERATOR AR
		I	0P-8707		001	CQ30842-1_____QUOTE NO.
		I	0P-8910		001	IU96-405_ POST SALE SPAR
		I	LA3034	01	001	3516B 1825 EKW 60 HZ EMISSIONS
	<a href="#">NPR</a>	IY	<a href="#">159-8836</a>	01	001	ENGINE AR
		I	3L-0414		001	SINGLE BEARING GEN ALIGN-3500
		I	3L-0432		001	TEST - PKG GEN SET (EMCP II)
	<a href="#">NPR</a>	IY	<a href="#">5N-2438</a>	05	001	LINES GP-FLEXIBLE FUEL
		I	5N-9581		001	LOW EMISSION - 3500B SERIES.
		I	5P-2506	00	001	LITERATURE GP
	<a href="#">NPR</a>	IY	<a href="#">7C-0527</a>	02	001	STARTING MOTOR GP-ELECTRIC
	<a href="#">NPR</a>	IY	<a href="#">7N-6782</a>	08	001	INDICATOR GP-AIR FILTER CHANGE
	<a href="#">NPR</a>	IY	<a href="#">8N-9639</a>	04	001	GUARD GP-DAMPER
	<a href="#">NPR</a>	IY	<a href="#">9Y-8175</a>	03	001	PUMP GP-AUXILIARY WATER
	<a href="#">NPR</a>	I	104-4704	03	001	MOUNTING GP-CONTROL PANEL
	<a href="#">NPR</a>	IY	<a href="#">112-2668</a>	06	001	LINES GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">113-1581</a>	00	001	AIR CLEANER GP
	<a href="#">NPR</a>	IY	<a href="#">115-3613</a>	01	001	MOUNTING GP-AIR CLEANER
	<a href="#">NPR</a>	IY	<a href="#">115-7182</a>	01	001	RAIL GP-ENGINE SUPPORT
	<a href="#">NPR</a>	IY	<a href="#">115-7850</a>	05	001	LINES GP-WATER
	<a href="#">NPR</a>	IY	<a href="#">116-7004</a>	02	001	REGULATOR GP-TEMPERATURE
	<a href="#">NPR</a>	IY	<a href="#">121-4450</a>	09	001	PANEL GP-CONTROL
	<a href="#">NPR</a>	IY	<a href="#">121-8856</a>	06	001	CONNECTION GP-ELECTRICAL
	<a href="#">NPR</a>	IY	<a href="#">126-9191</a>	02	001	GROUND GP-ELECTRICAL
	<a href="#">NPR</a>	IY	<a href="#">134-0061</a>	04	001	WIRING GP-ENGINE
	<a href="#">NPR</a>	I	141-1809	01	001	BOX GP-GENERATOR CONNECTION
	<a href="#">NPR</a>	I	153-0191	02	001	INSTALLATION AR-GENERATOR
		I	3L-0456		001	PROCEDURE - DVR PROG AND TEST
	<a href="#">NPR</a>	I	145-5138	00	001	WIRING GP-ELECTRONIC CONTROL
		I	LA1860	05	001	GENERATOR 825 FRAME PM
	<a href="#">NPR</a>	I	122-3487	01	001	CONVERSION GP-GENERATOR

	I	LA3033	01	001	GENERATOR REMOVAL - 825 FRAME
<a href="#">NPR</a>	IY	<a href="#">131-1965</a>	01	001	PANEL GP-INSTRUMENT
<a href="#">NPR</a>	IY	<a href="#">5N-8877</a>	04	001	MOUNTING GP-ENGINE FLEXIBLE
	I	LA0781	04	001	RADIATOR REMOVAL 72/25, 0.428
	I	LA1018	02	001	RADIATOR 85/CVD, 0.357
<a href="#">NPR</a>	IY	<a href="#">120-9122</a>	02	001	RADIATOR & FAN GP
<a href="#">NPR</a>	I	120-9790	02	001	COVER GP-SHIPPING
<a href="#">NPR</a>	I	122-0335	02	001	RELAY GP
<a href="#">NPR</a>	I	122-1194	01	001	BOX & MOUNTING GP
	I	LA2916	00	001	DIGITAL VOLTAGE REGULATOR
<a href="#">NPR</a>	I	121-6203	06	001	REGULATOR GP-VOLTAGE
	I	LA0961	02	001	Y ADAPTER
<a href="#">NPR</a>	IY	<a href="#">5N-2457</a>	03	001	FITTING GP-EXHAUST
<a href="#">NPR</a>	IY	<a href="#">124-0104</a>	01	001	FLANGE GP-EXHAUST
	I	LA0498	06	001	LOAD SHARE MODULE
<a href="#">NPR</a>	IY	<a href="#">149-6326</a>	02	001	GOVERNOR GP-ELECTRONIC
	I	PA4393	06	001	JACKET WATER HEATER - DUAL
<a href="#">NPR</a>	IY	<a href="#">6I-1043</a>	03	001	MOUNTING GP-JACKET WTR HEATER
<a href="#">NPR</a>	IY	<a href="#">6I-1044</a>	07	001	MOUNTING GP-JACKET WTR HEATER
<a href="#">NPR</a>	IY	<a href="#">7E-6248</a>	06	001	HEATER GP-JACKET WATER
<a href="#">NPR</a>	I	134-1157	00	001	RELAY GP
<a href="#">NPR</a>	IY	<a href="#">121-4712</a>	01	001	PANEL GP-ELECTRONIC
<a href="#">NPR</a>	IY	<a href="#">121-4716</a>	01	001	MODULE GP-ALARM
	I	121-4713	00	001	INSTRUCTIONS
	I	PA5313	05	001	LUBRICATING OIL
<a href="#">NPR</a>	I	5P-2586	03	001	OIL
<a href="#">NPR</a>	IY	<a href="#">8N-6435</a>	02	001	FILTER GP-PRIMARY FUEL
<a href="#">NPR</a>	IY	<a href="#">3E-0264</a>	02	001	SWITCH GP-TEMPERATURE
<a href="#">NPR</a>	IY	<a href="#">9Y-8234</a>	03	001	MOUNTING GP-RADIATOR
<a href="#">NPR</a>	IY	<a href="#">5R-7425</a>	01	001	BARRING GP
	I	LA0427	08	001	CHARGING ALTERNATOR 24V 35AMP
<a href="#">NPR</a>	IY	<a href="#">7C-4803</a>	02	001	ALTERNATOR GP-CHARGING
<a href="#">NPR</a>	IY	<a href="#">7E-4836</a>	04	001	MOUNTING GP-ALTERNATOR
<a href="#">NPR</a>	IY	<a href="#">7W-5780</a>	04	001	GUARD GP-BELT
<a href="#">NPR</a>	IY	<a href="#">107-7361</a>	01	001	DRIVE GP-ACCESSORY
<a href="#">NPR</a>	I	133-6468	01	001	WIRE AS-GROUND
<a href="#">NPR</a>	I	7C-3874	02	001	BATTERY CHARGER
	I	PA1787	09	001	24 VOLT BATTERY SET - DRY
<a href="#">NPR</a>	IY	<a href="#">7L-7872</a>	08	001	BATTERY GP
<a href="#">NPR</a>	IY	<a href="#">5N-4659</a>	06	001	REGULATOR GP-OIL LEVEL

	I	LA1060	05	001	FUMES DISPOSAL
<a href="#">NPR</a>	IY	<a href="#">9Y-5563</a>	00	001	FUMES DISPOSAL GP
<a href="#">NPR</a>	IY	<a href="#">120-9818</a>	04	001	FUMES DISPOSAL GP
<a href="#">NPR</a>	IY	<a href="#">115-1063</a>	02	001	PUMP GP-FUEL PRIMING
	I	139-1129	00	001	COOLANT SENSING PROGRAM
<a href="#">NPR</a>	IY	<a href="#">111-3794</a>	00	001	SENSOR GP-COOLANT LEVEL
<a href="#">NPR</a>	IY	<a href="#">7W-0825</a>	01	002	CABLE GP-BATTERY
<a href="#">NPR</a>	IY	<a href="#">3N-7056</a>	00	002	SUPPORT GP-BATTERY
	I	0P-1530		001	GENERATOR TEST REPORT
	I	0P-1578		001	PRIME PLUS 10% RATING-3500
	I	0P-1793		001	GEN SET TEST CHG AT 0.8 PF
	I	5N-9600		001	VOLTAGE INDICATOR - 2400 VOLT
	I	PP3111	09	001	2628 BHP 1880 GEN KW WOF 60 HZ
	I	2T-7784	00	001	1960 KW @ 1800 RPM (2628 BHP)