

3512B GEN SET ENGINE

Engine Serial Number - 6WN (Build Date - 09/2000, Test Date - 09/2000, Ship Date - 10/2000)

▼ ENGINE - ENTIRE GROUP (6WN)

<u>Qty.</u>	<u>NPR</u>	<u>Note</u>	<u>Part No.</u>	<u>Change Level</u>	<u>Req. Qty</u>	<u>Part Name</u>
						FEATURE CODES
		I	KW01500	F	001	1500 EKW W/FAN
		I	512DE76	F	001	3512B 1500 EKW 60 HZ - LO BSFC
		I	EMCPLUS	F	001	EMCP TWO PLUS
		I	EMCAM07	F	001	ALARM MODULE - NFPA 110
		I	EMCPLAR	F	001	PANEL LIGHTS/AUXILIARY RELAY
		I	CLSSTND	F	001	COOLANT LOSS SENSING
		I	EMCEFR1	F	001	RELAY GP
		I	CCM0001	F	001	CUST COMMUNICATIONS MODULE-CCM
		I	ALSLSM1	F	001	LOAD SHARE MODULE
		I	GENCON1	F	001	GENERATOR CONVERSION
		I	SHREL01	F	001	SPACE HEATER RELAY
		I	RAD6007	F	001	RADIATOR 60/CV, 0.357
		I	RRM0032	F	001	RADIATOR REMOVAL 46/CV, 0.428
		I	CLS0010	F	001	COOLANT LEVEL SENSOR
		I	FPPRH02	F	001	FUEL PRIMING PUMP, RH MOUNTED
		I	FLN0001	F	001	FLEXIBLE FUEL LINES
		I	FUMDIS4	F	001	FUMES DISPOSAL
		I	OPADR4	F	001	OIL PAN DRAIN VALVE
		I	LUBOIL1	F	001	LUBRICATING OIL
		I	JWHD002	F	001	JACKET WATER HEATER - DUAL
		I	ELSDLH3	F	001	ELEC START MTR LH DUAL 24V
		I	BAT2418	F	001	24 VOLT BATTERY SET - DRY
		I	BTRCBL1	F	001	BATTERY CABLES
		I	ALT2442	F	001	CHARGING ALTERNATOR 24V 35 AMP
		I	60H-0480	F	001	60HZ 480 VOLTS
		I	MSEPGGN	F	001	GENERAL EPG
		I	TRSGEN7	F	001	GEN SET TEST CHG AT 0.8 PF
		I	3512B	F	001	3512B DIESEL ENGINE.
		I	LOWBSFC	F	001	LO BSFC
		I	60HERTZ	F	001	60 HERTZ
		I	STANDBY	F	001	STANDBY POWER APPLICATION
		I	EMCPTWO	F	001	ELECTRONIC MODULAR CONTROL PNL

PART NUMBERS

	I	PP3562	07	001	2172 BHP 1545 GEN KW WOF 60 HZ
	I	LA2123	02	001	3512B 1500 EKW 60 HZ - LO BSFC
	NPR	IY 128-2846	04	001	ENGINE AR
	I	3L-0414		001	SINGLE BEARING GEN ALIGN-3500
	I	3L-0432		001	TEST - PKG GEN SET (EMCP II
	NPR	IY 4P-0558	01	001	AIR CLEANER GP
	I	5N-9582		001	LOW BSFC - 3500B SERIES.
	I	5P-2506	00	001	LITERATURE GP
	NPR	IY 7N-6782	08	001	INDICATOR GP-AIR FILTER CHANGE
	NPR	IY 7W-6669	01	001	GUARD GP-DAMPER
	NPR	IY 8N-9639	04	001	GUARD GP-DAMPER
	NPR	I 104-4704	03	001	MOUNTING GP-CONTROL PANEL
	NPR	IY 113-1592	04	001	MOUNTING GP-AIR CLEANER
	NPR	I 115-7033	00	001	RAIL GP-ENGINE & GEN SUPPORT
	NPR	IY 121-4450	10	001	PANEL GP-CONTROL
	NPR	IY 121-8856	06	001	CONNECTION GP-ELECTRICAL
	NPR	IY 126-9191	03	001	GROUND GP-ELECTRICAL
	NPR	IY 134-0056	04	001	WIRING GP-ENGINE
	NPR	I 141-1808	01	001	BOX GP-GENERATOR CONNECTION
	NPR	I 144-1668	03	001	GENERATOR AR
	NPR	I 153-0191	04	001	INSTALLATION AR-GENERATOR
		IY 158-6167	04	001	CONVERSION AR
	I	121-4713	00	001	INSTRUCTIONS
	NPR	I 121-9480	02	001	CONNECTION GP-TERMINAL STRIP
	NPR	IY 121-4717	01	001	MODULE GP-ALARM
	NPR	IY 121-4712	01	001	PANEL GP-ELECTRONIC
	I	139-1129	00	001	COOLANT LOSS SENSING
	NPR	I 134-1157	00	001	RELAY GP
	NPR	I 102-8627	01	001	MODULE GP-SYSTEM COMMUNICATION
	I	LA0498	06	001	LOAD SHARE MODULE
	NPR	IY 149-6326	03	001	GOVERNOR GP-ELECTRONIC
	I	LA1969	03	001	GENERATOR CONVERSION
	NPR	I 154-6022	00	001	CONVERSION GP-GENERATOR
	I	3L-0456		001	PROCEDURE - DVR PROG AND TEST
	NPR	I 121-6202	06	001	REGULATOR GP-VOLTAGE
	NPR	I 145-5138	00	001	WIRING GP-ELECTRONIC CONTROL
	NPR	I 122-0335	02	001	RELAY GP
	I	LA2421	01	001	RADIATOR 60/CV, 0.357
	NPR	I 9Y-8563	00	001	COVER GP-SHIPPING
	NPR	I 120-9108	02	001	RADIATOR & FAN GP

	I	LA1296	01	001	RADIATOR REMOVAL 46CV, 0.428
NPR	IY	121-3356	02	001	SENSOR & MTG GP-RADIATOR
	I	LA3236	00	001	FUEL PRIMING PUMP AR-RH
NPR	IY	124-3187	04	001	LINES GP-FUEL PRIMING
NPR	IY	165-9154	02	001	PUMP GP-FUEL PRIMING
NPR	IY	5N-2438	05	001	LINES GP-FLEXIBLE FUEL
	I	LA1060	05	001	FUMES DISPOSAL
NPR	IY	9Y-5563	00	001	FUMES DISPOSAL GP
NPR	IY	120-9818	04	001	FUMES DISPOSAL GP
NPR	IY	9Y-7876	01	001	DRAIN GP-ENGINE OIL
	I	PA5311	05	001	LUBRICATING OIL
NPR	I	5P-2586	03	001	OIL
	I	PA4391	08	001	JACKET WATER HEATER - DUAL
NPR	IY	6I-1041	04	001	MOUNTING GP-JACKET WTR HEATER
NPR	IY	6I-1042	06	001	MOUNTING GP-JACKET WTR HEATER
NPR	IY	7E-6248	06	001	HEATER GP-JACKET WATER
	I	PA2478	06	001	ELECTRIC STARTING MOTOR LH
NPR	IY	8N-3896	14	001	STARTING MOTOR GP-ELECTRIC
	I	PA1788	10	001	24 VOLT BATTERY SET - DRY
NPR	IY	7L-7871	08	001	BATTERY GP
NPR	IY	7W-0825	01	001	CABLE GP-BATTERY
	I	LA0427	08	001	CHARGING ALTERNATOR 24V 35AMP
NPR	IY	7C-4803	02	001	ALTERNATOR GP-CHARGING
NPR	IY	7E-4836	04	001	MOUNTING GP-ALTERNATOR
NPR	IY	7W-5780	04	001	GUARD GP-BELT
NPR	IY	107-7361	01	001	DRIVE GP-ACCESSORY
NPR	I	133-6468	01	001	WIRE AS-GROUND
	I	5N-9597		001	VOLTAGE INDICATOR - 480 VOLT
	I	0V-1065		001	END USE: GENERAL EPG
	I	3L-0334		001	NAMEPLATE INFORMATION
	I	0P-9715		001	EXTRA LITERATURE-G.S. M/AUX
	I	0P-1793		001	GEN SET TEST CHG AT 0.8 PF
	I	PP3562	07	001	2172 BHP 1545 GEN KW WOF 60 HZ
	I	2T-8373	00	001	1620 KW @ 1800 RPM (2172 BHP)
					SHIPPED LOOSE
NPR	S	0S-1588		008	BOLT
NPR	S	1D-4706		002	BOLT
NPR	S	2A-1538		008	BOLT
NPR	S	2J-3506		014	NUT-FULL
NPR	S	2N-8928		008	CLIP

	NPR	S	2V-7397	002	CABLE AS
	NPR	S	3B-2968	010	BOLT
	NPR	S	3B-7749	001	NIPPLE-PIPE
	NPR	S	3K-1715	001	CABLE AS
	NPR	SY	3N-2451	004	JOINT AS-TUBE
	NPR	S	3N-6504	001	HOSE AS
	NPR	S	3V-6785	001	CABLE AS
	NPR	S	4D-7794	002	CLIP
	NPR	S	4P-3117	001	VALVE-BALL
	NPR	S	5F-5990	002	CLIP
	NPR	S	5M-2894	016	WASHER-HARD
	NPR	S	5P-0597	002	CLAMP-HOSE
	NPR	S	5P-1472	580	HOSE
	NPR	S	5P-8154	002	JOINT AS-TUBE
	NPR	S	5P-8248	032	WASHER-HARD
	NPR	S	6V-3835	001	SEAL-O-RING
	NPR	S	7C-3879	002	BAR
	NPR	S	7C-3892	002	BRACKET
	NPR	S	7K-1181	007	STRAP-CABLE
	NPR	S	7N-5274	001	COVER AS-TERMINAL
	NPR	S	8L-8413	004	STRAP-CABLE
	NPR	S	8N-0869	001	COVER-TERMINAL
	NPR	S	8N-1186	001	HOSE AS
	NPR	S	8N-1663	002	BOOT
	NPR	S	8N-1725	001	COVER AS-TERMINAL
	NPR	S	9G-0003	004	COVER AS-TERMINAL
	NPR	S	9G-0004	004	COVER AS-TERMINAL
	NPR	S	9G-8909	001	COVER-TERMINAL
	NPR	S	9S-8752	008	NUT-FULL
	NPR	S	9X-9720	004	BATTERY
	NPR	SY	111-3794	001	SENSOR GP-COOLANT LEVEL
	NPR	S	120-9107	001	RADIATOR & FAN GP
	NPR	S	121-3369	001	HARNESS AS-SENSOR
	NPR	S	126-5957	001	ELBOW
	NPR	SR	164-8940	001	MODULE GP-SYSTEM COMMUNICATION
	NPR	S	171-6719	001	KIT-PARTS
	NPR	SY	171-6721	001	KIT-PARTS
		S	JERC2162	001	SOFT
		S	SEBP2414	002	PTSBK
		S	SEBP2443	002	PTSBK



S	SEBU6042	002	SUPP
S	SEBU6251	002	LUBE 1632-16 (A)
S	SEBU6874	001	S.I.
S	SEBU6916	002	OMM
S	SEBU6918	002	OMM
S	SEBU6984	002	SUPP 140013B1(A)
S	SELF5308	001	WARRANTY 140013C2(A)
S	SELS0086	002	S.I.
S	SENR4794	002	SCHEMATIC
S	ESO	001	(PRNT ESO COPY)
S	PML	001	*REQUIRED DECALS